


5122W Multimedia Keyboard Block diagram



BTC	S0	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	S13	S14	S15	S16	S17	S18
R0	139 Game	121 F10	136 Vol+ DN	137 Vol- UP	135 Mute	134 Win	133 www	132 Menu /?	45 102 KEY	131 Close	142 F1	77 F11 Left	141 F12 Right	67 Japan	65 Japan	130 Play	128 Next	129 Prev	138 ZZ
R1	35 G	36 H	37 J	33 D	32 S	47 X	76 Del	46 Z	81 End	86 Page DN	140 Stop			60 Alt Left		92 4	97 5	68 Erase Ease	107 Brazil
R2	8 & 7	12 - -	123 F12	124 Print Screen	13 + =	15 Back Space	115 F4	116 F5	80 Home	85 Page UP	56 Japan		78 F12 Right	14 Japan	66 Japan	91 7 Home	96 8 ↑	82 Esc	113 F2
R3	9 * 8	7 ^ 6	6 % 5	5 \$ 4	4 # 3	3 @ 2	125 Scroll Lock	114 F3	1 ~ ,	126 Pause				58 Ctrl Left	89 →	84 ↓	79 ←		110 Esc
R4	25 O	24 I	26 P	122 F11	27 { 	31 A	75 Insert	28 } 	42 (UK)	43 Enter	57 Shift Right				143 Power	105 +	106 ↑	83 Num Lock	112 F1
R5	10 (9	119 F8	120 F9	38 K	39 L	40 ; :	41 " ,	52 M	51 N	29 _ \			62 Alt Right	144 Sleep	100 *	95 /	90 Num Lock	101 Pg Up	
R6	11) 0	34 F	118 F7	117 B	49 V	53 < ,	54 > .	55 ? /	61 Space Bar					64 Ctrl Right	103 Pg Dn	98 2 ↓	93 1 End	102 6 →	
R7	23 U	22 Y	21 T	20 R	19 E	18 W	17 Q	48 C	16 Tab	30 Caps Lock	44 Shift Left				145 Wake up	99 Ins	104 Del	108 Enter (Pad)	2 1

BTC	S0	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	S13	S14	S15	S16	S17	S18
R0	139 Game	121 F10	136 Vol+ DN	137 Vol- UP	135 Mute	134 Win	133 www	132 Menu /?	45 102 KEY	131 Close	142 FF	77 FB Left	141 FB	67 Japan	65 Japan	130 Play	128 Next	129 Prev	138 ZZz
R1	35 G	36 H	37 J	33 D	32 S	47 X	76 Del	46 Z	81 End	86 Page DN	140 Stop			60 Alt Left		92 4 ←	97 5	68 Erase Erase	107 Brazil
R2	8 &	12 -	123 F12	124 Print Screen	13 +	15 Back Space	115 F4	116 F5	80 Home	85 Page UP	56 Japan		78 FB Right	14 Japan	66 Japan	91 7 Home	96 8 ↑	82 F2	113
R3	9 *	7 ^	6 %	5 \$	4 #	3 (@)	125 Scroll Lock	114 F3	1 ~	126 Pause					58 Curl Left	89 →	84 ↓	79 ←	110 Fisc
R4	25 O	24 I	26 P	122 F11	27 {	31 A	75 Insert	28 }	42 \ (UK)	43 Enter	57 Shift Right				143 Power	105 -	106 +	83 ↑	112 F1
R5	10 (	119 F8	120 F9	38 K	39 L	40 ;	41 "	52 M	51 N	29 				62 Alt Right	144 Sleep	100 *	95 /	90 Num Lock	101 Pg Up
R6	11)	34 F	118 F7	117 F6	50 B	49 V	53 <	54 >	55 ?	61 Space Bar					64 Curl Right	103 3 Pg Dn	98 2 ↓	93 1 End	102 6 →
R7	23 U	22 Y	21 T	20 R	19 E	18 W	17 Q	48 C	16 Tab	30 Caps Lock	44 Shift Left				145 Wake up	99 0 Ins	104 .	108 Enter (Pad)	2 1