


# USER MANUAL

## E506

### Safety Warning

- Before using the unit please read the manual.
- Keep this product away from any water, liquid or wet areas.
- Keep this product away from open flames such as candles.
- This item is ONLY to be plugged into an AC 100V~240V Power outlet.
- The unit should be powered off before unplugging the product.
- Do not place the product in direct sunlight or heat. Keep away from temperatures over 35°C.
- Never try to repair this product yourself, take it to an authorized technician. Trying to remove panels or repairing the unit yourself could result in an electric shock.
- Do not insert foreign objects into the product.
- Adult Supervision is recommended if children are using this product



### Operating instructions :

Put E506 product on the mobile wireless-receiving sense area (the printed mark on furniture ), and the phone can be charged

### FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

### Specifications :

Input: 5V2A

Output: 5V1A

Power: 5W

### Trouble Shooting :

| Appearance                         | Passable Reason                     | How to Solve                                |
|------------------------------------|-------------------------------------|---------------------------------------------|
| Can not charge the phone           | Power plug does not connect         | Re connect the power plug                   |
|                                    | USB plug does not connect           | Re connect the USB plug                     |
| The charging light does not work   | Does not align to the charging area | Try move around                             |
|                                    | Receiver or transmitter not work    | Try another receiver or contact your dealer |
| The phone is too hot when charging | Does not align to the charging area | Try move around                             |