60mm

HA-B5T

| JVL | WIRELESS HEADPHONES |
|-----|---------------------|
| | Instruction Manual |

1 / n

69mm



website : us.ivc.com

CHARGING THE EARBUDS

Put the earbuds into the charging case, the earbuds will be charged automatically. The red status LED light will be on during charging and will turn off when fully charged.

CHARGE THE CHARGING BOX

Use a Type-C cable connected to a USB charger (DC 5V-1A)

THE STEPS FOR DUAL EARBUDS PAIRING (FIRST USE ONLY)

Take out both earbuds from the charging case the same time. LED light on both earbuds will be flashing blue & red at first. One of the earbud's LED light will turn Off after 2 seconds. It means that both earbuds are ready to pair. Turn on the bluetooth on your device and search for a new device then select "JVC HA-B5T" to connect.

HOW TO RE-CONNECT


The earbuds will automatically try to re-connect with the last paired device after re-start. If not, please put earbuds back to charging case and try again or connect manually.

Caveats

- 1. Never disassemble or modify your earbuds for any reasons to avoid any damages and danger.
- 2. Do not store the earbuds and charging case in extreme temperatures
- (under 5°C or over 35°C).
- 3. Avoid using the indicator close to the eyes of children or animals.
- 4. Do not use this earbuds during a thunderstorm to avoid irregular function and increased risk of electricshock.
- 5. Do not use harsh chemicals or strong detergents to clean the earbuds.

6. Keep the headset dry.

PRODUCT DESCRIPTION



1. Charging Case 2. Power Button Status LED 3. Multi Function Button (MFB) 4. Status LED

COMMON PROBLEMS AND SOLUTIONS:

1. The mobile phone cannot find the wireless earbuds - Check whether the earbuds power is switched On or not. - Does the status LED light flicker red & blue alternatively? If the wireless earbuds still haven't been found after switching power On, please restart both the earbuds and the bluetooth search on your phone.

2. There is something wrong with the wireless earbuds while using it.

- Please try to re-connect with the mobile phone after turning it Off and restarting the earbuds. - Check the charging status of the earbuds by putting them into the charging box until the red LED indicator is On. Then take them out and let them trying to re-connect with the mobile device.

3. The wireless earbuds always disconnect or make noise when connected to the mobile device.

- The wireless earbuds power status is low, please re-charge it. - There is an obstruction between the mobile device and the wireless earbuds, or the wireless distance is beyond signal range. Please do not cover the wireless earbuds with your hands in order to maintain the continuous stability of the signal; please try to keep the wireless earbuds and the mobile device in the same direction

SPECIFICATIONS

 Wireless version: V5.0 Wireless range: 10M Plavtime: 4 Hours · Charging Time: 1 hr earbuds 1.5 hr charging case Battery Capacity: Earbuds 30mAh Case 200mAh Operation Frequency: 2402-2480MHz Operational Temperature: -10 - 40°C Charging Port: Type-C

PACKAGE CONTENTS

Earbuds x 2 Earbuds caps: Charging case × 1 Size S x 2 Charging cable × 1 Size M x 2 (installed) User manual × 1 Size L x 2

FCC Statement:

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired open
- FCC CAUTION:

tions not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that intereference will not occur in a particular installation. If this an imment chas cause harmful interference to radio or television recention which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measure

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receive - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help This transmitter must not be co-located or operated in conjuction with any other antenna or transmitter
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines as

this equipment has very low levels of RF energy.

Tips:

Before using the earbuds, please read the manual carefully and keep it for future references
The earbuds need to be fully charged prior to first-time use.

If the earbudd is left unused for over two weeks, please recharge it periodically.
Please use the chargers made by qualified manufacturer.

5. If the earbuds cannot be found by your phone, please check whether it is in pairing mode; if left unconnected for a long while, the earbuds will exit pairing mode, please re-enter the mode; if a procedure error of your

curs, reboot it: if a procedure error of the earbuds occurs, reboot or reset it.

MADE IN CHINA Support

rchased is powered by a rechargeble battery that is 800-8-BATTERY for information on house

Function

Power on

Power off

Pairing Mode

Charging case charging

Charging case fully

Earbuds charging

Earbuds fully charged Play/Pause

Picking up incoming call

For Customer Use:

Model No.

Serial No.

End phone call

Next song

Previous song

Reject incoming call

Connected

charged

Operation

Take out the earbuds from the charging case.

ED light flashing red & blue at first. One of the

earbuds will be off automatically after 2 seconds.

Red LED lights on earbuds turn off automatically.

Put the earbuds into the charging case.

LED light is off on both earbuds

Red LED lights on earbuds are on.

Triply press the MFB of the right earbud

Triply press the MFB of the left earbud

Or long press MFB

Red LED light flash

Red LED light is on

Single touch MFB

Single touch the MFB

Single touch the MFB

Long touch the MFB

Enter the Model No. and Serial No. (on the charging case) below.

Reponsible party : JVCKENWOOD USA Corporation

(1) This device may not cause harmful interference, and

including interference that may cause undesired operation.

(2) this device must accept any interference received,

This device complies with part 15 of the FCC Rules. Operation is

Address: 1440 Corporate Drive, Irving, TX 75038

Retain this information for future reference

Supplier's Declaration of Conformity

Telephone Number: (678)449-8879

subject to the following two conditions:

Model Number : HA-B5T

Trade Name : JVC

FCC ID: 24370-HAR5T

JVC IS HERE TO HELP!

TOLL FREE: 1(800)252-5722

http://www.us.jvc.com