### **Customer Service**

Warranty: 12-Month Limited Warranty

Support: Lifetime Technical Support

Email: support@govee.com

Official Website: www.govee.com



For FAQs and more information, please visit: WWW.govee.com

#### FCC and ISED Canada Statement

This device complies with Part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil nedoit pas produire de brouillage, et.

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélec trique subi, même si le brouillage est susceptible d'en comprom ettre le fonctionnement.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- 2. Increase the separation between the equipment and receiver.
- 3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4. Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-005.

Cet appareil numérique de la classe B est conforme à la norme

NMB-005 du Canada.

### FCC and IC Radiation Exposure Statement

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Lors de l'utilisation du produit, maintenez une distance de 20 cm du corps afin de vous conformer aux exigences en matière d'exposition RF.

Responsible party (this contact information is only for FCC matters):

Name: GOVEE MOMENTS(US) TRADING LIMITED Address: 2501 Chatham Rd Suite R Springfield IL 62704 Email: certification@govee.com Contact information: https://www.govee.com/support

All Rights Reserved.

The trademark Govee have been authorised to Shenzhen Qianyan Technology LTD.

Copyright ©2021 Shenzhen Qianyan Technology LTD.



**User Manual** 

Model: H7063 Govee Triad Flood Light

### Safety Instructions

- The product is of high brightness. Avoid looking at it directly.
- The light body is rated as IP66 waterproof while the control box is IP67. It can be used outdoors but cannot be immersed in water.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
- To reduce the risk of strangulation the flexible wiring connected to this luminaire shall be effectively fixed to the wall if the wiring is within arm's reach.
- Do not allow children to assemble and install this product without adult supervision.
- Avoid installing this product near major heat sources.
- External dimmers cannot be used with this product.
- Use this product with the provided power adapter only.
- CAUTION-The product is not a toy. Children and the disabled should use it under adult supervision.
- Risk of Electric Shock. The adapter install only to a covered Class A GFCI receptacle that has an enclosure that is weatherproof with the attachment plug cap inserted or removed.

01


### Introduction

Thanks for choosing the Govee Triad Flood Light. This product can be easily installed on the ground. It can bring you an excellent experience whether being used to light up the surroundings or as a decor for the backyard. The foldable design allows for a wider illumination area. You can also create various scenes and ambiance with the RGBIC technology.

### What You Get

Item	Quantity
Flood Light	1
Adapter	1
Control Box	1
Accessory Kit	1
Quick Start Guide	1
User Manual	1

### At a Glance



# Follow the Quick Start Guide to Install the Product

# Pairing Your Device with the Govee Home App

#### What You Need

- A Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
- A smartphone or tablet running iOS or Android.



- Download Govee Home App from the App Store (iOS devices) or Google Play (Android devices).
- 2. Turn on your smartphone's Bluetooth.
- 3. Open the app, tap the "+" icon in the top right corner and search "H7063."
- 4. Tap the device icon and follow the on-screen instructions to complete pairing.

### **Specifications**

Power Input	100-240VAC 50/60Hz
Power Output	24VDC 2A
Light Color	RGBWW
Color Temperature	2700K~6500K
Lumens (6500K)	4500lm
Waterproof	Control Box (IP67)
	Flood Light (IP66)
Working Temperature	-20°C~45°C/-4°~113°F

### **Troubleshooting**

- 1. Failed to connect to Wi-Fi.
- a. Make sure the distance between the device and the router is less than 100ft.
- b. Keep as few obstructions (e.g. wall, windows, etc.) as possible between the device and the router.
- c. Make sure the Wi-Fi name and the password you entered is correct.
- d. Make sure the Wi-Fi you connect to is 2.4GHz. 5GHz is not supported.

- a. Make sure your home Wi-Fi is working normally.
  - b. Check whether the Wi-Fi password has been modified
  - c. Keep as few obstructions (e.g. wall, windows, etc.) as possible between the device and the router.

2. Lost Wi-Fi connection./Cannot use the device with the app.

- d. Check whether the device is connected to Wi-Fi. If the device is not connected to Wi-Fi, please reconnect by following the above steps.
- 3. Cannot pair or connect with Alexa or Google Assistant.
- a. Ensure the stability of the Wi-Fi connection.
- b. Go to the app's "Settings" page and follow the instructions under "User Guide" to pair the device again.
- 4. The synchronization effect for Music Mode does not work properly.
- a. Make sure the control box is close to the music source, which will help the mic pick up sounds better.
- 5. Can multiple users control one device?
- a. Each device can only be controlled by one account.
- b. If multiple users want to control the same device, make sure they are using the same account.

02 03 04 05 06