

MC92N0

QUICK START GUIDE




BATTERY INSERTION


<http://www.motorolasolutions.com/mc92n0-g>
See User Guide for more information

POST IN WORK AREA


Front View




Battery Removal



Stylus Removal




SNAP-ON ACCESSORY INSTALLATION




CHARGING INSTRUCTIONS


⦿ = LED Indicator Location Slow Flash = Normal Charge Solid Amber = Full Charge Fast Flash = Charging Error



Four Slot Spare Battery Charger




Single Slot Serial/USB Cradle




Four Slot Cradles
Charge-Only Cradle and Ethernet Cradle

OPTIMUM IMAGING AND SCANNING POSITIONS


Laser Scanning



Standard Range Imaging





Long Range Imaging



OPTIMUM UPRIGHT BODY POSTURE




AVOID EXTREME WRIST ANGLES



OPTIMUM BODY POSTURE

Low Scanning
Alternate left and right knees



Alternate left and right hands



High Scanning
Use a ladder



Taking breaks and task rotation recommended

POST IN WORK AREA

