


SARINA

FLOATING


WATERPROOF SPEAKER & LED PHONE POUCH



Product Diagram



Button Functions



1. Light: 8 light modes, single press to cycle, long press to switch FM radio single press Power/Pause button to search station
2. Previous Track/Volume Down: Short press for previous track
Long press for lower volume
3. Pause/Power: Long press for power on/off
Short press to pause track/answer phone call
Double press to hang up phone call
4. Next Track/Volume Up: Short press to play next track
Long press to raise volume
Double press to enter TWS function
5. 5V Charging Port

Bluetooth Connection

1. Long press the on/off button to turn on speaker. It will automatically enter bluetooth pairing mode
2. Open Bluetooth list of input device, select "SA-POOL" in the available devices
3. Speaker will chime when connection is successful

Specifications

Power: 3W
Waterproof: IPX8
Play Time: 4-5hrs
Frequency Response: 180Hz ~ 80KHz
Bluetooth® Version: 5.0
Battery: 3.7V 1200MAH
Speaker Size: 52mm
Vibration Mode Size: 52mm
Light Changing Current: 5V 1A
Product Size: 6.3 x 6.3 x 2.1in (162x162x55mm)
BT ID: D059694
FCC ID: 2AANZPOOL-F

Troubleshooting

1. If the Speaker is not responding
 - Device turns itself off after a few hours of inactivity
 - Device may need to be charged
2. Bluetooth Interference
 - Device has a bluetooth range of 16.5ft (5m) be sure your connected device is within range of speaker
3. Bluetooth cannot connect
 - Be sure you've connected to the correct speaker. If not you may need to reboot the speaker
 - Check for other nearby Bluetooth devices that have have connected instead of the intended device

Notice

- Speaker should be kept in a cool dry place when not in use. Keep away from extreme heat or cold sources
- Do not dismantle or repair the your speaker
- Do not drop device
- Be sure to dispose of speaker correctly. Battery may cause fire if not disposed of properly

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING:

Contains button or coin cell battery.
Hazardous if swallowed -see instructions.

This product contains a Button or Coin Cell Battery. A swallowed Button or Coin Cell Battery can cause internal chemical burns in as little as two hours and lead to death. Dispose of used batteries and keep batteries out of reach of children. If swallowed, contact a physician or your local Poison Control Center immediately.



IPX8 Waterproof

Keep your mobile device safe when you're outdoors, hiking, boating, or in weather. The innermost layer is designed to be waterproof to keep your smart phone safe. The easy swivel snap and lock closure gives you access to your device quickly without any complicated setups required.

Touch Screen Responsive

Our case is constructed with smart phones in mind, and the touch screen responsive window also protects your device from scratches. A double window means you can take photos with your phone as well.

Bright LED Lights

The LED lights work under water! Perfectly sealed, turn on your LED lights before swimming, rain or going on an adventure. Enjoy the beautiful lights or use them to light up the space around you.

Detachable Neck Strap

An optional detachable neck strap is included for you to keep your device easily within reach. Simply hook onto the top of the Phone Pouch to keep your smart phone safe while you're on-the-go.

SARINA

SARINA guarantees the quality of the product.
For questions or comments, please feel free to contact us
via email at support@digust.com
Distributed by DIGU Group Ltd, Etilon AU 28817
www.digust.com