

Re: Certification for Delco Delphi
Communiport MPC-PRO
Model: 12205129
FCC ID: L2C0014T

USER'S MANUAL

The user's manual is in preparation at this time. The following material will be contained in the vehicle owner's manual:

(PRELIMINARY)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

1		
2	Table of Contents	0
3	Welcome	3
4	System Overview	4
5	System Set Up	4
6	MPC PRO-10 Components	4
7	Installing the MPC PRO-10	4
8	Connecting the System	0
9	Using your Communiport MPC PRO-10	6
10	Activating the MPC PRO-10	0
11	Speech Recognition	0
12	Global Voice Commands	7
13	Switching Between Applications	7
14	Using the Date Book	8
15	Selecting dates	8
16	Selecting appointment entries	9
17	Using the Address Book	10
18	Categories	10
19	Looking up a record	11
20	Navigating Address Book entries	11
21	Dialing a phone number	11
22	Ending the call	12
23	Using the To Do List	12
24	Categories	12
25	Navigating Do List items	13
26	Using Memo Pad	14
27	Categories	14
28	Navigating Memo Pad items	14

29	Using Mail	15
30	Selecting Mailboxes and items	15
31	Navigating Mailboxes and items	16
32	Using the Phone Functions	16
33	Placing outgoing calls	16
34	Answering incoming calls	17
35	Ending calls	17
36		

(This should appear on a page prior to the table of contents.)

Information included in this owner's manual was accurate at the time of publication. Delphi Automotive Systems, however, reserves the right to make changes in product configuration and performance without prior notice.

Return Policy

Delco Electronics Corporation, a subsidiary of Delphi Automotive Systems (collectively "Delphi") will accept returns from the end user ("Customer") for a period of thirty (30) days after the sale. Provided the Customer has proof of purchase and the unit is in proper working order with no physical or cosmetic damage to the unit, Delphi will refund the Customer the purchase price paid for the unit. Shipping and handling fees are non-refundable.

Limited Warranty

Delco Electronics Corporation, a subsidiary of Delphi Automotive Systems (collectively "Delphi"), warrants to the end user ("Customer") that this product will be free from defects in workmanship and materials, under normal use, for ninety days from the date of original purchase from Delphi or its authorized reseller. Delphi's sole obligation under this expressed warranty shall be, at Delphi's option and expense, to replace the product or part with a comparable product or part, repair the product or part, or if neither repair or replacement is reasonably available, Delphi may, in its sole discretion, refund to the Customer the purchase price paid for the product or part. Replacement products or parts may be new or reconditioned. Delphi warrants any replaced or repaired product or part, and any hardware upgrade to which the Customer is entitled under the agreement between Customer and Delphi, for a period of thirty (30) days from shipment, or through the end of the original warranty, whichever is longer. All products or parts that are replaced become the property of Delphi.

(This should appear after the table of contents)

Welcome

The Communiport Mobile Productivity Center 500 Series (MPC PRO-10) is a unique mobile productivity tool designed to provide you hands-free, eyes-free access to the features and content of your Palm while you are on the road. Docking both a Palm handheld and a portable Ericsson phone, the MPC PRO-10 enables you to be more efficient, more informed and more connected, while keeping your hands and eyes free to navigate the road.

System Overview

Your Communiport Mobile Productivity Center Pro-10 (MPC PRO-10), designed to be convenient and easy to use enables hands-free and eyes-free access to the standard applications of your Palm V or Vx personal digital assistant. It also allows you to send and receive hands-free and eyes-free phone calls with your Ericksson R280 or 1228 mobile phone. Using the spoken commands to operate the MPC PRO-10, it will communicate to you through your FM radio or headphones.

[System Tree Chart including global commands – Insert figures 1]

The mounting hardware provided with your MPC PRO-10 accommodates a number of mounting configurations and plugs into an auxiliary power source such as a lighter, supporting your demand for communication and information while you are in your vehicle.

Warning: It is always important to keep your eyes on the road and hands on the wheel. Not doing so could result in injury to you or others.

System Set Up

MPC PRO-10 Components

[Show photos with callouts of the contents of the MPC PRO-10.]

The MPC PRO-10 consists of the following components:

- Docking station
- Adjustable mounting bar
- Phone cable
- Software

To fully enjoy the features and functions of your MPC PRO-10, you will need a Palm V or Vx, an Ericsson R280 or 1228 phone, and an FM radio or headphone set. Other handheld computing devices and cellular phones may not be compatible with your MPC PRO-10.

Installing the MPC PRO-10

Caution: Before you mount the MPC PRO-10 in your vehicle, make sure you are complying with your state's safety regulations for mounting devices to a vehicle's windshield.

To install the MPC PRO-10 in your vehicle:

1. Firmly attach the suction cup on a clean, dry area at the center of the windshield as close to the dashboard as possible.

[Insert drawing of correct windshield mount]

Warning: Be certain to mount the MPC PRO-10 in a position where it will not obstruct your ability to see the road or interfere with the functionality of safety features in your vehicle, such as head impact areas or deployment of the airbags. Not doing so could result in injury to you or others.

2. Extend the bar at about a 90-degree angle from the windshield. [Insert a drawing.]
3. Tighten the adjustment screws.

Warning: The bar should be mounted at a 90-degree angle and the adjustment screws fully tightened to ensure a secure mount. Failure to properly mount the MPC PRO-10 may cause it to release from the windshield in a collision, resulting in injury to you or others.

4. Tune your FM radio to 88.1. The MPC PRO-10 communicates with you by broadcasting to your radio on this channel. For you to be able to hear the MPC PRO-10's audio outputs, the radio must be turned on and tuned to this channel. For your convenience, you may want to set this channel as the first FM preset on your radio.

While the MPC PRO-10 is on and listening for your commands, your radio, cassette, or CD player will be disabled. When the MPC PRO-10 is switched to standby mode or turned off, your radio, cassette and CD player can again be used.

The MPC PRO-10 broadcasts messages to your FM radio. It will automatically broadcast to channel 88.1 unless you change the station.

Note: You can change the station your MPC PRO-10 broadcasts to using the "FM Tuner" command and following the voice prompts.

Nearby cars tuned to the station you are using might be able to hear the communication between you and your MPC PRO-10. Be careful not to say anything you don't want others to hear. To avoid this risk, connect headphones into the headphone jack on your MPC PRO-10 instead of broadcasting messages via your radio. This will disable the MPC's FM transmitter, eliminating the risk that you will be overheard.

Warning: Before listening to your MPC PRO-10 through headphones, make sure you are complying with your state's safety regulations for headphone use while driving.

Docking your Palm and Phone in the MPC PRO-10

Before using your Palm V or Vx with the MPC PRO-10, you must install the Communiport software provided with your MPC PRO-10. This software enables the MPC PRO-10 to interact with your Palm using voice commands. Consult your Palm user's manual for information on how to install software.

1. Install the MPC PRO-10 software provided following your Palm's instructions.
2. Dock your Palm in the MPC PRO-10 by placing it in the docking station.
While docked, your Palm's buttons and touch screen are disabled. You can only access Palm functions using voice commands.
3. Dock your Ericsson cellular phone in the MPC PRO-10 using the connecting cable provided.
4. Plug the MPC PRO-10's power cord into a 12-volt auxiliary power outlet such as your vehicle's lighter.

Note: For you to operate the Palm and phone using voice commands, both of them must be correctly docked and the phone must be on. Voice commands can also be used if either the Palm or the Ericsson phone is connected, but you can access only the functions of the connected device.

Using your Communiport MPC PRO-10

With the Communiport MPC PRO-10, you have eyes-free, hands-free access to your Palm and your Ericsson cellular phone. Your interface to information on the road, Communiport is convenient and easy to use.

Activating the MPC PRO-10

To activate the MPC PRO-10, press the Communiport button on the front of the docking station.

Each time you dock your Palm, it may take up to 7 minutes before it completes processing the information in your Palm and is ready to interact with you. Processing time depends on the amount of information you have stored in your Palm.

While the system is processing Palm data, the green ready light on the MPC PRO-10 will flash. When processing is complete, the ready light will stop flashing and remain on. When the MPC PRO-10 is ready to accept voice commands, it will say "Ready."

If you do not speak a command within 5 seconds, the MPC PRO-10 will prompt you for input by saying "Command Please." If you do not speak a command within 10 seconds, the MPC PRO-10 will say "Goodbye" and enter standby mode. The green ready light turns off.

You can also put the MPC PRO-10 in standby mode by saying "Shutdown" or by pressing the Communiport button. When in the standby mode, the MPC PRO-10 reduces power consumption and does not listen for or react to voice commands.

To return to interactive mode, press the Communiport button again. The ready light turns on and the MPC PRO-10 will say "Ready."

System Navigation

Communiport Mobile Productivity Center is operated using a series of voice commands. It compares your spoken command to a dictionary of preset voice commands and makes the best possible match.

Always speak your commands clearly and in a normal volume. Depending on the volume and clarity of your voice, other voices inside the vehicle or additional noise, the MPC PRO-10 may not always make a correct match. When the MPC PRO-10 does not respond with the correct command or does not understand you, repeat your command or use a synonym.

Note: If other passengers in the vehicle are talking when you speak a command, the MPC PRO-10 may hear and respond to their voices.

Note: There is no need to "train" the MPC PRO-10 to understand your voice.

When the MPC PRO-10 recognizes a spoken command, you will hear a confirmation tone. If your command is not recognized, the MPC PRO-10 will say "Command not recognized," and wait until you repeat it or speak another command.

Global Voice Commands

(Insert global commands diagram #7)

There are several voice Commands that can be used almost anytime the system is on, including:

Main Menu – Takes you from any application to the Main Menu. You can also say "Cancel" to return to the Main Menu.

What can I say? – Tells you what commands are currently available.

Shutdown – Turns off the voice recognition system and places the MPC PRO-10 in standby mode.

Repeat - Repeats the last MPC PRO-10 response.

Following your voice command, the MPC PRO-10 may reply with a brief prompt, a list of options, or read from your Address Book, Memo Pad or another application. You can interrupt the current response at any time by pressing the Communiport button. The MPC PRO-10 will stay in the same application and prompt you for your next command.

Switching Between Applications

To move from on application to another, return to the Main Menu by saying "Main Menu." Then say the command for the application you want to use.

215 Using the Date Book

216 (Insert drawing 3 – voice commands for date book)

217 The Date Book allows you to schedule and check appointments stored in your Palm
218 calendar using voice commands. To access your Date Book, say “Date book.”

219 The MPC PRO-10 responds with “Date book ...” followed by the current date and the
220 number of appointments for the day. It then says, “Your next appointment is at (the
221 time).”

222 **Note:** The MPC PRO-10 relies on your Palm for the current date and time when
223 processing all date/time-related functions. Verify that the date and time shown on your
224 Palm are correct.

225 If there are no appointments for the day, the MPC PRO-10 responds with "You have no
226 appointments."

227 Selecting dates

228 The following commands allow you to select dates in the Date Book:

229 **Today** – Reads the number of appointments for today, followed by information
230 about the first appointment.

231 **Tomorrow** - Reads the number of appointments for the day following the current
232 day and reads information about the first appointment for that day.

233 **Yesterday** – Reads the number of appointments for the day preceding the current
234 day, followed by information about the first appointment for that day.

235 **Next** - Reads the next appointment for the selected day.

236 **Previous** - Reads the previous appointment for the selected day.

237 **How many appointments?** – The MPC PRO-10 reads the number of
238 appointments for the current day. You can also say “How many entries?” If there
239 are no appointments for the day, the MPC PRO-10 responds with "You have no
240 appointments."

241 **Read Note** - Reads the contents of the note attached to the selected appointment.
242 If there is no note associated with the selected entry, the MPC PRO-10 responds
243 with "No note attached."

244

245 When you reach the last appointment and use the “Next” command, the MPC PRO-10
246 will respond by saying “No additional entries.” The same thing will happen if you are at
247 the top of a list and use the "Previous" command. The list will not "wrap" to the top from
248 the bottom, or vice versa.

249 You can move directly to any date by issuing a command using the month/day/year
250 format. For example, to go to August 12, 2001, say:

251 “August twelfth, two thousand and one.”

252 You can also move to a specific date using only the month and day. The MPC PRO-10
253 assumes that the year is in the upcoming 12-month period. For example, if on December
254 10, 2001, you said the command:
255 "February tenth"
256 The MPC PRO-10 would automatically assume the year is 2002.
257 To find an appointment in the current week, you can say a day of the week. The
258 MPC PRO-10 assumes that you mean the day within the **current** week, as defined
259 in your "Week starts" Palm preferences.
260 It is important to keep the current week in mind when entering or listening to Date Book
261 data.
262 Example: Assume that your preferences are set with Monday as the first day of
263 the week. If, on Sunday you want to look up an appointment, and say "Monday,"
264 the MPC PRO-10 will assume the previous Monday because that Monday is part
265 of the "current" week.
266 Assuming the preferences above, to look up a meeting for the following Monday, you
267 would say "Next Monday."
268 The commands "Next" and "Previous" are not related to your "Week starts" preferences.
269 If on Sunday you say the command "Next," the MPC PRO-10 will always access the
270 following Monday, regardless of your "Week Starts" preferences.
271 **Selecting appointment entries**
272 Use the following voice commands to navigate through your appointments for the
273 currently selected date:
274 **Go to last** - Reads the information about the last appointment for the currently
275 selected day.
276 **Go to first** - Reads the information about the first appointment for the currently
277 selected day.
278 **Go to** - Responds with "Number please." Say the number of an appointment for
279 the currently selected day. The MPC PRO-10 goes to the numbered appointment
280 for the currently selected day and reads the information about that appointment.
281 **Next** - Reads the information about the next appointment for the currently
282 selected day. If you are at the end of your appointment list for that day, the MPC
283 PRO-10 will say "No additional entries."
284 **Previous** - Reads the information about the previous appointment for the
285 currently selected day. If you are at the beginning of your appointment list for that
286 day, the MPC PRO-10 will say "No additional entries."
287
288 When saying information about an appointment, the MPC PRO-10 includes the time of
289 the appointment, the title of the appointment and indicates if there is a note attached.

290 If there is no time recorded for the appointment, the MPC PRO-10 will respond with "No
291 time."

292 Example:

293 "Thursday August thirty first two thousand, You have ten appointments. First
294 appointment, No Time, Meet with Sue sometime today. There is a note attached."

295 Using the Address Book

296 (Insert drawing 4 – voice commands for address book)

297 The Address Book allows you use voice commands to retrieve information about
298 "records" in your Palm. Each entry stored in your Palm is a separate record. For each
299 record, you can include address, phone and other data.

300 To access your Address Book using voice commands, say "Address Book."

301 Categories

302 When you switch to the Address Book, the MPC PRO-10 will begin in the All category
303 and respond with:

304 "Address Book, All category. Command please."

305 To change categories, say "Category." The MPC PRO-10 will respond by saying "New
306 category please." Say the name of the desired category. The MPC PRO-10 will confirm
307 the change by saying the name of current category and prompt with "Ready."

308 If the MPC PRO-10 is unable to find the category, it will respond with "Sorry, category
309 not found."

310 To determine the current category, say the command "Current category" and the MPC
311 PRO-10 will respond with "You are currently in the ... (name of category) ... category."

312 **Note:** To help organize records, your Palm can group items in the Address Book, To Do
313 List and Memo Pad into as many as 15 categories, plus the All and Unfiled categories.
314 Any category you create on your Palm will be recognized by the MPC PRO-10. By
315 dividing your records into categories, you will help the MPC PRO-10 understand your
316 commands. When you create categories, you reduce the number of records the MPC
317 PRO-10 must search through, and when searching a smaller number of records, the
318 probability of a first-time match is improved.

319 For example, if you have all of your records in a single category, it may have several
320 records with similar sounding names such as:

321 John Ames

322 Jane Iams

323 Johnnie James

324 The MPC PRO-10 may have difficulty determining which record you want to use. By
325 splitting your records into several categories, such as Family, Friends, Professional, etc.,
326 you may reduce the number of similar sounding names in each category.

NAME * MERGEFORMAT |1122ErError! Bookmark not defined.

327 **Looking up Address Book records**

328 To find a name (referred to in your Palm manual as a “record”) in your Address Book,
329 say “Look up.” The MPC PRO-10 responds with the prompt "Name please." Say the
330 name of the person you want to look up as you entered it in your Palm.
331 The MPC PRO-10 responds by saying “Found ...” followed by the record name and a
332 prompt to "Call or Read."
333 If no match is found, the MPC PRO-10 responds with "Command not recognized. Name
334 please." Say the name again to begin searching.

335 **Navigating Address Book entries**

336 The following voice commands can be used to move between records in the Address
337 Book:

338 **Next** – Moves to the next record in the current Address Book category.
339 When you reach the last appointment and attempt to move beyond it with the
340 “Next” command, the MPC PRO-10 will respond by saying “No additional
341 entries." The same thing will happen if you are at the top of a list and give the
342 "Previous" command. The list will not "wrap" to the top from the bottom, or vice
343 versa.
344 **Previous** – Moves to the previous record in the current Address Book category.
345 **Read** – Reads the contents of the currently selected Address Book record, starting
346 with the first field in the item and continuing through the last field, skipping all
347 empty fields. For example:
348 "Last Name: Doe, First Name: John, Title: Director, Company: Doe and
349 Sons, Work: 555.543.5555, Fax: 555.543.0000"
350 To stop the report at any time, press the Communiport button.
351 **Read Note** – Reads the contents of the note attached to the record. If there is no
352 note attached, the MPC PRO-10 says, "No note attached."

353 **Dialing a phone number**

354 To dial a phone number from the Address Book, look up the desired entry and then say
355 "Call." If the MPC PRO-10 doesn’t detect a phone that is on, it will say:

356 “Phone not detected or not activated."

357 If a phone is connected and active, the MPC PRO-10 will check the list of available
358 phone numbers for the currently selected record in your Address Book. If there is only
359 one phone number available, the MPC PRO-10 will respond by saying “Dialing” with the
360 phone number. For example:

361 “Dialing. Press the button to end the call.”

362 Your Palm can store up to 5 phone numbers for each record. If there is more than one
363 number for the selected record, the MPC PRO-10 responds to the “Call” command by
364 saying the labels you have assigned to the phone numbers in the record.

NAME * MERGEFORMAT |1122ErError! Bookmark not defined.

365 Example:

366 "Choose Work, Home or Fax."

367 **Note:** Your Palm allows you to include additional phone numbers in user-defined fields.
368 The MPC PRO-10 only recognizes the numbers stored in the Palm's 5 main phone
369 number fields.

370 To select the number to call, say the label for the desired phone number.

371 It is possible to have more than one phone number with the same label. You can move
372 through the list of available phone numbers by saying "No" as the MPC PRO-10 prompts
373 you with them. For example, if there are three phone numbers for the Work label, the
374 MPC PRO-10 would respond by saying:

375 "Call Work: Bob's office, 555-1212?"

376 Say the command "No" and the MPC PRO-10 will respond with the next entry in the
377 Work label:

378 "Call Work: Bob's assistant, 555-1213?"

379 You could again say the command "No." The MPC PRO-10 responds with the next entry:

380 "Call Work: Switchboard, 555-1000?"

381 To dial the number, confirm the selection by saying "Yes." The MPC PRO-10 responds
382 by saying "Dialing. Press the button to end the call."

383 If there are no phone numbers in the currently selected record, the MPC PRO-10 will say
384 "No available numbers."

385 Phone numbers can also be dialed directly by saying the desired phone number (see the
386 Phone Functions section).

387 **Note:** You cannot access your cell phone's Address Book or speed dial numbers through
388 the MPC PRO-10. When connected to MPC PRO-10, the phone must be dialed using
389 your Palm Address Book or a spoken number.

390 **Ending the call**

391 You can end a call at any time by pressing the Communiport button.

392 **Using the To Do List**

393 (Insert drawing 5 – voice commands for To Do List)

394 The To Do list application allows you to recall lists of activities using voice commands.
395 To access the To Do List using voice commands, say, "To Do List."

396 **Categories**

397 To help organize records, your Palm provides the ability to group To Do List items into
398 as many as 15 categories, plus the All and Unfiled categories.

399 After switching to the To Do List, the MPC PRO-10 starts in the All category and
400 responds by saying "To Do List," followed by the number of tasks in the All category. It
401 then reads the first item in the list.

402 For example:

403 "To Do List, All category. You have 23 entries. Item one. Send memo to team
404 members regarding project schedule. Due seven twenty seven. There is a note
405 attached attached. Incomplete."

406 To change categories, say the command "Category." The MPC PRO-10 responds by
407 saying "New category please." Say the name of the desired category. The MPC PRO-10
408 will confirm the change with the name of the category. For example:

409 "To Do List, Clients category. You have 3 entries. Item one. Call John Doe.
410 Incomplete."

411 Navigating To Do List items

412 The following voice commands are available to navigate through items in the To Do List:

413 **Go to** – Responds with "Number please." Say the number of a To Do List item in
414 the currently selected category. The MPC PRO-10 goes to the numbered To Do
415 List item and reads the information about that item. For example:

416 "Item fourteen. Distribute meeting minutes. Due eight twenty six. There is
417 a note attached. Incomplete."

418 If you request a To Do List item number that is greater than the number of
419 available entries, the MPC PRO-10 will respond with "You have ...(number) ...
420 entries" and then prompt for a correct appointment number with "Number please."

421 For example, if you have 10 appointment entries and request number 14, the MPC
422 PRO-10 will respond with:

423 "You have 10 entries. Number please."

424 **Go to last** – Goes to the last item in the current category and reports the
425 information about that record, including the presence of any attached notes.

426 **Go to first** - Goes to the first item in the current category and reports the
427 information about that record, including the presence of any attached notes.

428 **Next** - Goes to the next To Do List item in the current category and reports the
429 contents.

430 When you reach the end of the list of data and attempt to move beyond it with the
431 "Next" command, the MPC PRO-10 will respond with "No additional entries."

432 **Previous** - Goes to the preceding To Do List item in the current category and
433 reports the contents. If you are at the top of a list and give the "Previous"
434 command, the MPC PRO-10 will respond with "No previous entries."

435 **How many entries** – Says the name of the current category and the number of
436 entries in that category. For example:

437 "Business Category. You have twenty three entries."

438 **Read Note** – Reads the contents of the note associated with the current To Do
439 List item. If there is no note attached, the MPC PRO-10 responds with "No note
440 attached." If there is a note but it has no information in it, the MPC PRO-10
441 responds with "Note has no content."

442 Using Memo Pad

443 (insert drawing 8 – voice commands for memo pad)

444 The Memo Pad allows you to recall information you have entered using voice commands.
445 To access the Memo, say "Memo Pad."

446 Categories

447 To help organize records, your Palm provides the ability to group Memo Pad items into
448 as many as 15 categories, plus the All and Unfiled categories.

449 After switching to the Memo Pad, the MPC PRO-10 starts in the All category and
450 responds by saying "All category. You have ... (number) ... entries." The MPC PRO-10
451 then reads the contents of the first Memo Pad item. For example:

452 "Client Meeting category. You have five entries. Item one. Project planning
453 meeting."

454 To change categories, say "Category." The MPC PRO-10 responds with "New category
455 please." Say the name of the desired category. The MPC PRO-10 will confirm the
456 directory change by saying the name of current directory and prompt by saying "Ready."

457 If the MPC PRO-10 was unable to find the category, it responds with:

458 "Sorry, category not found."

459 To determine the current category, say the command "Current category" and the MPC
460 PRO-10 will respond with:

461 "You are currently in the ... (name of category) ... category."

462 Navigating Memo Pad items

463 The following voice commands are available to navigate through Memo Pad items:

464 **Go to** – Responds with "Number please." Say the number of a Memo Pad item in
465 the currently selected category. The MPC PRO-10 goes to the numbered Memo
466 Pad item and reads the information about that item.

467 If you request a Memo Pad item number that is greater than the number of
468 available entries, the MPC PRO-10 will respond with "You have ...(number) ...
469 entries" and then prompts for a correct appointment number with "Number
470 please."

471 **Go to last** – Goes to the last Memo Pad item in the current category and reads the
472 contents of the item.

- 473 **Go to first** - Goes to the first item in the current category and reads the contents.
- 474 **Next** - Goes to the next Memo Pad item the current category and reads the
- 475 contents.
- 476 When you reach the end of the list of data and attempt to move beyond it with the
- 477 "Next" command, the MPC PRO-10 will respond with "No additional entries."
- 478 **Previous** - Goes to the preceding item in the current category and reads the
- 479 contents. If you are at the top of a list and give the "Previous" command, the MPC
- 480 PRO-10 will respond with "No previous entries."
- 481 **How many entries?** – Says the name of the current category and the number of
- 482 entries in that category.
- 483 **Read** – Reads the contents of the currently selected Memo Pad item. To stop the
- 484 report at any time, press the Communiport button.

485 **Using Mail**

- 486 (Insert drawing 3 – voice commands for mail)
- 487 The Mail application allows you to retrieve and listen to stored e-mail messages.
- 488 To access Mail using voice commands, say "Mail," or "E-mail." After entering the Mail
- 489 function, the MPC PRO-10 will automatically report the number of items in the Inbox
- 490 and read the information about the first item.
- 491 For example:
- 492 "Inbox. You have 5 messages. Message 1. From: Jane Smith, Subject Re: Surprise
- 493 Party."
- 494 The MPC PRO-10 will prompt you for the next command with "Ready."
- 495 If there are no messages in your inbox, the MPC PRO-10 will say:
- 496 "Inbox. You have no messages. Ready."

497 **Selecting Mailboxes and items**

- 498 The following voice commands are available to select Mailboxes and items:
- 499 **Mailbox** – Responds with "Mailbox please." Say the name of the desired
- 500 Mailbox. The Mailboxes available are Inbox, Outbox, Deleted, Filed, and Draft. If
- 501 the MPC PRO-10 does not recognize the name of the Mailbox, it responds with
- 502 "Command not recognized. Mailbox please."
- 503 **Current mailbox** – Responds with "You are currently in the ..." and the name of
- 504 the currently selected mailbox.
- 505 **How many messages** – Responds with the number of messages in the currently
- 506 selected mailbox.
- 507 **Read** – Reads the currently selected message.

Navigating Mailboxes and items

Go to last – Goes to the last item in the selected Mailbox and reads the header information.

Go to first – Goes to the first item in the selected Mailbox and reads the header information.

Go to – Responds with “Number please.” Say the number of the mail item and the MPC PRO-10 goes to that item and reads the header information.

If you request a mail item number that is greater than the number of available entries, the MPC PRO-10 will respond by saying "You have ...(number) ... entries" and prompt you for a correct item number by saying "Number please."

Next - Goes to the next item in the current Mailbox and reads the header information. When you reach the end of the list of data and attempt to move beyond it with the “Next” command, the MPC PRO-10 will respond with “No additional entries.”

Previous - Goes to the preceding item in the current category and reads the contents. If you are at the top of a list and give the "Previous" command, the MPC PRO-10 will respond with “No previous entries.”

Note: Unlike the To Do List and Memo Pad, you can not organize your e-mail into different categories.

Note: The MPC PRO-10 recognizes only the Palm-supplied e-mail interface.

Using the Phone Functions

(insert drawing 9 – voice commands for phone)

The MPC PRO-10 phone function allows you to dial your cellular phone by dictating phone numbers. It also provides hands-free speakerphone capabilities.

The MPC PRO-10 can provide Phone Functions even without having your Palm connected; however, calls must be dialed by saying the phone number rather than selecting a phone number from a Palm record.

To access your phone using a voice command, say “Phone,” “Dial,” or “Call.” After switching to the Phone Function, the MPC PRO-10 will say "Number please.”

Placing outgoing calls

To dial the phone, say the number you want to dial.

Note: There is no need to include a “1” when saying a long distance phone number. The MPC PRO-10 automatically adds a "1" to all phone numbers that are 10 digits long.

The MPC PRO-10 will respond with "Did you say ..." plus the spoken number. Say the command “Yes” to accept and dial the number. When the call connects, you can begin speaking.

NAME * MERGEFORMAT |1122ErError! Bookmark not defined.

545 Say the command “No” if the number was incorrectly recognized. The MPC PRO-10 will
546 prompt with “Number please.” Say the desired phone number again.

547 If the MPC PRO-10 does not recognize the spoken number, it will respond with
548 “Command not recognized. Number please.” Say the phone number again.

549 When connected to your Palm, you can also place calls from numbers listed in your
550 Address Book (see the Address Book Functions section).

551 **Note:** Many organizations use words to make their phone numbers easier to remember
552 such as:

553 800-GO-FLYING

554 345-BANK-NOW

555 888-REALTOR

556 The MPC PRO-10 does not recognize letters when dialing. You must convert any letters
557 to numbers before dialing with voice commands.

558 **Answering incoming calls**

559 To answer an incoming call, press the Communiport button. The MPC PRO-10 will
560 interrupt any current functions and answer the call.

561 **Ending calls**

562 To end a phone call, press the Communiport button.