
70X70mm





TWS-J11 使用指南



		2 /		7170727		
当前状态	单击	双击	三击	四击	五击	长按
配对						
连接待机						2S喚醒语音助手
音乐模式	暂停/播放	上一曲 下一曲	加音量 减音量			
通话模式	接听/挂断					25担听
游戏模式				游戏模式 or音乐模式		

多功能按键功能定义

技术规格

- 烈号: TWS-J11
- 最大使用功率: 5mW
- 耳机锁率响应: 15Hz-20kHz ● 英牙斯本: V5.3
- 支持协议: A2DP/AVRCP/HFP/AVDTP
- 蓝牙有效距离:≥10米
- 耳机工作时间:(約3小时)(建议连续使用耳机不認过2小时) ● 耳机待机时间: 大于200小时
- 充电盒充电时间:约1.5小时 ● 充电盒给耳机充电次数:约2次
- 耳和充由計画: 約15/kgt
- 喇叭单元: 百机①:13mm (32R) 百机②:10mm (16R)
- 耳机电池容量:25mAh ● 充电盒电池容量:150mAh

耳机低电提示报警电量低(预计可再使用10分钟左右),请充电。 放入充电盘充电。





使用注意事项

- 日常使用中耳机充电面会沾上灰尘等脏污的东西可以使用棉签清理耳 机充由由接触而。
- 耳机需按要求正确规范的使用,注意使用环境对耳机的影响,为保证连接顺畅,建议手机和耳机之间的距离在8米范围内。
- 如耳机有连接不上或通讯不畅等其它问题,请忽私自拆卸耳机本体及 ■ 其配件,否则不予保修不要使用超过额定安数伏数的充电头给耳机充
- 为了保证你正常使用耳机,请确保耳机的电量充足。

温馨提示

- 如果你的耳机充电中存在发烫严重或烧坏的情况可以看是不是使用大于5V2A功率的 充电头,大于的话需要更换小于5V2A的充电头。
- 当左右耳机出现只有一边有声音的时候请把两只耳机重新放入充电盒耳机自动关机。 打开手机找到配对名,点击取消蓝牙配对,打开充电盒取出耳机,靠近解锁的手机 等待 8秒左右打开手机蓝牙搜索蓝牙配对名点击连接。
- 耳机听不到声音 (1)确认耳机处于工作状态
 - (2)确认耳机的音量大小是否合适
 - (3)确认耳机是否与手机正常连接
 - (4)确认耳机在正常的工作范围
- 如果听到耳机有断续的情况:有些地方信号干扰大,蓝牙耳机会出现干扰蓝牙底噪的 情况会出现断续情况走到别的地方断开重新连接即可解决。
- (1)耳机离手机距离超出8米以上或中间有障碍物时,会影响信号传输 (2)周边有大功率发射设备时,会影响信号传输 (3)紧密空间也会影响信号传输(电子城等)

有毒有害物名称及含量标识

● 有毒有害物质或元素的名称及含量标识表

※ 符合电子信息产品污染控制管理办法的有害物质或元素标识表

			有害物质或元素					
部件名称	目标部件	铅 (Pb)	汞 (Hg)	報 (Cd)	六价铬 (Cr(VI))		多溴二苯醚 [PBDE]	
电路板组合件	印刷电路板	0	0	0	0	0	0	
塑胶及五金件	喇叭前后壳,头戴钢条,音控壳及 对应的表面喷油部件等。	0	0	0	0	0	0	
喇叭	全音喇叭	0	0	0	0	0	0	
线材组件	线材及插针等	×	0	0	0	0	0	
附件	彩盒,泡绵,吸塑,卡通,说明书,布袋等。	0	0	0	0	0	0	

本表格依据SJ/T 11364的规定编制

- O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572规定的限量要求以下。
- X:表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572规定的限量要求。




在中华人民共和国境内销售的电子电气产品上将印有"环保使用期"(EPuP)符号。圆圈中的数字代表产品的

保修卡/合格证 请您妥善保管好保修证和购机凭证,这些将是您的保修凭证。 产品保修单(非人为损坏保修一年) 购机日期 产品编号 通讯地址 故障描述 日期 检修记录 修理人员 合格证





TWS-J11 **Usage Guide**



Current status	Click	Double-click	Three hits	Four hits	Five hits	Long press
Pairing						
Connected standby						2S/Wake up voice assistant
Music mode	Pause/Play	Previous song Next song	Turn it up Reduce the volume			
Call mode	Incoming call: Answer					Long press for 2S to reject listening
Game mode				Game mode or music mode		

- Model: TWS-J11 Maximum power used: 5mW
- Headphone frequency response: 15 Hz-20kHz
- Bluetooth version: V5.3 Supported protocols: A2DP/AVRCP/HFP/AVDTP
- Bluetooth effective distance: ≥10 meters
- Headset working time: (about 3 hours) (It is recommended to use headphones continuously for no more than 2 hours)
- Headset standby time: more than 200 hours Charging time of charging case: about 1.5 hours
- The number of times the charging case charges the earphones: about 2 times
- Earphone charging time: about 1.5 hours
- Horn unit: Headphone: 13mm (32R) Headphone: 10mm (16R)
- Headphone battery capacity: 25mAh
- Charging case battery capacity: 150mAh

The earphone low battery prompts the alarm battery is low (it is expected to be used for about 10 minutes), please charge. Place in the charging case to charge.





Precautions for use

- In daily use, cotton swabs can be used for dirty things such as dust on the charging surface of the earphones Clean the headphone charging contacts.
- The headset should be used correctly and standardly, and pay attention to the influence of the use environment on the headset. To ensure a smooth connection, it is recommended that the distance between the phone and the headset be within 8 meters.
- If the headset has other problems such as poor connection or poor communication, please disassemble the headset body and. Its accessories, otherwise there is no warranty, do not use the charging head exceeding the rated ampere volt to charge the earphone.
- In order to ensure that you can use the headphones properly, make sure that the headphones are fully charged.

- If your earphones are seriously hot or burned out in the charging of your headphones, you can see if you are using them if the charging head is greater than SVZA power, if it is larger, it is necessary to replace the chargin head less than SVZA.
- When there is only sound on one side of the left and right earbuds, please put the two earphones back into the charging case. The headset automatically turns off, open the phone to find the pairing name, click to cancel Blacetooth pairing, open the charging case. Take out the headset, wait dots on the unlocked mobile phone for about 5 seconds, turn on the Bluetooth of the mobile phone to search for Bluetooth pairing First name click Connect.
- (1) Confirm that the headset is in working condition
- (2) Check whether the volume of the headphones is appropriate (3) Confirm whether the headset is properly connected to the mobile phone
- (4) Confirm that the headset is within the normal working range
- If you hear that the headphones are intermittent: there is a lot of signal interference in some places, and the Bluetooth headset will appear in the case of interference with the Bluetooth noise floor, there will be intermittent situations, just go somewhere else and disconnect and reconnect Settle. (1) When the distance between the headset and the mobile phone exceeds 8 meters or there is an obstacle in the middle, the signal transmission will be affected
- (2) When there is high-power transmitting equipment around, it will affect the signal transmission (3) Tight space also affects signal transmission (electronic city, etc.)

Name and content label of toxic and harmful substances

Name and content identification table of toxic and harmful substances or elements

		Hazardous substances or elements						
Target part	lead (Pb)	mer cury (Hg)	ium (Cd)	lent chro mium	Polybro minated biphenyls (PBB)	Polybrominat ed diphenyl ethers (PBDE)		
Printed circuit boards	0	0	0	0	0	0		
Speaker front and rear shells, head wearing steel bars, sound control shell andCorres ponding surface oil-injected parts, etc.	0	0	0	0	0	0		
Pitch trumpet	0	0	0	0	0	0		
Wires and pins, etc	×	0	0	0	0	0		
Color baxes, foam, blisters, cartoons, manuals, cloth bags, etc.	0	0	0	0	0	0		
	Printed circuit boards Speake fruit and rear shelts, head wearing steel bars, sound control shell and Corres ponding surface of injected parts, etc. Pitch trumpet Wires and pins, etc. Color boxes, foam, blisters, cartoons,	Printed circuit boards Printed circuit boards Speaker front and rear shells, head wearing a seed bars, sound control shell and Corresponding surface oil righted parts, etc. Pitch trumpet Wires and pins, etc. Loio boass, fours, biliters, cartoons,	Target part read re	Target part Ited min Sold min	Target part	Target part tead to the property of the part of the pa		

This form has been prepared in accordance with SJ/T 11364

- O: Indicates that the content of the hazardous substance in all homogeneous materials of the part is presentThe limit requirements specified in GB/T 26572 are as follows.
- X: Indicates that the hazardous substance is present in at least one of the homogeneous materials of the part The limit requirements specified in GB/T 26572.



Electrical and electronic products sold in the People's Republic for China. Admiral's print There is a "Environmental Use Period"

(EPuP) symbol. The numbers in the circle represent the product
Normal environmental protection service life.

Please keep the warranty certificate and purchase voucher properly, these will be your warranty certificates. Product warranty (one year warranty for non-human damage)

User name		Contact number	
Product number		Date of purchase	
Mailing address			
Fault description			
Maintenance	records		

serial number	date	Maintenance records	Repair staff
1			
2			



