








HW82说明书

尺寸: 55*96

材质: 80g哑粉

四色印刷

骑马钉

<div><div>Instruction manual</div><div>SMART WATCH</div><div></div><div><p>* Please read this manual before using this product</p></div></div> <div>1</div>	<div><div><div></div><div>1</div><div>Open the package and take out the watch</div></div><div><div></div><div>2</div><div>Long press the Circular key to turn the smart watch on</div></div></div> <div>2</div>	<div><div>Watch client download and connect</div><div></div><div>Scan the QR code above to download the client</div><div><div>1.Download "Da Fit" APP It can be downloaded and installed on the mobile phone by scanning the QR code on the manual,scanning the built-in QR code of the watch, or directly searching "DaFit" in the stores. 2.Connect the watch 1) Scan code connection: After Bluetooth is enabled on the mobile phone, enter the APP (Note:If the APP can not be opened, please open the positioning and then open the APP) and click Device->Add Device->click Scan code binding(scan the QR code on the watch). 2) Manual connection: After Bluetooth is enabled on the mobile phone, enter the APP(Note:If the APP cannot be opened,Click Device->Add Device->Click Search Device (find the device with the corresponding Bluetooth name and MAC address in "Settings">"About">"Vision" in the sliding control center of the watch)-> click Connect. 3) Connect Wireless call: The Wireless call is off by default in the initial state of the watch. 1.Android System: After the watch is connected to the APP, the phone will prompt a request for Bluetooth pairing from the watch - click on Pair - once the Wireless call is connected, you can make and receive calls. 2.iOS System: After the watch is connected to the APP, it will prompt for pairing twice. Click Allow for both to allow pairing, and then you can make and receive calls. Note: The media audio is off by default in the initial state of the watch. To turn on the media audio, swipe down from the main interface of the watch face to click on the settings - click on Call - click on Media Audio. After turning it on, the watch can play music from the phone.</div></div><div>3</div></div>	<div><div>Charging and Activation</div><div><p>Align the magnetic charging dock with the magnetic charging port on the back of the watch until the watch screen displays a charging prompt. When the watch indicates low battery, please charge it in a timely manner. This device is an all-in-one unit, and the back cover and battery are not removable.</p></div><div>Attention: The charging cable is magnetic, please keep it away from high temperatures.</div><div><div>Watch Operation Instructions</div><div>1. Watch Face Interface Press and hold the screen to enter the watch face selection page. You can switch watch faces by swiping left or right. After confirming the watch face, tap once to select. (Note: The system comes with 6 preset watch face pages, the last one being "Custom". This watch face will change according to the downloads and settings from the watch face market and custom watch faces on the APP.) 2. Menu Page Press the circular button on the watch face page to enter the menu page. Once in the menu page, press the circular button twice to switch the menu style. Press once to return to the main watch face page. 3.Function page On the menu page, tap the app icon to enter the corresponding function. Swipe right to go back, and press the circular button once to return to the main watch face page.</div></div><div>4</div></div>	<div><div>Buttons and touch controls</div><div><div></div><div><div>Circular key</div><div>1.Press the circular key long by shutting down the state to turn on the watch. 2.Click the circular key to return to the main table disk interface in the menu interface,double-click the circular key to switch different menu style</div></div></div><div></div></div> <div>5</div>	<div><div>Q&A</div><div><div>1.The watch cannot start Please hold down the power button for more than 6 seconds or the battery may be low. Please charge it in time. 2. Bluetooth is not connected or cannot be connected 1) Please try to restart the watch and re-link. 2) Please try to restart Bluetooth and connect again. 3) Don't connect your phone to other Bluetooth devices at the same time. 3. Sleep data is not accurate enough 1)Sleep monitoring simulates the time you actually fall asleep and wake up, and it requires the watch to be worn correctly. 2) If you go to sleep too late or only start wearing the watch when you go to sleep, there might be discrepancies. 3) Sleep data is not monitored during the day, with the default sleep monitoring period set from 10:00 PM to 8:00 AM the next day.</div><div>For more frequently asked questions, please check the APP [My > FAQ].</div></div><div>6</div></div>	<div><div>Note:</div><div>1) Do not charge in a humid environment with water 2) please regularly use a clean flannelette to clean the magnetic suction charging hole on the back of the watch, to ensure that the magnetic suction charging hole and magnetic charger fit, to ensure normal charging 3) This product is not equipped with a power adapter, in order to ensure the safety of family and property, when charging, you can use the computer USB interface or choose a power adapter whose output is not more than 6V 1A. Please buy the power adapter through the regular channel, and avoid using the bottom quality and fake power adapter to avoid bursting or fire.</div><div>Matters needing attention</div><div>1. The measurement results of this product are only for industrial examination and are not used as any medical use or basis. Please follow the doctor's guidance and do not use the measurement results for self-diagnosis and treatment. 2, this product waterproof grade is IP68, can not be used for deep diving and long time in the water. In addition, this product does not put hot water, because the steam will affect the watch. 3. The Company reserves the right to modify the contents of this manual without prior notice. Some functions are different in the corresponding software version. This is normal.</div><div>7</div></div>	<div><div>FCC Warning</div><div>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</div><div>Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</div><div>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: ► -Reorient or relocate the receiving antenna. ► -Increase the separation between the equipment and receiver. ► -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. ► -Consult the dealer or an experienced radio/TV technician for help.</div><div>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</div><div>8</div></div>
--	---	---	--	--	--	---	--