


Size: 414x57mm



QUICK START GUIDE


TRUE WIRELESS STEREO EARBUDS

USING THE PORTABLE CHARGING CASE

It is recommended to keep the earbuds in the portable charge case when not in use. While on-the-go, the case doubles as a charging solution for the earbuds. Simply put the earbuds into the charging case. The earbuds will automatically begin to charge. A full charge of the earbuds takes 1 hour.

Connect the Micro USB cable to the charging port on case. A full charge of the case battery takes up 2 hours. When the case is charging, the LED light flashes blue light and show the battery power status. When full charged, it will show SOLID blue light "100%".





QUICK START GUIDE

TRUE WIRELESS STEREO EARBUDS

1




Your True Wireless earbuds come pre-paired. When you remove the earbuds from the charging case, the earbuds will automatically turn on.

If they lose connection, please follow the below steps to reconnect.

1. Turn off, both earbuds and turn it back on. If not, place both earbuds back into case and remove from charging case.


2. While earbuds are not in the case, press and hold both earbuds for 10 seconds.



QUICK START GUIDE


TRUE WIRELESS STEREO EARBUDS

2



The two earbuds will pair to each other automatically.


- Turn ON: Press and hold the button for 3 seconds.
- Turn OFF: Press and hold the button for 5 seconds.



QUICK START GUIDE

TRUE WIRELESS STEREO EARBUDS

3




4



Turn on Bluetooth on your phone or tablet. Choose "FB-SMTW". Enter "0000" if asked. You're paired!


To turn OFF press and hold the multifunction button for 5 seconds on either earbud.



QUICK START GUIDE

TRUE WIRELESS STEREO EARBUDS

2



3



Select "FB-SMTW" from the Bluetooth menu of your first device. Enter PIN code "0000" if asked. This earbud is ready to use.


To pair the other earbud, make sure your other wireless device is nearby. Same pairing operation as the first earbud. Choose "FB-SMTW". Enter "0000" if asked.




QUICK START GUIDE

TRUE WIRELESS STEREO EARBUDS

BUTTON CONTROLS (using as pair)




- Turn ON: Press and hold the button for 3 seconds.
- Turn OFF: Press and hold the button for 5 seconds.
- Play/Pause: While music is playing press the button on the Right or Left Earbud once.
- Volume +/- : Quickly press the earbud button 3 times.
- Switch Music: Quickly press the earbud button twice.
- Answer/End Call: Press the button on the Right or Left earbud once.
- Reject Call: Press and hold the button on the Right or Left earbud.
- Voice Assistant: Press and hold the button for 3 seconds on the Right or Left earbud.



QUICK START GUIDE

TRUE WIRELESS STEREO EARBUDS

SPECIFICATIONS



Chip set: JL6963A

Bluetooth version: 5.1

Support: A2DP, AVRCP, HSP, HFP

Earphone battery capacity: 40mAh

Charging case battery capacity: 300mAh

Speaker impedance: 32Ω±15%

Effective distance: 30ft (10 m)

Play time: Up to 3 hours

Earbuds charge time: 1-2 hrs

Charging case charge time: Up to 2 hr




QUICK START GUIDE

TRUE WIRELESS STEREO EARBUDS

CONNECTION LOST?

- If only one earbud works, turn off the earbud and reconnect the earbuds as a pair.
- If the paired two earbuds don't work, turn off the earbud and reconnect earbuds as a pair.
- Make sure your earbuds are within range of your smart device.
- If you hear a long beep, you need to recharge your earbuds. Connection may be lost due to low battery.



QUICK START GUIDE


TRUE WIRELESS STEREO EARBUDS

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL




QUICK START GUIDE

TRUE WIRELESS STEREO EARBUDS

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by




QUICK START GUIDE

TRUE WIRELESS STEREO EARBUDS

turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AANZSMTW BT ID: D051448



QUICK START GUIDE

TRUE WIRELESS STEREO EARBUDS

FCC RADIATION EXPOSURE STATEMENT:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

WARRANTY


This product is covered by a 3 month limited manufacturer's warranty. Contact us if you have any problems at support@dglusa.com.

WARNING

Keep away from water and moisture.

Keep away from heat sources.

Do not disassemble.



PDF
Adobe