

Phone layout—keys and parts



- | | |
|-----------------|----------------------|
| 1 Receiver | 8 Right soft-key |
| 2 Screen | 9 Music function key |
| 3 Left soft-key | 10 End key |
| 4 SIM2 call key | 11 Pound key |
| 5 SIM1 call key | 12 Camera |
| 6 Number key | 13 Speaker |
| 7 Star key | |

Making phone calls

When you want a call, press the phone keypad to input the area code and phone number.

Press Middle key to save.

Press "+", and then you can dial an international number. (The '+' stands for international dial code.)

Press Dial key to dial the number. If the number is stored with a name, it appears on the display when you dial the number.

You can also make a call through call logs, phonebook and messages.

Managing contacts

Your contact list

To view the contacts on your phone, select Phonebook in the menu. Press corresponding alphanumeric keys to search for a number by name. Enter the first letter of the name that you want to find. Select contact's name, press left soft key to open the option menu.

Add a contact

Press navigation key to move the cursor to Add new contact, first, confirm the storage media in: To SIM1, To SIM2, To phone.

If preferred storage is phone, then input Name, Number, Caller picture, Caller ringtone.

※**Note:** If add new entry to SIM card, there only need input name and number.※

SMS and MMS messaging

Inbox

Through the menu you can read received SMS and MMS messages of SIM1 and SIM2. There is "1" or "2" icon displayed on the right side of every messages, it means this message is received by SIM1 or SIM2. To the message list, select one and open it, press Left soft key to view, replay, forward, delete and other options.

Write messages

Select Write message, the Compose screen opens.

Write the content, press Left soft key to insert number, name, subject and other attach.

Press Left soft key to select Send to and select the number, press Left soft key to select Send to send the message.

Call center

Call history

In this menu, you can view all the calls, or the call you missed, dialed and received.

There is "1" or "2" icon displayed on the left side of every call logs, it means this call is dialed or received by SIM1 or SIM2. Select the call log, press SIM1 or SIM2 to dial the number with SIM1 or SIM2.

Call settings

Set SIM1 call settings, SIM2 call settings and Advance settings.

Multimedia

Camcorder

Enter the menu, the display shows the preview image.

Shortcut key operation:

Press Middle key to take a photo or start to record.

Press up and down navigation key to switch between camera and recorder

Image viewer

Show image list, press left soft key to do: View, Image information, Browse style, Send, Use as, Rename, Delete, Sort by, Delete all files, Storage.

Media player

Through the menu, you can play music or ring tone file.

During playing the music, press Left or Right navigation key to next music file; long press Left or Right navigation key to fast forward or Rewind; press Down navigation key to pause/play the playing; press * and # key to adjust volume.

Sound player

Through the menu, you can record sound. The sound recorded can be set as ring tone for call or message.

Press left soft key to access:

New record: begin a new recording;

List: show all the recording files;

Settings: set the storage media, saving format.

FM radio

Before starting FM radio, insert the earphone into left side of the phone. The earphone line equates in FM radio antenna. Please let it hang freely. Open the FM radio, the phone will show the channel frequency that the phone searched automatically. You can press left/right navigation keys to change the channel frequency. Press * and # key to adjust volume. And press right soft key to exit, and the press left soft key to operate.

File manager

To save more information, the phone support memory card. The card can be installed at any time. The menu can manage the files on the phone.

Organizer

Calendar

Through the calendar, you can view the date and task list at specific day. Press left soft key to access.

Tasks

Through the menu, you can view the task list, and set ring tone prompt mode. The feature can reminder you important events. Press left soft key to view, add, edit, delete, delete overdue, delete all.

Alarm

Through the menu, the phone sends out the noisy bell sound at specific time. If the specific time arrives, the phone will ring even if the phone is powered off. Press left soft key to on/off, edit alarm, repeat, alarm tone, snooze, alert type.

Calculator

Through the calculator, you can operate: Addition, Subtraction, Multiplication and Division.

Unit Converter

Through the menu, you can operate unit conversion with different weight and length unit

Currency Converter

Through the menu, you can operate currency conversion with local and foreign currency. Enter the currency rate, then confirm. Press left or right navigation key to select proportion, and then convert the currency.

Stopwatch

The menu provides stopwatch timer function

Ebook reader

E-Book Reader supports read e-book files on your phone. You also can set the reader parameter for convenience. Now the phone only supports TXT and PDB format files

World Clock

The menu allows inquiry time of world each place. When you are outside the country, you can change the system time into the locating place time.

Press left/right navigation key to view the country date and time at different longitude. The country name displays on the upper screen, and the date and time displays below. A world map displays in the middle. Select the country, press left soft key to access "Daylight saving time for foreign city". Set the feature is On or Off

Notes

Add notes by texts or symbols, never miss any important information

Led Flashlight

On or off the flashlight function. The flashlight is in the front of the mobile.

Services

STK

STK features are provided by your service provider. If your SIM card supports STK feature, you will see the STK menu. Different STK has different STK main

menu. Please contact your service provider if the STK does not work.

Internet services

Wireless Application Protocol, a kind of browse Internet webpage mode. You can browse the internet , and grasp any information through your mobile. You need to apply the service to your network service provider before using the service.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: B8301(FCC ID: 2ABXQ-B8301) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.749W/kg and when properly worn on the body is 0.633W/kg. This device was tested for typical body-worn operations with the back of the handset kept 1.5cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.