

TABLE OF CONTENTS

NFORMATION TO THE USER 2
BEFORE YOU START 3
GETTING TO KNOW YOUR PSX364
BLUETOOTH OPERATION5
BLUETOOTH OPERATION6
TREAMING MUSIC7
<i>NUX INPUT</i> 8
SB INPUT 9
REMOTE CONTROL 10
NSTALLATION11
ROUBLESHOOTING12
VIRE DIAGRAM13
SPECIFICATIONS 13

SUPPORT

For the latest information about this product please visit www.planetaudio.com

TECH SUPPORT:805-751-4854 www.planetaudio.com/customer-support

Thank you for purchasing this

💕 Planet Ludio®

PSX36 All-Terrain Sound System Please read through these instructions carefully so you will know how to operate your model properly.

After you have finished reading the instructions, keep this document in a safe place for future reference.

THIS PACKAGE CONTAINS

1- PSX36 All-Terrain Speaker System ***** 6444 1- Mounting Kit 1- Power Accessory Extension Adaptor 1- Remote control 1- User Manual 1- Warranty Card INFORMATION TO THE USER 😵 Bluetooth° The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks is under license. Other trademarks and trade names are those of their respective owners.

WARNING

oved by the party responsible for mpliance could void the user's authority to operate the equipmen

device complies with part 15 of the FCC Rules. Operation is subject to the following

is device may not cause harmful interference, a this device must accept any interference received, including interference that may se undesired operation.

ent has been tested and found to comply with the limits for a Class B digital uant to part 15 of the FCC Rules.

re designed to provide reasonable protection against harmful interference

erates, uses and can radiate radio frequency energy and, if not installed n accordance with the instructions, may cause harmful interference to radio


ver, there is no guarantee that interference will not occur in a particular installation. etermined by turning the equipment off and on, the user is encouraged to try to correct terference by one or more of the following measures: prient or relocate the receiving antenna. ease the separation between the equipment and receiver.


Connect the equipment into an outlet on a circuit different from that to which the receiver

-Consult the dealer or an experienced radio/TV technician for help.

`			

💕 Planet Ludio





AUX-IN OPERATION 1)Power on the **PSX36** by plugging in the male cigarette lighter adaptor into **2** a female cigarette lighter receptacle.

2) Press the button (9). Select AUX mode:

3) Connect the integrated 3.5mm AUX-IN cable $oldsymbol{1}$ to your devices headphone jac 4) Route the wire back to **PSX36**, and secure your device

VOLUME CONTROL

1) To raise the volume press the (10) VOLUME UP button or use your devices controls 2) To lower the volume press the (7) **VOLUME DOWN** button or use your devices controls

For maximum audio performance, ensure your device headphone volume is set to a minimum 75% level before stowing

💕 Planet Audio

USB INPUT

USB IN OPERATION 1)Power on the **PSX36** by plugging in the male cigarette lighter adaptor into **(2)** a female cigarette lighter receptacle. 2) Insert the USB Flash drive on (5) and play the music automatically. 3) Press the (**8**) *PLAY/PAUSE* once to start playing music or pause 4) To skip songs or advance, press the (11) NEXT TRACK button

5) To select the previous song, press the $({f 6})$ PREVIOUS TRACK button 6) To raise the volume press the 10 VOLUME UP button or use your devices controls

7) To lower the volume press the (7) VOLUME DOWN button or use your devices controls

USB can play music formats MP3 and WMA. USB can provide 1A current. 💕 Planet Ludio°

