MNOBLE



充电盒 x1





USB充电线 x1


**€ R** xxx-xxxxxx

www.nobleaudio.com




105mm 封面


使用说明书







耳机











ELC VA		
1. 打开充电盒盖子。耳机将自动 开机并进入配对模式,蓝白指示 灯闪烁。		
2. 在智能手机上启用蓝牙并在可用的蓝牙设备中搜索 "Noble FoKus Amadeus"。找到后,选择 "Noble FoKus Amadeus"开始 配对。你会听到"Connected",耳 机就可以使用了。		
配对新设备		
1. 打开充电盒的盖子。耳机将自动开机并连接到您当前的设备。 2. 通过从智能手机的蓝牙设备列表中"断开连接"或删除"Noble FoKus Amadeus"来取 消耳机与上次连接的智能手机的配对。 3. 断开连接后,耳机将自动进入配对模式,蓝白指示灯交替闪烁。		

4. 在新设备上启用蓝牙,并在可用的蓝牙设备中搜索"Noble FoKus Amadeus"。找到后,


选择"Noble FoKus Amadeus"开始配对。你会听到"Connected",耳机就可以使用了。

控制			
MI	播放/暂停	单击 MFS (L/R)	
<b>4</b> +	提高音量+	三击 MFS (L)	
<b></b> -	音量减小-	双击 MFS (L)	
M	上一曲	双击 MFS (R)	
M	下一曲	三击 MFS (R)	
<b>%</b> /~	接听/挂断电话	单击 MFS (L/R)	
٠×	拒接来电	长按 MFS 2秒 (L/R)	
•	语音助手功能 - Siri / Google	长按 MFS 3秒 (R)	
୬Î∕ ∕୬ ···	通透模式 / ANC模式	长按 MFS 3 秒 (L)	

LED指示灯		
使用场景	LED指示灯状态	
开机	白色 LED 灯闪烁一秒钟	
关机	蓝色 LED 灯闪烁一秒钟	
配对	蓝白 LED 灯闪烁	
配对成功	白灯亮2秒,熄灭	
播放音乐或通话	LED 灯关闭	
耳机低电量	蓝色 LED 灯每 8 秒闪烁两次	
将耳机放入充电盒中	蓝色 LED 灯常亮	
耳机放入充电盒满电后	LED 灯关闭	
充电盒充电中	- \(\doc{1}{2} \cdot \cdot \cdot \cdot \cdot \cdot 25\cdot \cdot \	
充电盒满电后	所有灯常亮	
<ul><li>单声道模式:蓝牙成功连接后,只要把任意一只耳机放回充电盒并合耳机将独立工作。</li><li>开机并连接后,如果任一只耳机电量耗尽并关机,另一只耳机可继续</li></ul>		

・超距离回连: 当耳机超出手机连接范围时, 3分钟内回到有效距离会自动回连手机;

若超时3分钟未回连接,耳机将自动关机。



*如果耳机无法相互配对或者无法与其他的 1.将耳机放回充电仓内 2.按下复位按键5秒,直到两个耳机上的蓝色的设备都将被清除。	设备配对,请重置耳机。 色 LED 灯快速闪烁,重置完成,所有先前配对
如果不小心只重置了一只耳机,则需要重置	置两只耳机才能再次作为一对耳机使用。
	L R • • 5°

品规格	
产品型号	FoKus Amadeus
蓝牙版本	V 5.4
支持协议	A2DP、AVRCP、HFP、HSP
音频传输	SBC、AAC、aptX Adaptive、LDAC
驱动单元	$8.3$ mm , $37\Omega \pm 3.7 (10\%)$
频率响应	20HZ~20KHZ
连接距离	≥10m
耳机电池容量(单个)	65mAh
充电保护盒电池容量	500mAh
播放时间(因音量和内容而异)	8H (降噪开),12H (降噪关)
充电时间	耳机:1.5小时;充电盒:2小时
充电接口类型	Type C
电源输入	5V == 1A

声明和警告在配对新设备之前请断开当前设备。
<u>↑</u> 警告!
长期暴露在高噪音环境中可能会导致永久性听力损伤。
请勿在禁止使用电子设备的场所使用 Noble FoKus Amadeus 耳机。
如果您有心脏起搏器或其他电子医疗设备,请在使用您 Noble FoKus Amadeus 耳机前
咨询您的医生。
此包装包含小零件,可能对小孩造成危险。
请勿擅自拆卸 Noble FoKus Amadeus,因为它包含锂电池,拆卸可能会导致触电、火灾
或人身伤害的危险。
避免在过高或过低温环境中使用。
任何未经授权的人员拆卸更换或试图维修 Noble FoKus Amadeus,都会导致 Noble
FoKus Amadeus 的保修失效。
本产品不适用于在水中或过于潮湿的环境中使用,请勿放入或浸没在水或其它液体中。
否则将导致任何保修失效,并可能对产品造成永久性损坏。
如果产品出现膨胀或开裂,请立即处理掉,因为这可能是电池老化的迹象,可能导致电

池破裂并引发火灾。

FCC 信息 FCC ID: 2AT8X-FOKUSAMADEUS 本设备符合FCC规则第15部分的规定。操作须符合以下两个条件: 1. 本设备不得产生有害干扰。 2. 本设备必须接受任何收到的干扰,包括可能导致意外操作的干扰。 警告:未经制造商授权的修改可能会导致用户丧失操作本设备的权力。 注意:本设备经过测试,符合FCC规则第15部分对B类数字设备的限 制性要求。这些限制旨在提供合理的保护,以防止住宅环境中的有害 干扰。本设备会产生、使用、并发射无线电波,如果未按照说明进行安 装和使用,可能对无线电通信造成有害干扰。然而,我们不能保证在 特定安装条件下不会发生干扰。 如果本设备确实对无线电或电视接收造成有害干扰(可通过关闭和打 开设备来确定),我们建议用户尝试以下方法来解除干扰: • 调整接收天线的方向或位置。 •增加设备和接收器之间的距离。 • 将设备连接到与接收器不同的电路插座上。 ・咨询经销商或有经验的无线电/电视技术人员,寻求帮助。

制造商: Noble Hifi. LLC **( R** 222-253864

105mm

## MNOBLE

封底

It Sounds Even Better with the Noble FoKus App!



iOS Noble FoKus App


Scan this QR code for Product Registration and to find this manual in other languages


www.nobleaudio.com **€** ℝ xxx-xxxxxx





105mm

**INSTRUCTION MANUAL** 










1. Open the lid of your charging case. The earphones will power on automatically 2. To unpair the earphones from your last connected smartphone by "disconnecting" or deleting "Noble FoKus Amadeus" from your smartphone's Bluetooth device list. 3. Once disconnected, the earphones will automatically enter pairing mode, with blue and white indicator lights flashing alternately. 4. Enable Bluetooth on your new device, and search for "Noble FoKus Amadeus" in the available Bluetooth devices. Once found, select "Noble FoKus Amadeus" to initiate pairing. You will hear "connected", now the earphones are ready for use.

Operation		
►II	Play/Pause	Single Click MFS (L/R)
<b>4</b> +	Volume Up+	Triple Click MFS (L)
<b>4</b> −	Volume Down-	Double Click MFS (L)
H	Previous Track	Double Click MFS (R)
M	Next Track	Triple Click MFS (R)
<b>%</b> /~	Answer Call/Hang Up	Single Click MFS (L/R)
٠×	Reject Call	Press the MFS for 2 seconds (L/R)
•	Voice Assistant function- Siri / Google	Press the MFS for 3 seconds (R)
)) /» ···	Ambient mode / ANC mode	Press the MFS for 3 seconds (L)

LED Indicator Lights	
Usage Scenario	LED Indicator Status
Power On	White LED light flashes for one second
Power Off	Blue LED light flashes for one second
Pairing	Blue and white LED light flashes
Pairing succeeds	White LED remains on for 2 seconds
Playing music or on calling	LED light off
Low Power	Blue LED light flashes twice every 8 second
When put earphones in the charger case	Blue LED light on
Earphones are sitted in the charger case	LED light off
Case is charging	
Case full charged	White LED light on

Pairing after being taken out of range: The earphones will automatically pair to the

smartphone within 3 minutes if they are close to the smartphone again after being taken out of range. If they are not brought within range within three minutes, the headphones will automatically power off.



pecification		Declarations and Warnings
		Disconnect previous devices before pairing a new device.
Product Model	FoKus Amadeus	
Bluetooth Version	V 5.4	
Bluetooth Profile	A2DP、AVRCP、HFP、HSP	⚠ WARNING!
Audio Codec	SBC、AAC、aptX Adaptive、LDAC	Long-term exposure to high noise volumes may cause permanent hearing loss.
river size	8.3mm ,37Ω ±3.7(10%)	Do not use the Noble FoKus Amadeus earphones in locations prohibiting the use of electror equipment.
equency response	20HZ~20KHZ	Consult your physician prior to using your Noble FoKus Amadeus earphones if you have a pacemaker or other electrical medical devices.
Connection Distance	≥10m	This package contains small parts, which may pose a hazard to small children.
arphone Battery Capacity	65mAh	Do not disassemble the Noble FoKus Amadeus as it contains lithium batteries, and disassembly could result in electric shock or fire or serious injury.
harging Case Battery Capacity	500mAh	Any disassembly of the Noble FoKus Amadeus, or attempt to replace or repair the Noble FoKus Amadeus by an unauthorized person, will void the Noble FoKus Amadeus warranty.
lay time	Up to 8 hours with ANC on and 12 hours with ANC off	This product is not designed for use in water or wet environments. Keep product away from water and liquids.
Charging time	Earbuds: 1.5 hours; charger case: 2 hours	Failure to do so will void any warranty and may cause permanent damage to the product.
Charging Port	Туре С	Dispose of the product if it becomes swollen or cracked as it may be an indication that the battery is degraded and may burst and cause a fire.
Power input	5V 1A	

11	
FCC STATEMENT	
FCC ID: 2AT8X-FOKUSAMADEUS	
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:	
<ul><li>(1) This device may not cause harmful interference, and</li><li>(2) This device must accept any interference received, including interference that may cause undesired operation.</li></ul>	
<b>Warning</b> : Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.	
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:	
Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.	
Manufacturer: Noble Hifi. LLC € 🕟 222-253864	