



BC 	Table of contents 1 Introduction..... 1 2 Kit Contents 2 3 Connection Diagram..... 3 4 How to use 3 4.1 General function 3 4.2 Pairing to mobile phone 4 4.3 Charging your speaker 6 5 Technology specification 6-7 6 FAQ..... 7	1.Introduction Congratulations, and thank you for choosing the Bluetooth Wireless Speaker. This manual will help you operate the Bluetooth Wireless Speaker, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Bluetooth Wireless Speaker. Safety Rules 1\ Please follow the rules depicted in this manual closely to ensure your safety. Before using this Bluetooth speaker, we would strongly encourage you to read through this user manual. 2\ Be more wary of any edges, uneven surfaces, metal parts, accessories and its packaging so as to prevent any possible injury or damage. 3\ Do not modify, repair or dismantle this Bluetooth speaker. Doing so may result in fires, electric shocks, complete breakdown of this Bluetooth speaker, etc. All of which, are not covered under warranty. 4\ Do not use any diluents or volatile liquid to clean the Bluetooth speaker. 5\ Do not use the Bluetooth speaker in a hazardous location.	2.package includes  1X Bluetooth Wireless Speaker  1X USB Charging, 1x3,5mm Aux-in Cable  1X User Manual 3.Connection Diagram 	4.How to use 4.1.General Functions <table><tr><th>Desired Result</th><th>Required Action</th></tr><tr><td>Turn on & Enter the pairing mode</td><td>Switch the On/Off button at the back.</td></tr><tr><td>Pairing</td><td>You should use a Bluetooth function mobile phone or other Bluetooth Master Device and to perform pairing action (detail refer to the chapter about pairing)</td></tr><tr><td>Play / pause</td><td>Press  to play when the device is pausing and press  to pause when the device is playing.</td></tr><tr><td>Next</td><td>Press  is for next music.</td></tr><tr><td>Previous</td><td>Press  is for previous music.</td></tr><tr><td>Volume up</td><td>Long press the VOL+ for volume up .</td></tr><tr><td>Volume down</td><td>Long press the VOL- for volume down .</td></tr><tr><td>Charging</td><td>Plug the charger to micro-USB port at the back of the device. (Red LED is on)</td></tr><tr><td>Light up effect change</td><td>Press  to change the light up effects.</td></tr><tr><td>Input Mode change</td><td>Long press "M" to change the audio input mode.</td></tr></table>	Desired Result	Required Action	Turn on & Enter the pairing mode	Switch the On/Off button at the back.	Pairing	You should use a Bluetooth function mobile phone or other Bluetooth Master Device and to perform pairing action (detail refer to the chapter about pairing)	Play / pause	Press  to play when the device is pausing and press  to pause when the device is playing.	Next	Press  is for next music.	Previous	Press  is for previous music.	Volume up	Long press the VOL+ for volume up .	Volume down	Long press the VOL- for volume down .	Charging	Plug the charger to micro-USB port at the back of the device. (Red LED is on)	Light up effect change	Press  to change the light up effects.	Input Mode change	Long press "M" to change the audio input mode.
	Desired Result	Required Action																								
Turn on & Enter the pairing mode	Switch the On/Off button at the back.																									
Pairing	You should use a Bluetooth function mobile phone or other Bluetooth Master Device and to perform pairing action (detail refer to the chapter about pairing)																									
Play / pause	Press  to play when the device is pausing and press  to pause when the device is playing.																									
Next	Press  is for next music.																									
Previous	Press  is for previous music.																									
Volume up	Long press the VOL+ for volume up .																									
Volume down	Long press the VOL- for volume down .																									
Charging	Plug the charger to micro-USB port at the back of the device. (Red LED is on)																									
Light up effect change	Press  to change the light up effects.																									
Input Mode change	Long press "M" to change the audio input mode.																									
4.2.Pairing to Mobile phone or other device To use your Bluetooth speaker, you must first pair your speaker with a phone or a computer. Once your Bluetooth speaker is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range. Pairing to a phone and Entertainment: • Turn on your phone and ensure its Bluetooth function is activated • Turn on the speaker go to the pairing mode. • Search your Bluetooth devices on your phone by following the phone's instructions. Refer to your phone's user manual for more information. • After a few second the phone will list the "BT-HELIOS " as a discover device. Select it and follow your phone instruction to select this pairing. • Your phone will confirm the pairing, and then press Yes/Ok. • Finally, select to connect with shower speaker from your phone. • You can play music; watch TV/movie and play game with your phone, then your can hear all the sound or music form the speaker. Also you can control the player by operating the speaker. Example, volume up and next music.	Pairing to a computer and Entertainment: • If there is no Bluetooth function supported by your computer, a Bluetooth adapter is necessary. Fix the adapter with your computer and ensure its Bluetooth function is activated. • Turn on the speaker go to the pairing mode. • Open the Bluetooth software (such as BlueSoleil) installed on your computer, and selects "Search your Bluetooth devices" function. Refer to user manual of the Bluetooth software for more information. • After a few second the " BT-HELIOS " will list in Bluetooth software of your computer as a discover device. Select this icon and click right button of mouse to select "pairing" item, then select "connect with audio device" with same operation. • Open your media player soft to play music, watch TV/movie and play game, then all the sound will be playback on your speaker.	4.3.Charging your speaker The speaker is convenient to connect to USB charger with Micro-USB port. Make sure that your speaker is full charged for at least 6 hours before initial use. Insert one terminal of your charger to USB port of PC and other terminal to Micro-USB jack. While charging, the red LED light constantly. When charging is completed, the LED turns off.  • You must select a qualified charger from a regular manufacturer. • You must charge the Bluetooth speaker if it has been not used for more than 12 months. 5.Technical specification <table><tr><th>Parameter</th><th>Value</th></tr><tr><td>Bluetooth Specification</td><td>4.2</td></tr><tr><td>RF Range</td><td>10 m</td></tr><tr><td>Frequency Response</td><td>100Hz-20KHz</td></tr></table>	Parameter	Value	Bluetooth Specification	4.2	RF Range	10 m	Frequency Response	100Hz-20KHz	<table><tr><th>Parameter</th><th>Value</th></tr><tr><td>Loudspeaker Output</td><td>3W</td></tr><tr><td>Playback Time</td><td>3 - 4 hours</td></tr><tr><td>Charging Time</td><td>Around 4 hours</td></tr><tr><td>Dimension (L×W×H)</td><td>65mm× 52 mm× 320mm</td></tr><tr><td>Weight</td><td>528g</td></tr></table> 6.FAQ 1. Why is there no power even when the Speaker is power on? Ans: Ensure the battery is being charged up to 6 hours for first time using. The LED is lighted when it starts charging. 2.There is no sound when playback. Ans: Check the connection between speaker with phone or computer, if the connection is not established, please reconnect again. Make sure the speaker is paired and connected with your target phone or other master device.	Parameter	Value	Loudspeaker Output	3W	Playback Time	3 - 4 hours	Charging Time	Around 4 hours	Dimension (L×W×H)	65mm× 52 mm× 320mm	Weight	528g			
Parameter	Value																									
Bluetooth Specification	4.2																									
RF Range	10 m																									
Frequency Response	100Hz-20KHz																									
Parameter	Value																									
Loudspeaker Output	3W																									
Playback Time	3 - 4 hours																									
Charging Time	Around 4 hours																									
Dimension (L×W×H)	65mm× 52 mm× 320mm																									
Weight	528g																									
4	5	6	7																							

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.