

QCY T11S 高通QCC3064中英文说明书成型尺寸:80×55mm,80g哑粉纸,双面印刷

折页线

\Box	4	Overview			How to Connect	Factory Setting	How to Wear	Mono Mode
	TWS Bluetooth	Pressure relief hole	Noise reduc	tion of hole	First time connectivity: Open the case and earbuds will auto power-on, pair with each other and turn connectable. On phone, search for QCY-T11S and tap to connect both earbuds to phone.	Open the charging box cover and press the charging box button for 10 seconds until the charging box indicator shows redAfter alternating blue flashes for 3 times, close the lid to complete the reset.		1. Earbuds were paired before. Keep tou either earbud for 2s to power on them. The connectable in 5s(LED will blink blue). 2. On phone, search for QCY-T11S and tap earbud to phone.
(°(1)		In-ear sensor	Touch	panel	Switch connected device: 1. Turn off phoneA's Bluetooth faculty and earbuds will auto disconnect and turn connectable."		Plug the ear cap diagonally downward into the ear canal gently to gently sway the head earphone without shaking.	Charge the Earbuds Push earbuds into the case and close the lid auto turn off and to be charged.
\mathcal{A}			LED		On phoneB, search for QCY-T11S and tap to connect. Multi-point connection is not available and earbuds will auto reconnect to phoneB upon powering up again.		During a call, point the earphone microphone towards the mouth to make the call clearer.	1
\	$\cup \cup \cup \cup$						3. Please wear the left and right earphones correctly, and make them firmly match the auricle and the sound producing mouth after entering the ear Must the ear canal.	Charge the Case LED of the case will glow solid red when cl
	7 /			−Mic 1-Pogo pins			One Press to Enter Pairing Mode	green once topped up.
				7 . e8e be			Put the headset in the box, open the charging box cover, and press the button of the charging box for 3 seconds until	1
		1 31	LED				chargingWith the box light flashing 3 times, the headset will disconnect from the phone and enter the pairing mode.	1
								1
			rpe-C USB					1
								The second secon
			narging port			' ·		1
For hetter i	Ising experience, please scan		narging port			(')		
	using experience, please scan pad QCY app before start-up.		narging port			·		
			arging port					
to downlo			arging port		Marrack Cond			
			arging port	. – – – .	Warranty Card	FCC Statement		l I I Tips
to downlo		Operation	LED	Prompt	Warranty Period 12 months after you purchase this item.(or you may	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the	Hazardous substances and their contents in the item	Before using the headset, please read th
to downlo	oad QCY app before start-up.	 	aarging port	Prompt	Warranty Period	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.	Hazardous substances and their contents in the item	Before using the headset, please read the carefully and keep it for future reference The headset need to be fully charged price.
to downlo	Current status Earbuds are not in the case Earbuds are in the case with its	Operation Keep touching the panel for 2s	aarging port		Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against hamful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the	Hazardous Substances	Before using the headset, please read the carefully and keep it for future references. The headset need to be fully charged primary in the headset is left unused for over two recharge it periodically.
Functions	Current status Earbuds are not in the case Earbuds are in the case with its lid closed (the case is within power	Operation Keep toyching the panel for 2s Open the lid	LED blinks blue	e TONE	Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against hamful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause hamful interference to radio communications. However, there is no guarantee that interference will not occur	Hazardous Substances	Before using the headset, please read the carefully and keep it for future reference The headset need to be fully charged price If the headset is left unused for over two recharge it periodically. Please use the chargers made by qualifications of the headset cannot be found by your phenomenance.
Functions	Current status Earbuds are not in the case Earbuds are in the case with its	Operation Keep touching the panel for 2s	LED blinks blue	e TONE	Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service.	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be	Hazardous Substances	1. Before using the headset, please read th carefully and keep it for future reference 2. The headset need to be fully charged pric 3. If the headset is left unused for over two recharge it periodically. 4. Please use the chargers made by qualific 5. If the headset cannot be found by your ph whether it is in pairing mode; if left uncor while, the headset will exit pairing mode.
Functions Functions Power-on	Current status Earbuds are not in the case Earbuds are in the case with its lid closed (the case is within power	Operation Keep toyching the panel for 2s Open the lid	LED blinks blue	e TONE	Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service. Model Number: Date of Purchasing:	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation, if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more	Hazardous Substances	1. Before using the headset, please read th carefully and keep it for future reference 2. The headset need to be fully charged prid 3. If the headset is left unused for over two recharge it periodically. 4. Please use the chargers made by qualification of the headset cannot be found by your play whether it is in pairing mode; if left uncounties, the headset will exit pairing mode the mode; if a procedure error of your phrocedure error of your phrocedure.
Functions Functions Power-on	Current status Earbuds are not in the case with its lid closed (the case is within power Case is within power /	Operation Keep touching the panel for 2s Open the lid Push earpuds into case and close the lid Keep touching the panel for 5s	LED LED blinks blur LED glows solid red when chargin LED glows red for 2s	e TONE	Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service. Model Number: Date of Purchasing: User's Name:	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against hamful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installated and used in accordance with the instructions, may cause hamful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause hamful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: — Reorient or relocate the receiving antenna.	Hazardous Substances	1. Before using the headset, please read the carefully and keep it for future reference. 2. The headset need to be fully charged prid. 3. If the headset is left unused for over two recharge it periodically. 4. Please use the chargers made by qualification of the headset cannot be found by your play whether it is in pairing mode; if left uncounties, the headset will exit pairing mode the mode; if a procedure error of your phreads.
Functions Functions Power-on Power-off Answer/end call	Current status Earbuds are not in the case Earbuds are in the case with its lid closed (the case is within power / Incoming call/calling	Operation Keep touching the panel for 2s Open the lid Push earphuds into case and close the lid Keep touching the panel for 5s Double tap the panel to answer/end the call	LED LED blinks blur LED glows solid red when chargin LED glows red for 2s	P TONE TONE TONE	Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service. Model Number: Date of Purchasing: User's Name: User's Phone: User's Address:	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installated and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different	Hazardous Substances	1. Before using the headset, please read the carefully and keep it for future reference. 2. The headset need to be fully charged prid. 3. If the headset is left unused for over two recharge it periodically. 4. Please use the chargers made by qualiff. 5. If the headset cannot be found by your play whether it is in pairing mode; if left uncowhile, the headset will exit pairing mod the mode; if a procedure error of your phit; if a procedure error of the headsetoccur. Caveats
Functions Functions Power-on Power-off Answer/end call Ignore call	Current status Earbuds are not in the case Earbuds are in the case with its lid closed (the case is within power / Incoming call/calling Incoming call	Operation Keep touching the panel for 2s Open the lid Push earbuds into case and close the lid Keep touching the panel for 5s Double tap the panel to answer/end the call Keep touching the panel for 1s	LED LED blinks blur LED glows solid red when chargin LED glows red for 2s	TONE TONE TONE TONE	Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service. Model Number: Date of Purchasing: User's Name: User's Phone: User's Phone: User's Address: Shop's Name:	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential instalation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.	Part Name Pb Hg Cd Cf PBB PBDE DIBP DEHP DBP BBP DBP DBP	1. Before using the headset, please read the carefully and keep it for future reference. 2. The headset need to be fully charged prid. 3. If the headset is left unused for over two recharge it periodically. 4. Please use the chargers made by qualiff. 5. If the headset cannot be found by your play whether it is in pairing mode; if left uncowhile, the headset will exit pairing mode the mode; if a procedure error of your phit; if a procedure error of the headsetoccur. Caveats 1. Never disassemble or modify your head reasons to avoid any damages and dan
Functions Functions Power-on Power-off Answer/end call	Current status Earbuds are not in the case Earbuds are in the case with its lid closed (the case is within power / Incoming call/calling	Operation Keep touching the panel for 2s Open the lid Push earphuds into case and close the lid Keep touching the panel for 5s Double tap the panel to answer/end the call	LED LED blinks blur LED glows solid red when chargin LED glows red for 2s	P TONE TONE TONE	Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service. Model Number: Date of Purchasing: User's Name: User's Phone: User's Address:	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/IV technician for help.	Part Name Pb Hg Cd CVVVV PBB PBDE DIBP DEHP DBP BBP Main body X O O O O O O O O O	1. Before using the headset, please read th carefully and keep it for future reference 2. The headset need to be fully charged pric 3. If the headset is left unused for over two recharge it periodically. 4. Please use the chargers made by qualific 5. If the headset cannot be found by your phother it is in pairing mode; if left uncounty while, the headset will exit pairing mode the mode; if a procedure error of your phother, it is procedure error of your phother, if a procedure error of the headsetoccurs Caveats 1. Never disassemble or modify your heads reasons to avoid any damages and dang 2. Do not store the headset in extreme tem 0°C or over 45°C.
Functions Functions Power-on Power-off Answer/end call Ignore call Voice assistant Music pause/	Current status Earbuds are not in the case Earbuds are in the case with its lid closed (the case is within power / Incoming call/calling Incoming call	Operation Keep toyching the panel for 2s Open the lid Push earpluds into case and close the lid Keep toyching the panel for 5s Double tap the panel to answer/end the call Keep touching the panel for 1s Triple tab the panel 1. Double tap	LED LED blinks blue LED glows solid red when chargin LED glows red for 2s	TONE TONE TONE TONE	Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service. Model Number: Date of Purchasing: User's Name: User's Phone: User's Address: Shop's Name: Shop's Address:	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installated and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2)	Hazardous Substances	1. Before using the headset, please read the carefully and keep it for future reference. 2. The headset need to be fully charged prid. 3. If the headset is left unused for over two recharge it periodically. 4. Please use the chargers made by qualification of the found by your plant whether it is in pairing mode; if left uncome while, the headset will exit pairing mode the mode; if a procedure error of your phore it; if a procedure error of the headsetoccurs. Caveats 1. Never disassemble or modify your head reasons to avoid any damages and dang 2. Do not store the headset in extreme tem 0°C or over 45°C). 3. Avoid using the indicator close to the eyanimals.
Functions Functions Power-on Power-off Answer/end call Ignore call Voice assistant	Current status Earbuds are not in the case Earbuds are in the case with its lid closed (the case is within power Case is within power / Incoming call/calling Incoming call Connected	Operation Keep touching the panel for 2s Open the lid Push earpuds into case and close the lid Keep touching the panel for 5s Double tap the panel to answer/end the call Keep touching the panel for 1s Triple tap the panel	LED LED blinks blue LED glows solid red when chargin LED glows red for 2s	TONE TONE TONE TONE	Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service. Model Number: Date of Purchasing: User's Name: User's Phone: User's Address: Shop's Name: Shop's Address: Comments:	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installated and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:	Hazardous Substances	1. Before using the headset, please read th carefully and keep it for future reference 2. The headset need to be fully charged pric 3. If the headset is left unused for over two recharge it periodically. 4. Please use the chargers made by qualific 5. If the headset cannot be found by your pheadset will exit pairing mode; if left uncounce while, the headset will exit pairing mode the mode; if a procedure error of your pheit; if a procedure error of your pheit; if a procedure error of the headset occurs Caveats 1. Never disassemble or modify your headseasons to avoid any damages and dang 2. Do not store the headset in extreme tem 0°C or over 45°C). 3. Avoid using the indicator close to the ey animals. 4. Do not use this headset during a thunde irregular function and increased risk of expressions.
Functions Functions Power-on Power-off Answer/end call Ignore call Voice assistant Music pause/	Current status Earbuds are not in the case Earbuds are in the case with its lid closed (the case is within power / Incoming call/ calling Incoming call Connected Playing	Operation Keep touching the panel for 2s Open the lid Push earpuds into case and close the lid Keep touching the panel for 5s Double tap the panel to answer/end the call Keep touching the panel for 1s Triple tab the panel 1. Double tap 2. Put off either earbud to pause and put it on in 15s to resume playing Keep touching either panel for 2s to skip	LED LED blinks blue LED glows solid red when chargin LED glows red for 2s	TONE TONE TONE TONE	Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service. Model Number: Date of Purchasing: User's Name: User's Phone: User's Address: Shop's Name: Shop's Address: Comments: Free exchange service will not be accessed under following circumstances:	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced adio/Tvtechnician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following woo conditions: (1) This device may not cause harmful interference, and (2) this device may not cause harmful interference, including	Part Name Pb Hg Cd Cr Ni PBB PBDE DIBP DEHP DBP BBP Mainbody X O O O O O O O O O Battery O O O O O O O O O O Eartips O O O O O O O O O O Eartips O O O O O O O O O O O Charging X O O O O O O O O O O O Charging X O O O O O O O O O O O O This form is made by SJ/T 11364 regulation. O: means that hazardous substance content in the homogeneous materials of this part is within the limits of (EU) 2015/863 regulation. X: means that hazardous substance content in, at least, one certain homogeneous material of this part is beyond the limits of (EU) 2015/863 regulation, but there is no mature alternative in the industry at present, it still conforms to the EU ROHS Directive in the scope of exemption. Notes: Please arrange using time properly as your hearing	1. Before using the headset, please read the carefully and keep it for future reference. 2. The headset need to be fully charged prid. 3. If the headset is left unused for over two recharge it periodically. 4. Please use the chargers made by qualiff. 5. If the headset cannot be found by your play whether it is in pairing mode; if left uncowhile, the headset will exit pairing mode the mode; if a procedure error of your phit; if a procedure error of your phit; if a procedure error of the headsetoccur. Caveats 1. Never disassemble or modify your head reasons to avoid any damages and dan 2. Do not store the headset in extreme tem 0°C or over 45°C). 3. Avoid using the indicator close to the eyanimals. 4. Do not use this headset during a thunde irregular function and increased risk of 5. Do not use harsh chemicals or strong declean the headset.
Functions Functions Power-on Power-off Answer/end call Ignore call Voice assistant Music pause/ resume playing	Current status Earbuds are not in the case Earbuds are in the case with its lid closed (the case is within power / Incoming call/ calling Incoming call Connected Playing	Operation Keep toyching the panel for 2s Open the lid Push earpuds into case and close the lid Keep toyching the panel for 5s Double tap the panel to answer/end the call Keep toyching the panel for 1s Triple tab the panel 1. Double tap 2. Put off either earbud to pause and put it on in 15s to resume playing	LED LED blinks blue LED glows solid red when chargin LED glows red for 2s	TONE TONE TONE TONE	Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service. Model Number: Date of Purchasing: User's Name: User's Phone: User's Phone: User's Address: Shop's Name: Shop's Address: Comments: Free exchange service will not be accessed under following circumstances: 1. Damages caused unauthorized disassembly. 2. Defects or physical damages caused by leaking or	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or relevision reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/Tytechnician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device must accept any interference received, including interference that may cause undesired operation.	Part Hazardous Substances Part Part Ph Hg Cd Cr Cr PBB PBDE DIBP DEHP DBP BBP Main body X O O O O O O O O O D Battery O O O O O O O O O O O O O O O O O O O	1. Before using the headset, please read the carefully and keep it for future reference. 2. The headset need to be fully charged prid. 3. If the headset is left unused for over two recharge it periodically. 4. Please use the chargers made by qualiff. 5. If the headset cannot be found by your plands whether it is in pairing mode; if left uncowhile, the headset will exit pairing mod the mode; if a procedure error of your phrit; if a procedure error of the headsetoccur. Caveats 1. Never disassemble or modify your head reasons to avoid any damages and dany. Do not store the headset in extreme tem 0°C or over 45°C). 3. Avoid using the indicator close to the eyanimals. 4. Do not use this headset during a thunderingular function and increased risk of themicals or strong deforms.
Functions Functions Power-on Power-off Answer/end call Ignore call Voice assistant Music pause/ resume playing	Current status Earbuds are not in the case Earbuds are in the case with its lid closed (the case is within power / Incoming call/ calling Incoming call Connected Playing	Operation Keep touching the panel for 2s Open the lid Push earpuds into case and close the lid Keep touching the panel for 5s Double tap the panel to answer/end the call Keep touching the panel for 1s Triple tab the panel 1. Double tap 2. Put off either earbud to pause and put it on in 15s to resume playing Keep touching either panel for 2s to skip	LED LED blinks blue LED glows solid red when chargin LED glows red for 2s	TONE TONE TONE TONE	Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service. Model Number: Date of Purchasing: User's Name: User's Name: User's Phone: User's Phone: User's Address: Shop's Address: Comments: Free exchange service will not be accessed under following circumstances: 1. Damages caused unauthorized disassembly. 2. Defects or physical damages caused by leaking or dropping off. 3. Damages by act of God.Supposing your item is within	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installated and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/Tv technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.	Part Name Pb Hg Cd Cr Ni PBB PBDE DIBP DEHP DBP BBP Mainbody X O O O O O O O O O Battery O O O O O O O O O O Eartips O O O O O O O O O O Eartips O O O O O O O O O O O Charging X O O O O O O O O O O O Charging X O O O O O O O O O O O O This form is made by SJ/T 11364 regulation. O: means that hazardous substance content in the homogeneous materials of this part is within the limits of (EU) 2015/863 regulation. X: means that hazardous substance content in, at least, one certain homogeneous material of this part is beyond the limits of (EU) 2015/863 regulation, but there is no mature alternative in the industry at present, it still conforms to the EU ROHS Directive in the scope of exemption. Notes: Please arrange using time properly as your hearing	1. Before using the headset, please read the carefully and keep it for future reference. 2. The headset need to be fully charged prid. 3. If the headset is left unused for over two recharge it periodically. 4. Please use the chargers made by qualification of the standard of the mode; if left uncombile, the headset will exit pairing mode the mode; if a procedure error of your photic, if a procedure error of your photic; if a procedure error of your photic; if a procedure error of the headsetocum. Caveats 1. Never disassemble or modify your head reasons to avoid any damages and dang 2. Do not store the headset in extreme tem o°C or over 45°C). 3. Avoid using the indicator close to the eyanimals. 4. Do not use this headset during a thunder irregular function and increased risk of 5. Do not use harsh chemicals or strong declean the headset.
Functions Functions Power-on Power-off Answer/end call Ignore call Voice assistant Music pause/ resume playing	Current status Earbuds are not in the case Earbuds are in the case with its lid closed (the case is within power / Incoming call/ calling Incoming call Connected Playing	Operation Keep touching the panel for 2s Open the lid Push earpuds into case and close the lid Keep touching the panel for 5s Double tap the panel to answer/end the call Keep touching the panel for 1s Triple tab the panel 1. Double tap 2. Put off either earbud to pause and put it on in 15s to resume playing Keep touching either panel for 2s to skip	LED LED blinks blue LED glows solid red when chargin LED glows red for 2s	TONE TONE TONE TONE	Warranty Period 12 months after you purchase this item.(or you may inquire your local shopper for more details.) Free Service: Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service. Model Number: Date of Purchasing: User's Name: User's Name: User's Phone: User's Address: Shop's Name: Shop's Address: Comments: Free exchange service will not be accessed under following circumstances: 1. Damages caused unauthorized disassembly. 2. Defects or physical damages caused by leaking or dropping off.	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installated and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.	Part Name Pb Hg Cd C VII PBB PBBE DIBP DEHP DBP BBP BBP Main body X O O O O O O O O O O O O O O O O O O	1. Before using the headset, please read the carefully and keep it for future reference. 2. The headset need to be fully charged pric. 3. If the headset is left unused for over two recharge it periodically. 4. Please use the chargers made by qualific. 5. If the headset cannot be found by your pheads whether it is in pairing mode; if left unconwhile, the headset will exit pairing mode the mode; if a procedure error of your pheads, it is a procedure error of your pheads, it is a procedure error of the headsetocurs. Caveats 1. Never disassemble or modify your heads reasons to avoid any damages and dang 2. Do not store the headset in extreme tem 0°C or over 45°C). 3. Avoid using the indicator close to the eyanimals. 4. Do not use this headset during a thunde irregular function and increased risk of 6. Do not use harsh chemicals or strong declean the headset.

1.尺寸要求:图面标注尺寸为必检尺寸

2.环保要求:符合和乐环保标准《HL-QP-RD-03》&包材指令

3.可靠性要求:符合和乐物料可靠性测试规范《HL-WI-QA-026》

4.其它方面要求:

名称	公差:mm	东莞市和乐电子有限公司										
▍ 外箱	±5.0											
彩盒	±1.0	资料确认表	料号		软件		法务					
标签	±0.5		名称	T11S中英文说明书	电子		市场					
说明书	±1.0		材质	80g哑粉纸	结构		包装	李思盛				
热缩膜	宽:士3,高:士15		工艺	双面印刷	声学							
防爆袋	宽:土3,高:土15	次立	物料承认 书编号		品牌							