



BLUETOOTH® COLOR HEADPHONES


3301732,3301733,3301734
User's Guide

We hope you enjoy your Bluetooth Color Headphones. With convenient controls on earcups, the headphones provide an elevated audio experience and supreme sound quality with noise isolating design. Please read this user's guide before using your headphones.

Package Contents

- Headphones
- USB Charging Cable
- 3.5mm Audio Cable
- Use's Guide

Charge Your Headphones



When the **LED Indicator** flashes red or has no response, charge your headset.

- Normal charging takes about 1.5 hours.
 - Provides up to 12 hours of play time and up to 100 hours standby.
1. Connect the supplied charging cable to the USB source and to the micro **USB charging port**. The **LED Indicator**

lights red when charging and turns off when fully charged.

2. Unplug the charging cable when the headphones are fully charged.

Pairing

1. Press and hold ► for 5 seconds to turn on. **LED Indicator** flashes pink and then blue quickly.
2. Press and hold ► for 3 seconds to start pairing. **LED Indicator** flashes blue and red.
3. On your device, turn on the Bluetooth function, and set it to search for Bluetooth devices.
4. Select **AUVIO BTCHP** from the list of found devices.
5. When paired, the **LED Indicator** flashes blue slowly.

Note: If the headphones are not paired within 3 minutes, they turn off automatically.

Using the headphones

To turn the headset on/off, press and hold ► for 5 seconds.

On: **LED Indicator** flashes pink and then blue quickly.

Off: **LED Indicator** flashes pink and then turns off.

To	Button	Press
Turn on headphones	►	..and hold for 5 sec.
Turn off headphones		..and hold for 5 sec.

Start Bluetooth pairing	►	..and hold for 3 sec.
Clear Bluetooth pairing		..and hold for 3 sec.
Play/Pause		× 1
Answer/end call		× 1
Reject an incoming call		× 2
Last-number redial	Vol +/-	..and hold for 3 sec.
Go to next/previous track		

Clear Bluetooth Pairing

Your headphones automatically reconnect to the most recently paired device when switched on.

If you want to clear the Bluetooth memory, change to other Bluetooth devices, or in case of problems with pairing, do the following:

1. Press ► and hold for 3 seconds.
2. The headphones beep to confirm disconnection. **LED Indicator** turns from flashing blue slowly to rapidly flashing blue and red.
3. When you switch on the headphones next time, the headphones no longer pair automatically.

Wired Mode

- Use the **3.5mm Audio Cable** to connect to your headphones's audio jack. Make sure the headphones are switched off to save power. A handy option when your headphone battery power is depleted.

Specifications

Battery charge time.....	1.5 hours
Operation time.....	12 hours
Standby time.....	100 hours
Battery charging voltage	5VDC
Charging current.....	400 mA
Bluetooth protocol.....	V4.0
Operating distance	33 ft. (10m)
Frequency response.....	20Hz - 20KHz (speakers)
	100Hz-10KHz (mic)
Sensitivity.....	113dB (speakers), -42dB (mic)
Impedance.....	32 Ohms
Charging Cable length	1.5 ft. (0.45m)
Audio Cable length.....	3.9 ft. (1.2m)

Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.

FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your radio. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

90-Day Limited Warranty

Go to www.radioshack.com/help for details.

RadioShack Customer Relations
300 RadioShack Circle, Fort Worth, TX 76102

The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by General Wireless Operations Inc. is under license.

RoHS Complies with the European Union's "Restriction of Hazardous Substances Directive," which protects the environment by restricting specific hazardous materials and products.

www.radioshack.com

© 2016 General Wireless Operations Inc.
All rights reserved. AUVIO is a registered trademark used under license by General Wireless Operations Inc. dba RadioShack.



05A16
3301732
3301733
3301734
Printed
in China