

Model No.: MH22193

MONSTER

BLUETOOTH HEADPHONE

QUICK START GUIDE

Please read this Quick Start Guide carefully and keep it for future use.

Product Overview

In-ear Earphone x 2 (left & right)

Charging Case

USB-C Charging Cable

Ear Tips x 3 pairs (medium pre-installed)

Ear support x 1 pairs

Quick Start Guide and Warranty Letter

3

4

5

1

2

6

1. Earphone indicator

2. MFB

3. Charging contact

4. Ear tip

5. Charging case indicator light

6. USB-C charging port

Power on/off

Open the cover of the charging case and it will turn on automatically. Put the earphones into the charging case, close the cover, and the earphones will automatically turn off and charge.

Charging

Use the USB-C charging cable provided with the product to charge, and the charging case indicator shows the charging status. When the charging case is fully charged, the charging case indicator lights up.

Pairing

Open the charging case cover and the charging case will open automatically. To connect a new device, turn on your phone's Bluetooth and search for "Monster N-Lite 206" to pair.

Volume control

Turn down the volume: While the music is playing, click the MFB on the left earphone.

Turn up the volume: While the music is playing, click the MFB on the right earphone.

Call

Answer/end a call: double-click the MFB .

Rejecting a call: Long press the MFB .

Music

Play/Pause music: Double click the MFB.

Previous: Connected mobile phone status, left earphone quickly touch 3 times.

Next: Connected mobile phone status, right earphone quickly touch 3 times.

Voice Control

When the phone is connected, long press the MFB for 2 seconds to wake up the voice assistant.

Reset

When the earphone is powered on and not connected to Bluetooth device, press the MFB button of one earphone five times, and the earphones will automatically shut down after the white light of the earphones is on for 2 seconds, and the factory Settings can be restored.

Indicator/Voice Prompt Guide

Mode	Description	Voice Prompt
Power On	The white light flashes quickly	The system prompts voice
Power Off	The white light is on for 2 seconds	The system prompts voice
Pairing	The white light flashes quickly	The system prompts voice
Connected	The white indicator is on for 1S and off	The system prompts voice
Charging case	When charging the charging case, the indicator light on the charging case flashes, and it will stay on after being fully charged	-

Cautions

- \* After removing the earphones from the charging case, without pressing any buttons, the left and right earpieces will connect automatically. When no connections found, it will enter automatic pairing mode.
- \* Please place the earphones in the correct location (L/R) for normal charging.
- \* Replacement of battery (on your own) is not recommended.
- \* Do not expose battery (battery pack) to excessive heat such as direct sunlight or fire.

Key operation

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2AVD2-MH22193

Model No.: MH22193

MONSTER

快速指南

请仔细阅读快速指南并妥善保存以备将来使用。

本产品由中国平安保险公司承保

产品概述

\*入耳式耳机x 2 (左&右)

\*充电盒

\*USB-C充电线

\*耳撑×1对

\*耳帽×3对 (M号已安装到耳机上)

\*快速指南与保修单

3

4

5

1

2

6

1. 耳机指示灯

2. 多功能触控键 (MFB)

3. 充电触点

4. 耳帽

5. 充电盒指示灯

6. USB-C充电接口

电源开/关

打开充电盒盖, 它将自动开机。将耳机放入充电盒, 把盖合上, 耳机会自动关机及进行充电。

充电盒充电

使用产品自带的 USB-C 充电线进行充电, 充电盒指示灯显示充电状态。当充电盒充满电时, 充电盒指示灯长亮。

配对

打开充电盒盖子, 它将自动开机。对于新设备连接, 请打开手机蓝牙并搜索“Monster N-Lite 206”进行配对。

音量控制

调低音量: 在音乐播放状态下, 单击左耳机的触摸多功能按键。

调高音量: 在音乐播放状态下, 单击右耳机的触摸多功能按键。

通话

接听/结束通话: 双击触摸多功能按键。

拒接来电: 长按触摸多功能按键。

音乐

播放/暂停音乐: 双击触摸多功能按键。

上一曲: 已连接手机状态, 左耳快击3下。

下一曲: 已连接手机状态, 右耳快击3下。

语音控制

已连接手机状态, 长按2秒触摸多功能按键后唤醒语音助手。

恢复出厂设置

在耳机开机且未连接蓝牙设备时, 连接其中一个耳机的MFB键5次, 耳机白灯长亮5秒后关机, 即可恢复出厂设置。

指示灯/语音指南

模式	描述	声音提示
开机	白灯快闪	系统提示音
关机	白灯长亮2S熄灭	系统提示音
配对	白灯快闪	系统提示音
连接	白灯长亮1S熄灭	系统提示音
充电盒充电	充电盒充电时, 充电盒上的指示灯闪烁, 充满后长亮	-

注意

- \*从充电盒中取出耳机后, 无需按任何按键, 左右耳机会自动连接和自动进入配对模式。
- \*请将耳机放在正确的位置进行充电。
- \*不建议未经许可私下更换电池。
- \*电池[电池组或电池组合]不得暴露于照明, 烘烤或类似过热的环境中。

按键操作

封面

75X95MM 105G双胶+1专1黑+风琴折

