



arlo®

Arlo Audio Doorbell
Quick Start Guide



View a video tutorial

To view a video tutorial, visit www.arlo.com/support and click the Arlo Doorbell.

For more information, look for *How do I set up my Arlo Audio Doorbell?*.



Scan the QR code to
view the video



What's in the box



Doorbell



AA batteries



Screwdriver



Wall screws
and anchors



Wire extensions



Wire screws



Wire nuts

Get the Arlo mobile app

You must use the app to install your Arlo Audio Doorbell. The app provides step-by-step instructions.




Power your doorbell and add it to your Arlo account

1. Insert two AA batteries into your doorbell. Your doorbell runs on battery power.
2. Use your app to set up your Arlo Doorbell and add it to your account.



Mount your doorbell without wiring

1. Secure the battery cover on your wall using the provided screws.
2. Attach the doorbell to the battery cover.
3. Secure the Arlo doorbell with the screw on the bottom of the battery cover.



Note: To mount your doorbell with wiring, see page 8.

Connect your Arlo doorbell to trigger your existing chime (Optional)


You can connect your Arlo doorbell to existing mechanical or electronic doorbells if they operate at a voltage between 8 and 24 volts AC. After you connect your doorbell, press the button on your Arlo doorbell to trigger your existing chime.

Set the chime switch

Determine whether you have a mechanical or a digital chime.


Mechanical chimes usually make a sound like ding dong. Digital chimes can have a variety of sounds, some can play tunes.

1. If you have a mechanical chime, set the chime switch to position 1.
2. If you have a digital chime, set the chime switch to position 2.



Connect the doorbell battery cover to your existing chime

1. Turn off the power to your current doorbell at the breaker.
2. Remove your current doorbell.
3. Connect the wires coming out of the wall to the terminals on the back of the Arlo doorbell battery cover with the screws we provide.




Current doorbell wires from your wall (Either wire can connect to either terminal.)

If the wires are too short, use the accessories provided.



4. Feed the wires back into your wall.
5. Secure the Arlo battery cover to the wall using the mounting screws.
6. Turn the power on at the breaker.




Attach the doorbell to the battery cover

1. Attach your doorbell to the battery cover.

2. Press the doorbell button, listen for a chime.

If you don't hear a chime, remove the doorbell from the battery cover and adjust the chime switch to position 3. Reattach the doorbell, press the doorbell button, and listen for a chime.



3. Secure the Arlo doorbell with the screw on the bottom of the battery cover.



Use your Arlo app

Use your app to set up and manage all your Arlo devices and your Arlo account.

To view useful tutorial videos, find troubleshooting tips, or get support, scan the QR code or navigate in your browser to visit www.arlo.com/support.



© Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. Other trademarks are for reference purposes only.

Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à arlo.com/docs.

(If this product is sold in Canada, you can access this document in Canadian French at arlo.com/docs.)

For regulatory compliance information including the EU Declaration of Conformity, visit www.netgear.com/about/regulatory/.

FCC ID: 2APLE18300388

IC ID: 23815-18300388



Arlo International, Ltd.

Floor 3, Building 3 University Technology Center
Curraheen Road, Cork, Ireland



Arlo Technologies, Inc.
2200 Faraday Ave. Suite 150
Carlsbad, CA 92008 USA

www.arlo.com
www.arlo.com/support

August 2018



201-24146-01