

The image shows the front cover of the instruction manual for the BASS JAXX ARMOR True Wireless Earbuds. At the top left is the BASS JAXX logo, which consists of a stylized 'B' above the text 'BASS JAXX'. The main title 'ARMOR' is prominently displayed in large, bold, black capital letters. Below it, 'TRUE WIRELESS EARBUDS' is written in a smaller, bold, black sans-serif font. Underneath that, 'INSTRUCTION MANUAL' is also in a bold, black sans-serif font. A paragraph of text follows: 'Thank you for purchasing the ARMOR True Wireless Earbuds. This manual provides more information about the wireless earbuds, please read the instructions before using.' At the bottom of the cover is a photograph of the product: a black, ruggedized carrying case with a handle and a clear window showing the earbuds inside, and two black wireless earbuds lying in front of it.

ARMOR True Wireless Earbuds

1. LED Indicator
2. Touch Control Area
3. Case Cover Lock
4. Charging LED Indicator
5. Micro USB Charging Port

Protective Stickers (at the bottom)

"Remove the protective stickers before using"

Portable Charging Case

1. LED Indicator
2. Touch Control Area
3. Case Cover Lock
4. Charging LED Indicator
5. Micro USB Charging Port

Charging Case Battery Capacity: 500 mAh
Micro USB Charging Cable Included

Power off the wireless earbuds; or
Switch off the Bluetooth on your mobile phone; or
Leave the earbuds 60ft away from your mobile phone or further.

Answer / Reject a call

When receive a call, press the touch control area once (on either earbud) to accept the call, or answer the call normally via your mobile phone.
Press and hold the touch control area 2 seconds to reject it.

End a call

To end the call, just press the touch control area at any side of earbud with Beep sound to end it.

Functions

Pause / Play Music: Short Press on touch control area
Go back to previous song: Double tap Left touch control area.
Advance to next song: Double tap Right touch control area.

Charging your Earbuds

1. Open the charging case cover.
2. Remove the protective stickers between earbuds and charging case.
3. Insert the Earbuds into the charging case.
4. The earbuds will start the charge automatically.
5. LED indicator light of the Earbuds will be turned on when charging.
6. Once fully charged, the LED will be off.


Recharge Charging Case

⚠ For your safety, please always use appropriate 5V output charger/Adapter to charge the product. **DO NOT USE** Quick Charging USB Adapter to charge the product, as it might damage the product.

1. Use the Micro USB charging cable provided with the packaging.
2. Connect the Micro USB plug to Micro USB charging port on the charging case, then connect the USB plug to a USB port on a computer or wall adapter to begin charging.
3. The Red LED on the charging case will be on during charge.
4. Once fully charged, the Red LED will be off.
5. The Blue LED will be on during earbuds is charging and will be off after fully charged.

NOTE:

- You must charge a qualified charger from a regular manufacturer.
- You must charge the charging case and earbuds if it has been not used for more than 6 months.



WARNING: This product can expose you to chemicals including Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

Made in China