



1 PREPARING



2 ASSEMBLY AND DISASSEMBLY




3 TESTING



# R90 • Long Range Reader

## 4 TAMPER SWITCH



An on board tamper switch is wired through the "I'm Alive" feature and if active, the standard supervisory signal will stop if the cover is removed.

## 5 OPTIONAL FEATURES

- Open Collector Output - controls an external device operating in Host Mode only. See iCLASS Application Note for details.
- Configuration Options - Configure LED, Speaker, and other features. See How To Order Guide or iCLASS Application Note for details.
- Hold Input - when asserted, this line either buffers a card or disables a card read until released, as configured.

## 6 PARTS

### PARTS

- 1 - reader
- 1 - Installation Manual
- 4 - #8 Phillips self tapping screws
- 4 - #8 Spanner security screws

### HID Corporation

9292 Jeronimo Road  
Irvine, California  
92618-1905 USA

tel:  
+1 (949) 598-1600  
U.S. (800) 237-7769  
fax:  
+1 (949) 598-1690  
email:  
tech@hidcorp.com

[www.hidcorp.com](http://www.hidcorp.com)



An ASSA ABLOY Group company

ASSA ABLOY

INSTALLATION

# iCLASS<sup>®</sup> by

# HID