尺寸:117x161mm 材质:100g书纸 工艺:骑马钉

Wireless Optical TV Headphones **USER MANUAL**

1. Works with all TV sets, including the latest Smart 2. Watch TV without disturbing others

for enjoying crystal sound stereo music and TV

DVD player, Hi-Fi system, or iPod. Without

complicated wiring and installation, the system

enables you to enjoy thrilling, lifelike sound in

3. Headphone lasts up to 6 hours after full charge 4. Wireless range: 80 ft.

INTRODUCTION

8. One transmitter for multiple headphones

COMPOSANTS This wireless stereo headphone is a perfect solution sound anywhere inside your home. Simply connect the transmitter to a desired audio source: TV set,

1. Increase Volume

2. Decrease Volume 3. Power Indicator

5. Micro USB Charging Port

6. 3.5mm Audio Jack

Power Indicator

8. 5V Power Input

10. Optical Audio Input

11. 3.5mm Audio Jack

12. Optical Audio Cable

14. RCA Audio Cable

15. 3.5mm Audio Cable

16. Micro USB Charging Cable

13. AC/DC Power Adapter

Power Switch

blue and turns off when fully charged.

2. ON/ OFF/ Channel Select Press this buttons for 3S to turn the headphone on/off Short press this button to switch to desired channel

When headphone is turned on, LED steadily glows red

When headphone is charging, LED steadily glows

Press the volume +/- Key to adjust volume

1. LED Light

Use a 3.5mm audio cable for wired mode

INSTALLATION SET UP THE TRANSMITTER Plug the included 5V AC/DC power adapter into the DC jack at the rear of the transmitter, then plug the other end of the adapter into a wall outlet.

CONNECT TO TV

RCA to 3.5mm adaptor cable, 1M 3.5mm audio cable and optical fiber cable are provided for various type of connection to TV.

You may connect transmitter to the TV in three

A. Headphone Jack Locate 3.5mm Audio IN socket at the rear of the transmitter and securely connect the 1M 3.5mm audio cable to this socket. Then, connect the opposite end of the included 3.5mm audio cable to TV's headphone jack.

B. RCA Audio Out

Check to see if your TV has red and white Audio Out jacks (also called RCA jacks). If so, connect the included RCA to 3.5mm adaptor cable to the RCA Audio Out jacks on your TV. Then connect the included 3.5mm cable to the RCA adapter cable, and plug the other end of the 3.5mm cable into the Audio In jack on the back of the transmitter.

C. Optical output Many new TVs do not have a headphone jack or RCA Audio Out jacks. If this is the case, you must use the optical output on your TV. Plug the included optical fiber cable into this jack on your TV. Then plug the other end into the Optical Fiber input on the back of the transmitter

USE THE HEADPHONE * TV Headphone Mode(wireless headphone mode) 1. Turn on your audio source (e.g. TV set, Hi-Fi system, MP3 or iPod).

> 2. At the rear of transmitter, slide power switch to channel A or B position, and LED indicator steadily 3. Turn on the headphone by pressing and holding

the power button for a couple seconds. After headphone power-on, the LED indicator will steadily glow red.

4. Once the headphone is powered on, it will automatically seek and stay at the working channel. 5. Adjust the volume on the headphones to the desired level.

6. When you are not using the headphone, turn it off.

* Wired Headphone Mode Plug in 3.5mm audio cable to the headphone audio IN, and connect the opposite end to your audio devices, like MP3 or phones; you can then use it as a regular headphone. However, in this mode, you won't be able to adjust the volume by using the

Headphone charging:

You can charge the headphone with a 5V USB power source. When headphone is charging, LED steadily glows blue and turns off when fully charged. Headphone charge: USB 5V Headphone charge time: about 3 hours

Transmitter Specification:

Voltage: DC 5V Work Current: 80mA Modulate: 50Khz Mode: FM Stereo Work Distance: 80 ft.

Headphone Specification:

Voltage: 3.7V(420mAh built-in rechargeable battery) Work Current: 55mA Work Time: about 6 hours Receiving Frequency Response: 60~15000Hz Receiving Sensitivity: better than 8dBuVemf Distortion: <1%

Transmitter *1

WHAT'S IN THE BOX

Headphone*1 AC/DC 5V Adapter*1

RCA to 3.5mm adapter cable *1 1M Audio Cable (both ends with 3.5 mm stereo plug)*

Optical fiber cable*1 Micro-Port USB charger cable*1

User manual*1

1. To achieve best reception, please spread out the power cord 2. If the sound is distorted or too strong, adjust the

etc) to a lower level, reception performance may 3. Put TV on mute or quiet mode, so you can listen

volume of signal source(TV set, DVD player, PC

to TV without disturbing others -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

NOTE: This equipment has been tested and found to

installation. This equipment generates uses and can

radiate radio frequency energy and, if not installed

and used in accordance with the instructions, may

cause harmful interference to radio communications.

However, there is no guarantee that interference will

not occur in a particular installation. If this equipment

comply with the limits for a Class B digital device,

pursuant to part 15 of the FCC Rules. These limits

are designed to provide reasonable protection

against harmful interference in a residential

does cause harmful interference to radio or

turning the equipment off and on, the user is

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment

or more of the following measures:

television reception, which can be determined by

encouraged to try to correct the interference by one

-Consult the dealer or an experienced radio/TV technician for help changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules.

WHAT'S IN THE BOX

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference,

(2) this device must accept any interference

received, including interference that may cause

FCC-ID: 2AO82-YH680

undesired operation.

英语

For any inquires, please contact info@inda-audio.com

Adjustable volume 6. Can also be used as wired headphones

7. All cables included 9. Headphone auto off 10 minutes after no signal is

9. Power Switch/Channel Selector Switch

S/N: >60dB

NOTE