







Inner View of EUT



Antenna Location




Front View of Main Board



Rear View of Main Board



Front View of Battery



Rear View of Battery