# Installation instrutions for helmets with thin edges:



Tick the Velcro and remove the white release paper.



The spare hairy round Velcro is

and pasted on the ear space of

the helmet.

Installation of left horn: spare fur round magic paste and tear the white release paper.





# Applicable to the following helmets:










Helmet

Full Helmet

Cross-Country Helmet

Half Helmet

Applicable to the following Wireless devices








Installation rendering





The spare round Velcro with rough surface can tear off the white release paper, and the horn can be pasted on the right position.





The left and right horn connecting wires are hidden in the interior.

## Product parameters

Wireless version: V5.3

Frequency range: 2.4026GHz - 2.480GHz Transmission distance: above 15-20M

MIC distance: ≤1 meter

Charging time: 3 hours standby Standby time: ≥100 hours Working hours: ≥60 hours

Wireless name: Y50

## Precautions for use of helmet Wireless headset

- 1. In order to protect your eardrum and hearing. do not turn the volume to the maximum.
- 2. Don't listen to music continuously for a long time.
- 3. Try to avoid collision.
- 4. Dust prevention, fire prevention and moisture prevention,
- 5. Remember to fully charge before using when going out.

# **Y50 QUICK INSTRUCTION MANUAL**

## | Product Overview




Important Notice

Before installing the headphones, follow the Quick Manual instructions to connect your phone and listen to the sound and volume. If there is a large difference in sound effect and volume after installing it on the helmet, please adjust the position of the speaker in the helmet.

## Power on/off

Power on default English (Disconnect wireless)



Long press for 3 seconds to turn on



Long press for 3 seconds to turn off




LED flash





LED flash

## Bluetooth pairing



Wireless waiting for pairing status: Blue LED blinking fast



Wireless waiting for pairing status: Blue LED flashes slowly

## Telephone function

Quickly right-turn the knob twice to release it to toggle Select between manual answer and automatic answer (When Wireless is not connected)



automatic

( After 10 seconds)

Press and hold

for 2 seconds





Answer

Refusal to answer

Last-code replay



Manually answer

"short press"




















## **Charging function**



## Music function



Short Press















Pause










Rotate once to switch to the next song

Rotate once to switch

to the previous song

Rotate without letting go Volume increase

## Voice assistant



(Exit by left-turning the rotary button twice again)





Al voice assistant

### List of items

Velcro installation kit\*1

#### Y50 Host\*1 Speaker Microphone\*1



Type-C charging cable\*1







Clip-on base\*1

Instruction manual\*1





#### **Notes**

- 1. Please do not put the product into the open fire to avoid explosion;
- 2. Please do not disassemble the product to avoid damage to the product's electronic devices;
- 3. Please do not close to sharp objects to cause damage to the product;
- 4. long time not used, please place in a dry place;
- 5. Before using the Bluetooth device, please fully charge it;
- 6. If the red light does not come on when charging, it may be the voltage is too low;
- 7.To extend the life of the built-in polymer battery, please charge the device at least once a month.

#### instruction warning

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmfulinterference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmfulinterference to radio communications. However, there is no quarantee that interference wil not occur in a particular installation. ifthis equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment offand on, the user is encouraged totry to correct the interference by one or more of the following measures.

- -Reorient or relocate the receiving antenna
- -Increase the separation between the equipment and rereiver.
- -Connect the equipment into an outlet on a circuit different from that to which thereceiver is
- -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliancecould void the user's authority to operate the equipment. This device complies with Part 15 of the FcC Rules. Operation is subject to the following two conditions.

- (1) this device may not cause harmful interference. and
- (2) this device must accept any interference received, including interference that may cause undesired operation.