Re: Certification for Delco 131 kHz Low Power Transmitter PNs: 16266469, 09352359, 09353715

FCC ID: L2C0003TR

CANADA: to be provided by IC

USER'S MANUAL

Owner's Manual Sample (preliminary): Your vehicle is equipped with the PASS-Key III theft deterrent system. PASS-Key III is a passive theft deterrent system.

This means you don't have to do anything different to arm or disarm the system. It works when you insert or remove the key from the ignition. PASS-Key III uses a radio frequency transponder in the ignition key that matches a decoder in your vehicle.

When the PASS-Key III system senses that someone is using the wrong key, it shuts down the vehicle's starter and fuel systems. For about three minutes, the starter won't work and fuel won't go to the engine. If someone tries to start your vehicle again or uses another key during this time, the vehicle will not start. This discourages someone from randomly trying different keys with different transponders in an attempt to make a match.

If the engine does not start and the PASS KEY light comes on, the key may be damaged. Turn the ignition off, wait about three minutes and try again. The PASS KEY light may remain on during this time. If the starter still won't work, and the key appears undamaged, wait about three minutes and try another ignition key. At this time, you may also want to check the fuse (see "Fuses and Circuit Breakers" in the Index). If the starter won't work with the other key, your vehicle needs service. If your vehicle does start, the first ignition key may be faulty. See your dealer or a locksmith who can service the PASS-Key III. If you accidentally use a key that has a damaged or missing transponder, the starter won't work and the PASS KEY light will come on. But you don't have to wait three minutes before trying another ignition key. See your dealer or a locksmith who can service the PASS-Key III to have a new key made. If you're ever driving and the PASS KEY light comes on and stays on, you will be able to restart your engine if you turn it off. Your PASS-Key III system, however, is not working properly and must be serviced by your dealer. Your vehicle is not protected by the PASS-Key III system. If you lose or damage a PASS-Key III ignition key, see your dealer or a locksmith who can service PASS-Key III to have a new key made.

This device complies with Part 15 of the FCC Rules and with RSS-210 of the Industry Canada. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

EXHIBIT_	_J
Page of	
U of Mich file 41	5031 <u>-93</u> 3