


SIZE:90X112MM

19



ENJOY MUSIC

FAST CHARGE

LIGHTING UP

Product size: 90x112mm

Material: ABS+Aluminum

Normal colors: BLACK, WHITE

Patent No.: 201820202737.3

Accessories: user manual, Adaptor(DC 9V/3A)

Speaker

Bluetooth: V 5.0

Power supply: 5V 500MA

Speaker: 40MM 40 2W

Frequency response: 20Hz-20K Hz

Working range: 10-150M

Desk led lamp

Ra: 95

LED Qty: 8PCS

Power Band: 1W 800MA

Color Temperature: 4000K

LED brightness: 75LM

Wireless charger


Battery supply power directly

5W


10W

9V/3A Adaptor power supply

PRODUCT INTRODUCTION



BUTTONS OPERATION



1. Reading Lamp Control Button, Long Press 2 Seconds for Power on or OFF, press once for brightness adjustment.


2. Wireless Charger Control Button, short press this button to activate Wireless Charger, it will start working and turn off automatically in 5 Seconds. If it does not identify the wireless charger input.

3. Bluetooth "ON/OFF" BUTTON, Long Press 3 second for Power on or OFF, short press this button for "Play/Pause".

4. Track or Volume Buttons, When short press this button: Previous track; long press: Volume down.


5. Track or Volume Button, When short press this button: Next track; long Press: Volume up.

DESK LED READING LAMP




1. There are four brightness options of LED Lamp. Long press the lamp control button to turn on the Reading Lamp, then adjust the brightness by rotating the lamp head. 2. Press the lamp control button to turn off the Reading Lamp.

WIRELESS CHARGER




1. Place your phone on the wireless charger, and put the short phone on the top of the wireless charging panel. 2. Press the wireless charger control button to start charging. 3. Press the wireless charger control button to stop charging.

BLUETOOTH SPEAKER



1. Pressing. Start playing automatically once you long press a speaker of speaker not off. 2. Pressing. Start playing automatically once you long press a speaker of speaker not off. 3. Pressing. Start playing automatically once you long press a speaker of speaker not off.

SAFETY INFORMATION



1. Do not use the device near water. 2. Do not use the device near fire. 3. Do not use the device near children.

WARRANTY



1. The device is covered by a 1-year warranty. 2. The warranty is void if the device is damaged by fire, water, or other external factors.

PDF
A688

