




Model: TT-BH095 TaoTronics SoundLiberty 95 True Wireless Stereo Earbuds **User Guide**

Package Contents



- 1 TaoTronics True Wireless Stereo Earbuds (TT-BH095)
- 2 1 x USB-C Charging Cable

3 1 x User Guide

- 4 1 x Quick Start Guide

4 Microphone ⑤ LED Indicator

② Multifunction Touch Control

① Microphone

3 Charging Contacts

10 Reset Button

Product Diagram




- 6 Charging Slot

- ① Charging Indicator
- ® USB-C Charging Por
- Oharging Case

Important Safety Instructions

 Do not expose this product to high temperatures. Please read the instructions thoroughly before using this product and retain it for · Do not clean the product with detergent containing alcohol, ammonia, benzene or abrasives. Avoid dropping.



This product contains lithium battery. Never expose it to excessive heat such as direct sunlight or fire to avoid explosion.

cause fire hazard, warranty voidance, and/or property loss.

Keep the charging case away from water, rain or any other liquid.

• Don't use the product in thunderstorm to avoid malfunction or electric shock.

Always ask a professional technician or authorized personnel for repair.

Close attention is needed when using near children.

Wear Your Earbuds

- Charging Please wear the earbuds as shown below. • Do not immerse the earbuds into water or expose them to humidity for a
- Place the earbuds back into the charging case when not in use and keep it away from children and pets to avoid choking hazard.
- Unauthorized disassembly of any parts of this product is forbidden, which may
 - Pictures only for reference.

Bluetooth Caution

 When the device is connected wirelessly to another device, place the two devices close to each other to achieve their normal

functionalities and avoid possible signal interference.

• The maximum effective Bluetooth range may vary with the

fences may shorten the effective range.

environmental circumstances.

- When using a wireless connection, make sure there are no obstacles between the two devices. Obstacles including walls and

Using Your Earbuds


1. Put the earbuds into the charging case as per the L (left) and R (right) marks. for a long time.

2. Cover the lid and charging will start automatically.

(if you are wearing the earbuds). Please charge in time or the

earbuds will turn off automatically around 10 minutes later.

Charge the earbuds at least once every 3 months when not using




 Unplug the charging cable (timely) when fully charged. • Please fully charge the earbuds when using them for the first time. • When battery is low, a "Battery low" voice prompt will be heard

Charging the Earbuds

Charging the Charging Case


1. Connect the charging port with any USB charging adapter or active computer USB port.

2. The charging indicator will stay solid white, and turn off once fully charged.



Power On

Uncover the lid and they will power on automatically.



Power Off

Put the earbuds into the charging case and close the lid, they will turn



- automatically. The LED indicator on the charging case will flash blue and white alternately indicating the earbuds are in pairing mode now.
- Find "TAOTRONICS SoundLiberty 95 L" in the searching results, tap on the name to connect.
- 3. Once connected, the LED indicator on the charging case will flash blue slowly.

- will attempt to pair with the last connected device for the first 20 seconds. If re-pairing failed in 20 seconds, the earbuds will enter pairing mode.
- necessary, please keep the two earbuds close to each other in couple

• The earbuds can remember the devices paired previously, and



Pairing


• You can use one earbud or both earbuds as per your preference. Please refer to the corresponding pairing instructions.


> • Before pairing, please turn off other Bluetooth devices and place the device to be connected close to the earbuds.

they will turn off automatically.

• When the earbuds are disconnected from your device for more than 10 minutes,











• It is not recommended to wear the two earbuds on different people. If

earbuds mode.



FCC ID: 2AVUHTT-BH095

support@taotronics.com

MANUFACTURER

Manufacturer: Shenzhen NearbyExpress Technology Development Co.,Lt Address: Floor 7, Building E, Galaxy World Phase II, Shenzhen, China

https://www.taotronics.com/pages/user-manual



Single Earbud Mode

Pair both earbuds with your device in Couple Earbuds Mode before using in Sinale Earbud Mode.

Use Primary (Left) Earbud Only

- 1. Take out the primary (left) earbud from the charging case, and make sure the
- re-pairing failed in 20 seconds, the earbud will enter pairing mode with voice

3. Turn on the Bluetooth function on your device and search for the nearby devices. Find "TAOTRONICS SoundLiberty 95 R" in the searching results, tap on



the name to connect.

10 seconds.

Manually Pairing

Place both earbuds back in the charaina case with the lid uncovered.

2. Press and hold the **Reset Button** for 3 seconds to disconnect the currently

- secondary (right) earbud is placed in the charging case and the lid is covered
- 2. It will try to pair with the last connected device for the first 20 seconds. If prompt "Pairing" every 10 seconds.
- devices. Find "TAOTRONICS SoundLiberty 95 L" in the searching results, tap on
- the primary (left) earbud is placed in the charging case and the lid is covered.
- the name to connect.

Learn more about the EU Declaration of Conformit

3. The earbuds will enter pairing mode with the LED indicator on the charging case flashing blue and white alternately.

4. Pair with your new Bluetooth® device as instructed in "Pairing" section.

The pairing history will not be cleared under this operation. 3. Turn on the Bluetooth function on your device and search for the nearby

Use Secondary (Right) Earbud Only

- 1. Take out the secondary (right) earbud from the charging case, and make sure
- 2. The secondary earbud will enter pairing mode with voice prompt "Pairing" every

If you want to change to couple mode, simply take out the other

- as instructed below:
- 1. Place both earbuds back in the charging case with the lid uncovered.
- charging case flash blue and white alternately.

Clear Pairing List

If you failed to pair your device with the earbuds, please clear the pairing history

- Only available in Couple Earbuds Mode:

instructed above if pairing failed.

already paired them with a device deactivate the Bluetooth function on the paired device or clear "TAOTRONICS SoundLiberty 95 L" from Answer via earbuds: its Bluetooth list. Restore the earbuds to factory settings as Tap the Touch Control on either of

Operation and Functions

earbud twice under music

Answer via mobile phone:

Tap Answer on the mobile phone

Tap the Touch Control on either of the

Tap the Touch Control on either of the

earbuds three times

- 2. Press and hold the **Reset Button** for 8 seconds until the LED indicator on the
- Tap the Touch Control on the right 3. If you have paired your device with the earbuds before, remove
 - "TAOTRONICS SoundLiberty 95 L" from the Bluetooth device list and pair again.

4. Re-pair with your Bluetooth® device as instructed in "Pairing" section. Tap the Touch Control on the

right earbud three times

Tap the Touch Control on the If you want to pair the earbuds with another device when you have

Bluetooth out of Range / Failed to Disconnected

Only when you are wearing the earbuds can you hear the voice prompt.

· Couple Earbuds Mode:

Tap the Touch Control on the left

earbud twice until a beep is heard

Tap the touch control on either of the

earbuds twice until a beep is hear

Refer to the "Clear Pairing List"

Cleaning and Maintenance

1. Clean the earbuds and the charging case on a regular basis.

4. Put the unit in a dry and shady place if it is to be idle for a long time.

2. Use dry and soft cotton cloth to wipe the unit.

3. Keep away from sharp objects to avoid scratches.

5. Do not clean the product with detergent or chemicals.

Note: Do not insert anything into the product.

Failed to pair the

No. Problem

Failed to turn on the

Failed to charge th

Bring the earbuds into pairing mode as instructed in the "Pairing" section

arbuds low battery, please charge them

Place the earbuds into the charging

Make sure the charging cable is intact

The earbuds reconnected with previously

Deactivate the Bluetooth function of

'TAOTRONICS SoundLiberty 95 L" from its

Bluetooth device list, and then search again

Put the device to be connected close to

urn on the device and activate its

previously paired device or clear

• Make sure the charging case is

and plugged in properly

paired device automatically:

Multifunction Touch Bluetooth function before pairing 11 | control of the earbuds

Bluetooth connection. Uncover the lid to turn on the earbuds and pair again.

Place both earbuds back to the chargi

No sound in one of the

earbuds in couple

Poor sound quality

8 Unstable connection

Can't hear the other

party during a phone ca

The other party can't

hear your voice during

a phone call

earbuds mode

case then take them out, they will pair

with each other automatically. If pairing

· Wear the earbuds properly and keep

Place the connected device close to tl

· Keep the earbuds close to your Bluetooth

The effective distance may shorten w

Turn off other Bluetooth devices to

Free the built-in microphone of any

case and cover the lid, disconnect the

ice the two earbuds into the charging

decrease the interference

Set the volume to higher level

earbuds or remove the obstacles

Clear the debris on the earhuds

them close to each other.

obstacles in the way

List" section

failed, restore them back to the factory

settings as instructed in the "Clear Pairing

Warranty and Service

If any problems occur, please contact the TaoTronics Customer Care Centre via the contact information listed in this User Guide.

compliance could void the user's authority to operate the equipment This device complies with Part 15 of the FCC Rules. Operation is subject to the

- Bluetooth (1) this device may not cause harmful interference, and
- Bluetooth SIG. Inc. and any use of such marks by Sunvalleytek International Inc. is under license. Other trademarks and trade names are those of their respective owners.



Class B digital device, pursuant to part 15 of the FCC Rules. These limits are Correct Disposal of This Product (Waste Electrical & Electronic Equipment) designed to provide reasonable protection against harmful interference in (Applicable in countries with separate collection systems)

residential installation. This equipment generates uses and can radiate radi frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. How waste at the end of their working life. To prevent possible harm to the there is no guarantee that interference will not occur in a particular installation environment or human health from uncontrolled waste disposal, please separate If this equipment does cause harmful interference to radio or television these items from other types of waste and recycle them responsibly to promote

reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and receiver.

· Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for

- Connect the equipment into an outlet on a circuit different from that to which

following two conditions:

(2) this device must accept any interference received, including interference

the receiver is connected.

The Bluetooth® word mark and logos are registered trademarks owned by the that may cause undesired operation.





This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household

tally safe recycling. Business users should contact their supplier and check the

terms and conditions of the purchase contract. This product and its electronic

accessories should not be mixed with other commercial wastes for disposal.

the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmen-

- Reorient or relocate the receiving antenna.

