

Overview



Quick Start Manual

Key	Introduction
Power key	Long press the power key and the device will power on. If the phone is in sleep mode, long press the power key to wake up the phone. If the phone is in power-off mode, long press the power key to turn on the phone.
Volume key	Long press the volume key to adjust the volume or press the power key to enter the power-off mode.
USB Port	Data cable jack, OTG cable jack
Associate MIC	Make all-in-one
Touch Screen	Make all-in-one

SIM card/Micro SD card installation and removal, the back cover lock and unlock

The device SIM card slot is only fit for the standard Micro SIM. Single SIM card supports 4G separately. As for dual SIM card, SIM 1 supports 4G, SIM 2 only supports GSM. SIM 2 supports 4G, SIM 1 only supports GSM.

Note: Use of other sized SIM cards will void warranty.
Please follow the steps mentioned below to install the memory card in the device:
1. Power off the phone
2. Open the screw lock according to the picture direction
3. Insert the SIM and SD card according to the picture
4. Put back the back cover and lock the screw
Warning: Please make sure the battery cover of mobile phones, battery cover screw lock, headphones and USB plug all rubber cover are tightly closed, in order to have perfect dustproof and waterproof effect. Be sure to close the back cover (specific reference in front of the battery back cover installation method).

Note:
To avoid damage to your phone or loss of data, make sure that the phone has been turned off, and there is no power or phone connector before installing or removing the SIM card or Micro SD card.
After installation is complete, be sure to tightly cover the battery. Tighten the Battery cover screw lock, to avoid water damage or dirt from entering the mobile phone.
Please try to use the phone's original data cable and adapter, or RugGear's approved data cable for the phone to charge.

Tips: Insert / Remove the memory card.
To store additional multimedia information, you must insert a memory card. The device can only accept up to 64GB Micro SD memory card. Please make sure to remove the memory card in safe circumstances.
1. In standby mode, open the application list, And then select Settings → Storage → unmount SD → OK
2. Remove the memory card

Waterproof and dustproof

Your device has been tested waterproof and dustproof.
Please note that compliance with waterproof and dustproof requirements, does not mean that your device will not be damaged by water under any conditions.

Caution: Please make sure the battery cover of mobile phones, battery cover screw lock, headphones and USB plug all rubber cover are tightly closed, in order to have perfect dustproof and waterproof effect. Be sure to close the back cover (specific reference in front of the battery back cover installation method).

To be waterproof and dustproof, please follow below step

1. Please make sure the back cover screw lock, headphones and USB plug all rubber cover are tightly closed, in order to have perfect dustproof and waterproof effect. Be sure to close the back cover (specific reference in front of the battery back cover installation method).
2. Do not immerse the phone in water. There is no harmful effect if the device is water sprayed strongly in all directions.
3. Do not expose your phone in the water dynamics such as waves or waterfalls.
4. Do not expose the equipment to salt water, ionized water or soapy water.
5. Do not use the phone in the spa or hot water because waterproof rubber is easily affected by high temperature.
6. Please do not use wet hands to open the battery cover. When open it, you must put

the cover down in case water goes into the cover slot.
7. Do not immerse the phone in water or in extremely wet conditions when opening the back cover, (such as swimming or shower).
8. Do not open the battery cover while the body is not completely dry.
9. Do not use detergent cleaning products and other chemicals.

10. Rubber seal stoppers in the battery cover are an important part of the device. Please be careful to avoid damaging it when you open or close the battery cover. Also, make sure there is no debris, such as sand or dust on the rubber seal.
11. If the device is dropped or subjected to impact, the battery cover and multifunction jack cover may be loose. Ensure that all covers are properly aligned and tightly closed.
12. Under certain conditions, such as high volume levels, it may be slightly vibrated. It is normal due to waterproof design and does not affect the performance.

13. If you accidentally drop your phone in the quagmire, do not worry, just flush it with clean water and dry it.
14. If you accidentally drop your phone on the beach, do not worry, just flush it with clean water and dry it.
15. If the device is immersed in water or wet microphone or speaker, during a call, the other party may not be able to hear your voice, so wipe with a dry cloth to make sure the microphone or speakers are clean and dry. Hair dryer is not permitted.

16. If water droplets are found on the screen, it may affect the perception of the touch screen resulting in errors. Recommend to continue to use the phone after drying the water droplets.

Using reset key

Because this phone has built-in battery, if the phone cannot be turned off owing to crash fault, you can long press the reset button for 14 seconds to reset, so as to restart the phone on normal standby. Abnormal operating this button may result in loss of some unsaved data, please use the reset key with great caution.

Gloves mode

Please check "Settings" → "Display" → "gloves mode selector". You can also use the touch screen while wearing gloves. Please make the fingers of gloves touch the phone's screen. The touch screen support wet hand operation, too.

Charging the battery

The first time you use your phone, please run out of power first, and then charge the battery until it is fully charged.

When the battery is low, the device will emit a warning tone and a low battery message prompts. The battery icon will appear blank. If the battery is too low, the phone will automatically shut down. Need to charge the battery in order to continue to use the phone.

Charging Travel Charger

1. Please open waterproof rubber plug according to the following right direction, before inserting the headset or data cable.

2. The Voltage Instability will lead to the touch screen not in good working condition. The phone becomes warm while charging. It is normal, does not affect the service life or performance of the phone.



To save power, unplug the device when not in use travel charger.

NOTICE:
This device complies with Part 15 of the FCC Rules (and with Industry Canada licence-exempt RSS standard(s)). Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.
L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Changes or modifications made to this equipment not expressly approved by (manufacturer name) may void the FCC authorization to operate this equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

折页示意图:



uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

This Mobile Phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC/ISED RF Exposure Information and Statement:

The SAR limit of FCC (ISED) is 1.6 W/kg averaged over one gram of tissue. Device types: TD-LTE digital mobile phone (FCC ID: LER-R730) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.910W/kg and when properly worn on the

Wireless charging devices

The device wireless charging function uses energy-saving control technology, and comprehensive identification of emission control technology, all functions by emitting part is completed. Before using the wireless charger function read all safety precautions and this manual carefully to ensure safety and proper use.

Extend battery life

1. This mobile phone built-in Qi standard wireless charging receiver. This phone only supports Qi Standard wireless charger.
2. Do not expose the wireless charger to rain or water.
3. Do not disassemble, modify or repair phone by yourself.
4. Do not store the device in water heaters, microwave ovens, hot cooking equipment or near the high pressure vessel.

Wireless charging photo:

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Extend battery life

1. This mobile phone built-in Qi standard wireless charging receiver. This phone only supports Qi Standard wireless charger.
2. Do not expose the wireless charger to rain or water.
3. Do not disassemble, modify or repair phone by yourself.
4. Do not store the device in water heaters, microwave ovens, hot cooking equipment or near the high pressure vessel.

Wireless charging photo:

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

折页示意图:



Specific Absorption Rate (SAR) information:

This Mobile Phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC/ISED RF Exposure Information and Statement:

The SAR limit of FCC (ISED) is 1.6 W/kg averaged over one gram of tissue. Device types: TD-LTE digital mobile phone (FCC ID: LER-R730) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.910W/kg and when properly worn on the

Wireless charging devices

The device wireless charging function uses energy-saving control technology, and comprehensive identification of emission control technology, all functions by emitting part is completed. Before using the wireless charger function read all safety precautions and this manual carefully to ensure safety and proper use.

Extend battery life

1. This mobile phone built-in Qi standard wireless charging receiver. This phone only supports Qi Standard wireless charger.
2. Do not expose the wireless charger to rain or water.
3. Do not disassemble, modify or repair phone by yourself.
4. Do not store the device in water heaters, microwave ovens, hot cooking equipment or near the high pressure vessel.

Wireless charging photo:

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.

Safety Information

16 protect yourself and others from harm, please read all of the following information before using your mobile phone.
Please use RugGear original profession adapters, chargers, accessories and similar accessories that do not satisfy these requirements may not comply with FCC/RF exposure requirements, and should be avoided.

1. When not using Bluetooth, Wi-Fi or GPS, please close these wireless communication function;
2. Lowering the phone screen brightness and setting a shorter sleep time can save power. You can press the power button to turn off the screen when not using the device;
3. Closing Email, calendar and contacts, and other applications of automatic synchronization; Long pressing the HOME main menu button, selecting the icon and dragging left or right to slide to disappear;
4. Your installation and use of some of the applications may shorten battery life, please exit used applications or long press the menu button to view the used application list and slide left/right to exit.