

For more support information





TECHNICAL SPECIFICATIONS

| Transmit frequency | Baby unit: 2402 - 2480 MHz (cover all WiFi, FHSS, BLE) |
|-------------------------|---|
| | Max Transmit power is 10mW (cover all WiFi, FHSS, BLE) |
| | Parent unit: 2406 - 2475 Mhz Max Transmit power is 100mW |
| LCD | 5" Color LCD (IPS 1280x720 pixels) |
| Nominal effective range | Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use. |
| Power requirement | Baby unit power adapter: Output: 5V DC, 1.5A Parent unit power adapter: Output: 5V DC, 2A Parent unit battery: 3.7V 5000mAh, 18.5Wh Lithium-ion battery |

Android $^{™}$ and Google Play $^{™}$ are trademarks of Google Inc. App Store is a trademark of Apple Inc., registered in the U.S. and other countries

IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

RM5887HD



1. Follow all warnings and instructions marked on the product.

- CAUTION: Do not install the baby unit at a height above 6.5
- feet (2 meters). 4. This product is intended as an aid. It is not a substitute for responsible and proper adult supervision and should not be

used as such.

- 5. This product is not intended for use as a medical monitor. 6. Do not use this product near water, for example, near to a bath, sink, swimming pool or shower.
- CAUTION: Use only the internally, non-user replaceable battery fitted to the parent unit. There may be a risk of explosion if a wrong type of battery is used for the parent unit. The battery cannot be subjected to high or low extreme temperature and low air pressure at high altitude during use, storage or transportation. Disposal of batteries in fire or a hot oven, mechanically crushing or cutting the battery can result in an explosion. Subjecting products or batteries to an extremely high temperture environment can result in explosion or leakage of flammable liquids, or gas. Products or batteries subjected to extremely low air pressures may result in explosion or leakage of flammable liquids, or gas. Dispose of used batteries according to the information in **The RBRC seal**.
- 8. Use only the power adapters supplied with this product. Incorrect power adapter polarity or voltage can seriously

Power adapter information:
Baby Unit Output: 5V DC 1.5A
VTech Telecommunications Ltd.
Model: VT07EUS05150 Parent Unit Output: 5V DC 2A VTech Telecommunications Ltd. Model: VT07EUS05200

Rechargeable battery information: 3.7V 5000mAh, 18.5Wh Lithium-ion battery Zhuhai Great Power Energy Co., Ltd. Model: GSP806090-5Ah-3.7V-1S1P

- 9. The power adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under the-table or cabinet outlet.
- 10. For pluggable equipment, the socket-outlet (power adapter should be installed near the equipment and should be easily 11. Unplug this product from the wall outlet before cleaning.
- o not use liquid or aerosol cleaners. Use a damp cloth for 12. Do not modify the power adapters or replace with other third-
- party adapters 13. Do not allow anything to rest on the power cords. Do not install this product where the cords may be walked on or
- 14. The product should only be operated from a power source indicated on the power adapter label or marking. If you are unsure of the type of power supply in your home, consult you dealer or electricity supply provider
- 15. Do not overload wall outlets or use an extension cord. 16. Do not place this product on an unstable table, shelf, stand or
- 17. This product should not be placed in any area where prope ventilation is not provided. Any slots or openings in the back or bottom of this product are provided for ventilation. To protect from overheating, openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat source.

18. Never insert any objects through any aperatures or slots in the product as this can be dangerous and cause damage to the battery or other internal parts. Never spill any liquids on the

19. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility.

Disassembling or removing parts of the product other than battery replacement via a battery door (if applicable) may expose dangerous voltages or other risks.

20. You should test the sound reception every time you turn on the units or move one of the components

Periodically examine all components for damage. 22. There is a very low risk of privacy loss when using certain electronic devices, such as baby monitors, cordless releasements devices, such as party monitors, cordiess telephones, etc. To protect your privacy, make sure the product has never been used before purchase, reset the baby monitor periodically by powering off and then powering on the units, and power off the baby monitor if you are not intending to use if for some time.

23. Children should be supervised to ensure that they do not play

24. The small parts of this monitor can be swallowed by babies or small children. Keep these parts out of reach of children. The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

SAVE THESE INSTRUCTIONS

Use and store the product at a temperature between 32°F (0°C) and 104°F (40°C).

- Mishandling batteries can cause burn, fire or explosion Batteries should not be exposed to excessive heat such as
- bright sunshine or fire. Do not expose the product to extreme cold, heat or direct
- unlight. Do not place the product close to a heating source Warning–Strangulation Hazard–Children have STRANGLED in cords. Keep this cord out of

the reach of children (more than 3 ft (0.9m) away). Do not remove warning label on the adapter cord.

Never place the baby unit(s) inside the baby's crib or playpen. Never cover the baby unit(s) or parent unit with anything such as a towel or a blanket. Other electronic products can cause interference to your parent unit and baby unit. Try installing your baby unit as far away as possible from the following electronic devices:

wireless routers, radios, mobile telephones, intercoms, roon monitors, televisions, personal computers, kitchen appliances (e.g. microwave ovens) and cordless telephones. Precautions for users of implanted cardiac pacemakers Cardiac pacemakers (applies only to digital cordless device Wireless Technology Research, LLC (WTR), an independent esearch entity, led a multidisciplinary evaluation of the interference between portable wireless devices and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicians that:


Pacemaker patients Should keep wireless devices at least six inches from the

Should NOT place wireless devices directly over the pacemaker, such as in a breast pocket, when it is turned ON. WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless devices.


Electromagnetic fields (EMF) This VTech product complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user's manual, the product is safe to be

sed based on scientific evidence available today

WHAT'S IN THE BOX



For mobile access: MyVTech Baby Plus mobile app Wi-Fi Network Wi-Fi router 2.4GHz 802.11 b/g/n 1.5 Mbps @ 720p or 2.5 Mbps @1080p upload Internet connection bandwidth per baby unit



DOWNLOAD APP FOR MOBILE ACCESS

Use the MyVTech Baby Plus on your mobile device to monitor your baby remotely. Follow the instructions below to set up and pair your baby monitor with the app.



Scan the QR code to download the free MyVTech Baby Plus mobile app, or search "MyVTech Baby Plus" on App Store or Google Play Store. If you have previously installed the app, ensure that you have the latest version.

> • Make sure your mobile device meets the minimum requirement for the mobile app.


Minimum requirement

□ Note

The mobile app is compatible with:

- Android[™] 9.0 or later (Not compatible with mobile devices with a 32-bit Android operating system); and
- iOS 14 or later.





- We recommend that you use common webmail services, such as Google Gmail, to register your user account. Check your email (including the Spam folder) and activate your new account by entering the email verification code. Then, sign in to your account.
- Ensure that you are connected to a 2.4GHz Wi-Fi network and have enabled Bluetooth and **Location Service** on your device. After signing in to the app, select **Camera(s) with Parent unit** and scan the QR code
- displayed on the parent unit. To find the QR code, press the MENU/SELECT button and go to Connect to Mobile App.
- Input the Wi-Fi password.
- Press and hold the pair key on the baby unit for 3 seconds until you hear the beep sound to enter pairing mode.
- 8. Select the camera model that appears in the app and wait for the camera to connect. Once connected, it will display a live view preview.
- Select "Continue" and create a profile for your baby (Optional). Now you can start

兴 TIP

Parent unit overview

LINK LED light

baby unit.

LED light

is lost.

Use **Camera Sharing** to instantly share access to the camera. Follow these steps:

- Go to Menu and select Camera Sharing.
- 2. Choose "Invite People" and enter the name and email address of the family member's app
- The family member will receive a pop-up notification in the app and can accept the invitation to access the camera(s).


!\ Caution:

INSTALL THE WALL MOUNT


 $\frac{1}{2}$ $\frac{1}{2}$ TIP: You can also install your monitor when your crib is away from a wall with the

OTC-Floorstand, available separately for purchase. This versatile floor stand

allows you to effortlessly locate your camera without securing to a wall.



from the opening of the Second Extension and is ready for connection.




2. Insert the Second Extension (B) onto the Wall Mount Cover (D), ensuring that the slot is correctly aligned.


Scan QR code to

watch wall mount


installation video.




Cover (D) until it emerges from the opening of the Second Extension (B).



4. Insert the Extension Cable plug into the DC socket, then secure the cable with the




Measure to correctly locate the Wall Mount and mark the 3 mounting holes for the Drill three holes in the wall using a 7/32 inch (5.5mm) drill bit.




Center of the crib (long side)

holes, then insert the screws (H) into the anchors. Tighten the screws until only 1/4 inch (6.5mm) of the screws are exposed. Then, attach the Wall Mount Bracket (E) onto




screws and gently slide

downwards.




7. Place the Wall Mount Cover (D) on the Wall

mount bracket (E), and then slide downwards



8. Install the Cable Covers (F) to prevent baby

from touching the cable.



Baby unit overview

End Cable Cover

OVERVIEW

Wall Mount screws

(inside bag with label)

and anchors

Light sensor Camera lens Microphone Infrared LEDs Allow you to see clearly in a dark environment.

Speaker

LED indicator Set to off by default. You can turn it on using the app (Setting > Camera Setting > LED status). In direct mode:

Cable Cover screws

(inside bag with label)


and anchors

- · Orange is steadily on when the baby unit is connecting to the parent unit.
- · Orange flashes slowly during video streaming.
- In Wi-Fi mode: Green is steadily on when the baby unit is connected to Wi-Fi.
- Green flashes slowly during video streaming to Wi-Fi.

ON/OFF switch Power it on or off.

Night light

Link



- **PAIR** key until you hear a beep sound. Release the PAIR key, then short press the **PAIR** key five more times until you hear another beep sound. The baby unit will emit one final beep when the reset is complete. After the beep sound, the baby unit will reboot itself.
- 10 O- Night light switch

11 Power connector

· Press to turn the night light on or off.

· Green and amber lights: moderate sound level. · Green, amber, and red lights: high

· On when the parent unit is linked to the

· Flashes when the link to the baby unit

• On when the parent unit is connected to

AC power, and the battery is charging.

The lights indicate different sound levels 9

Flashes when the parent unit battery is

low and needs to be charged.

3 3- level sound indicator light

detected from the baby unit.

· Green light: low sound level.

sound level. 4 TALK / **→**

Press and hold to talk to the baby unit.

 Ψ is displayed on screen while the button is pressed.

• While in a sub-menu, press to exit.

Press to enter the main menu.

selection, or save a setting.

While in a menu, press to confirm a

MENU | SELECT

14 RESET

 Press to zoom in/out to different levels. (1) (2) (4) (8)

⟨|**∧**|**⟩**|**∨** Arrow keys

up and down.

Microphone

VOL - | VOL +

 \oplus Zoom

unit volume.

Press to navigate leftward, upward,

main menu and sub-menus.

to move the viewed image le

rightward or downward, within the

· While viewing a zoomed image, press

Increase, decrease or mute the parent

10 U Power | LCD ON/OFF • Press and hold to turn on/off the power.

• Press to turn on/off the LCD screen.

Speake 13 Power jack

Force reboot the parent unit.

11 Antenna