

FCC ID: 2ASWH-QPE
Model No.: T13187
IC: 29260-QPE
Thank you for purchasing the TOZO authentic product.
For more latest products, parts and accessories,
please visit: www.tozostore.com
For any assistance please contact Email: info@tozostore.com

FC RoHS CE    

Open Buds
WIRELESS HEADPHONES

User Manual

English
03 - 10

日本語
11 - 18

Deutsche
19 - 26

Français
27 - 34

Italiano
35 - 42

Español
43 - 50

1.0 Thanks for purchasing


The earphone provides you with the extraordinary experience of stable voice call and peaceful music sound in noisy surrounding with fashionable appearance and multiple functions, making them a great choice for you while working going out and driving.

2.0 Specifications

Speaker Size: Ø 14.2mm
Charging Time: <2H
FR Range: 20KHz-20KHz
Impedance: 16Ω ± 15%
Transmission Range: >10M

Earphone Battery Capacity: 70mAh
Charging Case Battery Capacity: 650mAh
Charging Parameters: 5V=1A
Product Size And Weight: 93*58*28mm; 78g

3.0 Product list




4.0 Power on/off

- Power on:**
1. The earphones are in the charging case, and opening the charging case will power on the earphones.
 2. With the earphones outside the charging case (in the off state), touch the left and right earphones respectively for 3 seconds to turn them on, and they can also be used individually.


Power off:

1. Place the left and right earphones into the charging case and close the charging case lid to power off the earphones.
2. With the earphones outside the charging case (in the on state), touch the left and right earphones respectively for 3 seconds to turn them off. When the left and right earphones are connected to each other, if you touch either earphone to turn off the power, both the left and right earphones will turn off.



5.0 Wearing

1. The earphone ear hook can rotate forward and backward, as well as left and right. The touch area is shown in the picture.



2. Adjust the curved part of the rotating earphone to adjust forward, backward, left, and right. Then wear it on the left and right ears respectively, and adjust the earphone's sound outlet to align with the ear canal, as shown in the picture.


6.0 Bluetooth connection

1. Connection inside the charging case: Open the charging case and the red and white signal lights will flash alternately. Search for the signal [TOZO Open Buds] and connect to it.
2. Connection outside the charging case: Touch the left and right earphones for 3 seconds to turn them on, and then search for the signal [TOZO Open Buds] to connect to it. You can also choose to connect only one earphone for use.
3. After a successful connection, the signal light on the earphones will go off.




7.0 Reset


When the earphones are placed in the charging case, press and hold the charging case button for 8 seconds to clear the Bluetooth pairing records and restore the factory settings.




8.0 Music control



9.0 Calling control




10.0 Voice assistant



11.0 Bluetooth multipoint feature


1. With the earphones turned on, put them in pairing mode and connect them to the first phone via Bluetooth.
2. Turn off Bluetooth on the first phone and put the earphones back in pairing, connect the earphones to the second phone via Bluetooth.
3. Turn on Bluetooth on the first phone and search for the earphones in the list of paired devices. Click on the earphones to connect to both phones simultaneously.



07

12.0 Charging methods

1. Earphone charging: Simply place the earphones into the charging case to charge them.
2. Charging case charging: It is recommended to use a 5V output charger to charge the charging case. Insert the Type-C charging cable into the charging port of the charging case to charge it.



13.0 TOZO APP

- Download the TOZO App for UI customization, EQ settings and more.
- UI customization: Most of the controls can be customized in the App.
- EQ settings: There're lots of EQ settings you can choose in the App to optimize your experience while enjoying different music genres.
- Earbuds firmware update: The earbuds firmware can be updated in the App. You will be informed once the new version of firmware is detected when you connect the earbuds with the App.



14.0 TOZO APP pairing

- Step 1:**
Download the TOZO App on your phone.




08

- Step 2:**
Bluetooth pairing with your earphone.



- Step 3:**
TOZO App pairing with your earphone.



15.0 Troubleshooting and reminders

1. Cannot turn on/trying to charge the earphones and charging case, check whether the charging case's red light is on before attempting to turn them on.
2. Water damage: Do not charge the product, and immediately turn it off, wipe off any surface water to let it dry, and then try to use it again.

09

3. Playback or connection issues: Put the earphones in the charging case, press and hold the charging case button for 10 seconds to restore factory settings, and then try to use them again.
4. Unable to connect to phone: Make sure Bluetooth is turned on, delete the pairing, turn on the earphones, and search for the earphones' Bluetooth signal to connect. If it still does not work, try restoring factory settings.
5. No sound: Ensure that Bluetooth is connected and try increasing the earphone volume.
6. Unable to charge: Try using a different 5V power adapter to charge or replace the charging cable to see if it solves the problem.
7. If the problem persists: Please contact TOZO customer service.

• FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications; however, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference and (2) this device must accept and interference received including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
Caution:
Radio Bandwidth Specification: RSS-Gen, Issue 5
• English:
This device contains a radio transmitter and receiver that comply with Innovation, Science and Economic Development Canada's license-exempt RSS (S). Operation is subject to the following two conditions:
This device may not cause harmful interference.
This device must accept any interference, including interference that may cause undesired operation of the device.
RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

• French:
Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (S) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:
Cet appareil ne doit pas causer d'interférences.
Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.
Déclaration d'exposition RF:
L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

10

1.0 お買い上げありがとうございます


このイヤホンは、ファッションナな外観と多機能性を備え、静かしい環境でも安定した音声通話と平穏な音楽サウンドという非日常体験を提供します。外出や通勤の際に最適です。

2.0 仕様

スピーカー サイズ: 14.2mm
充電電圧: 5V
FR 帯域: 20Hz-20kHz
インピーダンス: 16Ω ± 15%
伝送距離: ≥10M

イヤホンバッテリー容量: 70mAh
充電ケースのバッテリー容量: 650mAh
充電/充電電圧: 5V=1A
製品のサイズと重量: 93*58*28mm; 78g

3.0 製品一覧



4.0 電源オン/電源オフ

電源オン:
1. イヤホンは充電ケースに入っています。充電ケースを開くとイヤホンの電源が入ります。
2. イヤホンを充電ケースから出した状態（オフ状態）で、右側のイヤホンをそれぞれ3秒間タッチすると電源がオンになり、個別に使用することもできます。


電源を切る:

1. 左右のイヤホンを充電ケースに入れ、充電ケースのふたを閉めてイヤホンの電源を切ります。
2. イヤホンを充電ケースから取り出した状態（オンの状態）で、左右のイヤホンをそれぞれ3秒間タッチしてオフにします。左右のイヤホンを接続した状態で、どちらかのイヤホンをタッチして電源を切ると、左右両方のイヤホンの電源が切れます。



5.0 着用

1. イヤホンのイヤーフックは前後左右に回転できます。タッチエリアは写真に示されています。



6.0 ブルートゥース接続

1. 充電ケース内での接続: 充電ケースを開くと赤と白のLEDライトが交互に点滅します。携帯 [TOZO Open Buds] を検索して接続します。
2. 充電ケース外での接続: 左右のイヤホンを3秒間タッチして電源を入れ、[TOZO Open Buds] のLEDライトが点滅します。イヤホンを1つだけ接続して使用することもできます。
3. 接続が成功すると、イヤホンのLEDライトが点滅します。




7.0 リセット

イヤホンを充電ケースに入れたら、充電ケースのボタンを8秒間押し続けると、Bluetoothペアリングの記録が削除され、工場出荷時の設定が復元されます。




8.0 音楽コントロール



9.0 呼び出し制御




10.0 音声アシスタント




11.0 Bluetoothマルチポイント機能

1. イヤホンの電源を入れた状態で、ペアリングモードにし、Bluetooth経由で最初の電話に接続します。
2. 1台目の電話のBluetoothをオフにして、イヤホンをペアリングに返し、イヤホンと2台目の電話にBluetooth経由で接続します。
3. 最初の電話でBluetoothをオンにし、ペアリングされたデバイスのリストでイヤホンを検索します。両方の電話に同時に接続するには、イヤホンをクリックします。



12.0 充電方法

1. イヤホン充電: イヤホンを充電ケースに入れるだけで充電できます。
2. 充電ケースの充電: 充電ケースの充電には5V出力の充電器を使用することをお勧めします。Type-C充電ケーブルを充電ケースの充電ポートに差し込んで充電します。



13.0 TOZOアプリ

- UIのカスタマイズ、EQ設定などについては、TOZOアプリをダウンロードしてください。
- ・UIのカスタマイズ: コントロールのほとんどは、アプリでカスタマイズできます。
 - ・EQ設定: さまざまな音楽ジャンルを流しながらエクスペリエンスを最適化するために、アプリで選択できるEQ設定が多数あります。
 - ・イヤホンのファームウェアの更新: イヤホンのファームウェアは、アプリで更新できます。イヤホンをアプリに接続すると、新しいバージョンのファームウェアが検出されると通知されます。



14.0 TOZOアプリのペアリング


- ステップ1:
TOZOアプリをスマートフォンにダウンロードします。



- ステップ2:
イヤホンとのBluetoothペアリング。



- ステップ3:
TOZOアプリとイヤホンのペアリング。



15.0 トラブルシューティングとリマインダー

1. 充電が入らない: イヤホンと充電ケースを充電する際、電源を入れる前に充電ケースの赤いランプが点灯しているか確認してください。
2. 氷による損傷: 製品を充電せず、すぐに電源を切り、表裏の水を拭き取って乾かしてから、もう一度使用してください。
3. 再生または接続の問題: イヤホンを充電ケースに入れ、充電ケースのボタンを10秒間押し続けて工場出荷時の設定に戻してから、もう一度使用してみてください。
4. 充電に接続できない: Bluetoothがオンになっていることを確認し、ペアリングを削除し、イヤホンの電源を入れ、イヤホンのBluetooth番号を検索して接続します。それでもうまくいかない場合は、工場出荷時の設定に戻してみてください。
5. 音が出ない: Bluetoothが接続されていることを確認し、イヤホンの音量を上げてみてください。
6. 充電できない: 別の5V電源アダプターを使用して充電するか、充電ケーブルを交換して問題が解決するかどうかを確認してください。
7. 問題が解決しない場合: TOZOカスタマーサービスにお問い合わせください。

1.0 Vielen Dank für den Kauf


Der Kopfhörer bietet Ihnen das außergewöhnliche Erlebnis eines stabilen Sprachanrufs und eines ruhigen Musikklangs in einer lauten Umgebung mit modischem Aussehen und mehreren Funktionen. Dies macht sie zu einer großartigen Wahl für Sie, wenn Sie arbeiten, ausgehen und fahren.

2.0 Spezifikationen

Lautsprechergröße: $\Phi 14,2\text{mm}$
Ladezeit: $\approx 2\text{h}$
FR-Bereich: 20Hz-20KHz
Impedanz: 16 Ω $\pm$ 15%
Übertragungsbereich: $\pm 10\text{M}$

Akkukapazität des Kopfhörers: 70mAh
Akkukapazität des Ladekoffers: 650mAh
Ladeparameter: 5V-1A
Produktgröße und Gewicht: 93*58*28 mm; 78g

3.0 Produktliste



4.0 Einschalten/Ausschalten

Einschalten:
1. Die Ohrhörer befinden sich im Ladeetui und durch Öffnen des Ladeetuis werden die Ohrhörer eingeschaltet.
2. Wenn sich die Kopfhörer außerhalb des Ladekoffers befinden (im ausgeschalteten Zustand), berühren Sie den linken und rechten Kopfhörer jeweils 3 Sekunden lang, um sie einzuschalten, und sie können auch einzeln verwendet werden.

19


Ausschalten:

1. Legen Sie den linken und den rechten Ohrhörer in das Ladeetui und schließen Sie den Deckel des Ladeetuis, um die Ohrhörer auszuschalten.
2. Wenn sich die Ohrhörer außerhalb des Ladeetuis befinden (im eingeschalteten Zustand), berühren Sie jeweils 3 Sekunden lang den linken und rechten Ohrhörer, um sie auszuschalten. Wenn der linke und der rechte Ohrhörer miteinander verbunden sind und Sie einen der beiden Ohrhörer berühren, um das Gerät auszuschalten, werden sowohl der linke als auch der rechte Ohrhörer ausgeschaltet.



5.0 Tragen

1. Der Ohrbügel des Kopfhörers kann sowohl nach vorne und hinten als auch nach links und rechts gedreht werden. Der Touch-Bereich ist im Bild dargestellt.



2. Passen Sie den gekrümmten Teil des drehbaren Ohrhörers an, um ihn vorwärts, rückwärts, links und rechts einzustellen. Tragen Sie ihn dann jeweils am linken und rechten Ohr und passen Sie den Schallauslass des Ohrhörers so an, dass er mit dem Gehörgang ausgerichtet ist, wie in der Abbildung gezeigt.

20


6.0 Bluetooth-Verbindung

1. Anschluss im Ladeetui: Öffnen Sie das Ladeetui und die roten und weißen Signalleuchten blinken abwechselnd. Suchen Sie nach dem Signal (TOZO Open Buds) und stellen Sie eine Verbindung her.
2. Verbindung außerhalb des Ladekoffers: Berühren Sie den linken und rechten Kopfhörer 3 Sekunden lang, um sie einzuschalten, und suchen Sie dann nach dem Signal (TOZO Open Buds), um eine Verbindung herzustellen. Sie können auch nur einen Kopfhörer zur Verwendung anschließen.
3. Nach erfolgreicher Verbindung erlischt die Signalleuchte an den Ohrhörern.




7.0 Zurücksetzen


Wenn die Ohrhörer in das Ladeetui gelegt werden, halten Sie die Taste des Ladeetuis 8 Sekunden lang gedrückt, um die Aufzeichnungen der Bluetooth-Kopplung zu löschen und die Werkseinstellungen wiederherzustellen.



8.0 Musiksteuerung




21



9.0 Anrufsteuerung



10.0 Sprachassistent



22