

HP-0505 Wireless Headphones IM

May 9 2024



WIRELESS HEADPHONES
With Removable Microphone
INSTRUCTION MANUAL

Table of Contents

- 1 Introduction 1
- 2 Packaging Contents 2
- 3 Connection Diagram 2
- 4 How To Use 3
 - 4.1 General Function 3
 - 4.2 Pairing To Mobile Phone 4
 - 4.3 Charging Your Product 4
- 5 Product Specification 6
- 6 FAQ 6
- 7 FCC Statement 7
- Battery Statement 8


1. Introduction

Congratulations, and thank you for choosing the Wireless Headphones with Removable Microphone. This manual will help you operate the Bubble Wireless Headphones, but firstly you should familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Wireless Headphones.


Safety Rules

- Please follow the safety description in this manual closely to ensure your safety. Before using the Bluetooth Headphones, we would strongly encourage you to read through this user manual.
- No form of any sharp, conductive surface, metal parts, accessories and its packaging to do to prevent any possible injury or damage.
- Do not modify, repair or disassemble the Bluetooth Headphones. Doing so may result in fire, electric shock, computer breakdown of the Bluetooth Headphones, etc. All are not possible under warranty.
- Do not use any device or vehicle liquid to clean the Bluetooth Headphones.
- Do not use the Bluetooth Headphones in a hazardous location.

2. Packaging Contents



3. Connection Diagram



4. How to use

4.1 General Functions

Desired Result	Required Action
Turn on & Enter the pairing mode	Press and hold the On / Off button for 3 seconds after turning on the USB Indicator lights on/off.
Pairing	Use a mobile phone with Bluetooth function or other Bluetooth device to perform manually pairing action. After pairing, the LED indicator slowly blink with blue.
Turn off	Press and hold the On / Off button for 3 seconds.
Charging	Plug the USB Type-C to the USB Type-C port. When charging, the LED indicator turns red. After full-charging, the LED indicator turns off.
Answering a Call	Press the USB button to answer phone call, press On / Off button again to end call. Press and hold 3 seconds to reject call. Double click to reject the call.
Play / Pause Music	Press On / Off button to play music and double click to pause music.

4.2. Pairing to Mobile phone or other device

To use your Bluetooth headphones, you must first pair your headphones with a mobile phone or other Bluetooth device. Once your Bluetooth headphones is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range.

Pairing to a phone and Entertainment:

- Turn on your phone and ensure the Bluetooth function is activated.
- Turn on the headphones, enter the pairing mode.
- Search your Bluetooth device on your phone by following the phone's instructions. Refer to your phone's user manual for more information.
- After a few seconds the phone will list the "HP-0505 HP" as a discover device. Select it and follow your phone's instructions to select this pairing.
- Your phone will confirm the pairing, and then press "Next/OK".

4.3. Charging your headphones

For your safety, please always use an appropriate 5V input charger/adaptor to charge the product. **DO NOT USE** Quick Charging USB Adapter to charge the product, as it might damage the product.

Use the USB Type-C cable accessory provided with the headphones. Connect the USB Type-C plug to the USB Type-C charging port on the headphones positioned at (1) in headphones diagram on page 2. Connect the USB plug to a USB port on wall adapter to activate charging.

Make sure to keep the headphones charging for a minimum of 2 hours before initial use.



Warning

- You must select a qualified charger from a regular manufacturer.
- You must charge the Bluetooth headphones if it has not been used for more than 3 months.

5. Product Specification

Driver Diameter: 40 mm
Impedance: 32 Ohms
Frequency Response: 20 Hz - 20 kHz
Sensitivity: 100 dB +/- 3 dB
Power Supply: Li-ion Battery 3.7V 180 mAh
Playing Time: 3-4 Hours
Charging Time: 2 Hours
Bluetooth Range: 33.6 Feet
Bluetooth Version: 5.3
USB Type-C Charging Cable Included
USB Type-C Charging Cable Rating: Mark Max.

6. FAQ

- Why is there no power even when the headphones is turned on?
Ans: Ensure the battery has been charged up to 1 hour for initial use.
- There is no sound when playback.
Ans: Check the connection between headphones with phone or computer. If the connection is not established, please connect again. Make sure the headphones is paired and connected with your target phone or other master device.

7. FCC Statement

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) The device may not cause harmful interference, and (2) the device must accept any interference, including interference that may cause undesired operation.

Caution: changes to modifications not approved by the party responsible for compliance must not be made without the party's permission.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

RF warning statement

This device has been evaluated to meet specific RF exposure requirements. The device can be used in portable operation condition without restriction.

8. Safety instructions for the User safety with charging the product

- The input voltage to the product is 5V 1A.
- In order to charge the product in safe manner and ensure conditions, please use only original certified compatible charger/adaptor for charging the product.
- Only charge the product at ambient temperature between 10 deg C to 30 deg C and 85 deg C to 95 deg F.
- Do not heat above 150 deg C (300 deg F), e.g. Do not expose to sunlight or keep into the closed of the product after use.
- Heater can not be used after any disassembly for any wiring operation. High Voltage higher than 50V, so this step should be aware to keep off properly, and we cannot avoid the operating process during the time the user using the product.
- In extreme cases, shock or misuse of electrical safety pack can lead to explosion, heat generation, fire development or smoke development.

The Bluetooth® word mark and logo are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marking without the permission of a valid license holder is prohibited. All other trademarks and registered trademarks are the property of their respective owners.

FCC ID: JACMS-HP-0505

FC

Manufacturer: JACMS Inc.
134 Street Street, Suite 200
Hillsborough, NJ 07034

Keep all relevant information for future reference.