How to install APP

IOS and Android or Apple system mobile phone can download the APP by scanning the QR code. Open a browser orother apps with the "Scan QR Code" function and scanfollowing QR code to download the APP.



With cell phone Scan QR code



APP interface



Surplife

How to reset

Turn on the light, then turn it off for 5 seconds (repeat 5 times)

Colorful function

Light color adjustment is divided into the whole section and segment, providing different columns for color selection or editing, and can adjust the brightness.

In the section interface, you can smear or erase the color of the section and set the gradient effect.





Situational function

Built-in lighting effect selection of four categories of scene modes: life, landscape, festival and mood, and click "DIY" or "Favorite" to add custom scenes.







Smear function

Click the plus sign to customize the light color and dynamic effect. Click Save after setting.

(Make sure the number of lights is consistent with the equipment before DIY, otherwise the lighting effect is incomplete, please edit the number of ic lights in the "Setting" function)





Wheel seeding function

Select the lighting effect of different categories of scene mode and set the lighting effect duration.

Combine different lighting effects to play in sequence.





Timing function

a). According to the time set by you, set the switch of the lighting under its control.

b). Set the execution of lights on, you can freely choose different lighting effects in colorful or scene.





Rhythmic function

Built-in 3 rhythm mode options: music mode, mobile phone microphone, device microphone (depending on the device configuration).

The light jumps and changes with the rhythm of the music, or the microphone


captures the external sound and converts it into a different rhythm of the light







Key Functions



Use the remote control to remove the insulating paper first

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to
 - which the receiver is connected.
 - —Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: