

Korean Postal Authority code	Enable Korean Postal Authority code
IATA	Enable IATA (default)
MSI/Plessey	Enable MSI/Plessey (default)
Telepen	Enable Telepen (default)
UK/Plessey	Enable UK/Plessey (default)
Code 128	Enable Code 128 (default)
Code 93	Enable Code 93 (default)
Code 11	Enable Code 11
RSS-14	Enable RSS-14
RSS-limited	Enable RSS-limited
RSS-expanded	Enable RSS-expanded
PDF417	Enable PDF417 (default)
MicroPDF417	Enable MicroPDF417 (default)

Table 3-17 Code configure description 1D laser

Field name	Description
UPC	Enable UPC A and UPC-E (default)
UPC+2	Enable UPC-A ADDON 2 and UPC-E ADDON 2
UPC+5	Enable UPC-A ADDON 5 and UPC-E ADDON 5
EAN	Enable EAN-13 and EAN-8 (default)
EAN+2	Enable EAN-13 ADDON 2 and EAN-8 ADDON 2
EAN+5	Enable EAN-13 ADDON 5 and EAN-8 ADDON 5
Code 39	Enable Code 39 (default)
Tri-optic	Enable Tri-optic (default)
Codabar	Enable Codabar (default)
Industrial 2of5	Enable Industrial 2of5 (default)
Interleaved 2of5	Enable Interleaved 2of5 (default)
IATA	Enable IATA (default)
MSI/Plessey	Enable MSI/Plessey (default)
Code 128	Enable Code 128 (default)
Code 93	Enable Code 93 (default)
RSS-14	Enable RSS-14
RSS-limited	Enable RSS-limited