

封底

封面

ELECTRIC

HEATED INSOLES

第一页

PACKING LIST

Heated Insoles\*2

5000mAh Rechargeable Batteries\* 2

Charging Cable\* 1 (Type-c)

USB Wall Charger\*1

Manual\*1

PRODUCT PARAMETERS

Model:

IN-01

Rated Power:

5V2A

Rated Voltage:

5W

Charging Time:

5-6H

Service Times Full Power:

3-11H

Cell Voltage:

3.7v

Single Battery Capacity:

5000mAh

Size cutting line

Heating area

Type-C Plug cable

Heating body

Front Velcro wool surface

Velcro hook surface

Back Battery

Battery Strap

PRODUCT PARAMETERS

Small

Large

Size of corresponding countries

Insloe (inches)

USA

EU

UK

Insloe Length

3.5-7.5

32-40

2.5-6.5

9.4-10.6

8-12

41-49

7-11

10.9-12.1

HOW TO CHARGE?

1 Insert the Type-c end of the charging cable into the battery charging port.

2 Plug the USB end of the charging cable into the power adapter

3 Plug the charging head into the wall outlet

4 Once fully charged, the green light stays on continuously.(After fully charged, please unplug the charging cableand use it)

第五页

BATTERY INDICATION

The green light represents the battery capacity:  
As Shown 

25%,50%,75%,100%

Power indicator area

Gear indicator area

Type-C socket

第六页

BATTERY INDICATION

A red light indicates four heating temperatures:

1

104°F ±3°F

9-11H

2

122°F ±3°F

7-8H

3

140°F ±3°F

5-6H

4

158°F ±3°F

4-5H

\*The following data are laboratory test data at room temperature of 77°F

第七页

BATTERY INDICATION

Battery Maintenance:

1.The battery should not be exposed to fire or high temperature. It should not be soaked in water,dropped, or dismantled.

2.If the battery is not used for a long time, it should be fully charged first.It is recommended to charge the battery every 60 days.

3.The battery should be stored in a dry and cool place to prevent low-temperature burns.

第八页

QUICK START GUIDE

1

1) First, please place the insloe inside the shoes.

2

2) Fix the batteries on the ankle your needs.

3

3) Insert the USB cable into the battery port.

第九页

QUICK START GUIDE

4

4) Press the button for 3 seconds to turn it on.

5

5) Short press to adjust temperature.

6

6) Wait for 20-30 seconds and test the temperature.

7

7) Enjoy a whole day of warmth and comfort.

第十页

QUICK START GUIDE

1

1 Please open the elastic band on the bandage battery and fix the battery on the calf you needs.

2

2 The bandage has elasticity. Please adjust the tightness to avoid discomfort.

3

3 Do not pull the elastic band too much, which will cause the elastic force to fail.

Warm wool surface

VELCRO

Velcro hook surface

第十一页

APP CONTROL INSTRUCTIONS

How to download APP?

Select the "APP store" and "Google Play" download QR code for scanning and downloading on iPhone and Android phones respectively. You can also download the corresponding app by searching for "HEATING INSOLE" in the app download market.

1 Scan the QR code.

2 store Click to download.

3.Open "HEATING INSOLE" and accept the Bluetooth connection request.

4.Enter your user name, gender, phone number, and email address. (Registration is for collecting your feedback on product usage and providing you with more personalized and professional services. please rest assured that your information will be kept strictly confidential.)

5.Registration completed!

HEATING INSOLE

APP Store

Download Diagram

第十二页

APP CONTROL INSTRUCTIONS

How to use the APP?

Attention:

it is recommended to use the heated insoles with fully charged batteries

1

After wearing the insoles, press and hold the power button for three seconds to turn them on.

2

Enable Bluetooth on your smartphone.

3

Open the "HEATING INSOLE" app.The heated insoles will automatically connect to the app. The indicator light on the top right corner will illuminate to indicate a successful connection.

4

Open the "HEATING INSOLE" app.The heated insoles will automatically connect to the app. The indicator light on the top right corner will illuminate to indicate a successful connection.

Please note: To ensure safety and optimal performance please follow the instructions in the user manual and regularly check the battery status of the heated insoles. Enjoy the warmth and comfort of our high-quality product!

第十三页

APP CONTROL INSTRUCTIONS

Reference Temperature

Quick Heating Button: 5-minute Rapid Heat up to 20-30°C/68-86°F

Switch: Fahrenheit or Celsius

Quick Temperature Regulation

Timing to Power off

Link StatusIndication: The indicator is highlighted so linked shoes are gray is broken chain status.

Battery Indicator: Please connect to a power source promptly when the battery indicator times below:

Product Help Center: Do you have any questions or feedback regarding the heated insoles? Please write them here.

Please GearControl: Adjustable temperature range from 66 to 158 degrees Fahrenheit, Every 4 degrees Fahrenheit 2 degrees Celsius per unit.

Power On/Off

第十四页

APP CONTROL INSTRUCTIONS

1.The battery must be turned on to use the app function. When it is turned off, the phone will not be able to search for the battery.

2.Turn on the mobile phone positioning and Bluetooth functions for APP Bluetooth control.

3.If the mobile app is not connected to the battery device after the battery device is powered on, please check whether other permissions of the mobile app are opened

4.If you have more than two battery devices, it is recommended to turn off all devices and only turn on two battery devices for app connection to avoid confusion.

5.After opening the battery, open the mobile application, and the mobile application will automatically connect to the battery device without binding and manual connection

第十五页

HOW TO CLEAN?

1

Disconnect the Battery pack from the insloe and unplug it.

2

Insoles are recommended to be hand washed in water not exceeding 122°F.

3

Lay flat to dry. Do not tumble dry, do not iron,do not dry clean.

4

Make sure the insoles are completely dry before using them again.

第十六页

FAQ

Q:What's the highest temperature that these heated insoles can achieve?

A: The highest temperature of our heated insoles can reach 158°F +3°F (70°C +2°C)  
Note: For a better user experience, it is recommended to fully charge the battery before use.

Q:Will I get scalded by the heated insoles?

A: No, these heated insoles are very safe and have four settings, with temperatures ranging from 110°F to 158°F(43°C to 70°C). For optimal heating effect, please wear a regular sock.

Q: Who can I contact in case my accessory or product is damaged?

A: You can contact our customer service via email: wamovalService@outlook.com

第十七页

DISCLAIMER

1 Warning: In order to avoid danger, it is forbidden to fold and stack the products under working conditions. The company is not responsible for any loss of life or property caused by violation of this specification.

2 Please select the heating setting carefully when using electric insoles. Do not use them for extended periods to avoid low-temperature burns. If you feel uncomfortable using the product, please stop using it immediately. The company is not responsible for any loss of life or property caused by violation of this specification.

3 Children must use this product very carefully and must be accompanied by an adult. The company is not responsible for any loss of life or property caused by improper use.

4 This product is not intended for use by pets. The company is not responsible for any loss of life or property caused by violation of this specification.

5 Be sure to remove the battery before washing the heated insoles. The company is not responsible for any loss of life or property caused by violation of this specification.

第十八页

DISCLAIMER

6 Please use neutral detergent to clean the product; do not use acidic detergent. The company is not responsible for any loss of life or property caused by violation of this specification.

7 If the electric insoles or batteries malfunction (e.g. insoles do not heat properly, local temperature is too high, or any other damage), please contact our after-sales service. The company is not responsible for any loss of life or property caused by violation of this specification.

8 The electric insoles battery should not be used in high temperature or other extreme environments, as it may lead to unexpected safety risks. The company is not responsible for any loss of life or property caused by violation of this specification.

9 Since the battery of electric insole accessories is not waterproof, it should not be used in bathrooms, laundry rooms, or similar humid environments. The company is not responsible for any loss of life or property caused by violation of this specification.

第十九页

DISCLAIMER

10 Do not place the battery next to the bathtub or other water containers. The company is not responsible for any loss of life or property caused by violation of this specification.

11 Please keep the battery and plug dry. Do not use them in the presence of water or high humidity. The company is not responsible for any loss of life or property caused by violation of this specification.

12 The battery shall not be used in places where there are inflammable substances, nor shall it be wiped and cleaned with flammable solvents. The company shall not be liable for any loss of life or property caused by violation of this specification.

13 Do not hit the battery violently. The company is not responsible for any loss of life or property caused by violation of this specification.

14 Do not iron this product; doing so may damage the heating components. The company is not responsible for any loss of life or property caused by violation of this specification.

第二十页

DISCLAIMER

15 Do not attempt to repair, modify, or disassemble this product. The company is not responsible for any loss of life or property caused by violation of this specification.

16 When using this product, if you notice that the local temperature of the battery and power cord plug is too high or if there are any other abnormalities, please stop using it and contact the after-sales department. The company is not responsible for any loss of life or property caused by violation of this specification.

17 Please use a 5V 2A adapter to charge the battery. Do not use an incompatible adapter. The company is not responsible for any loss of life or property caused by violation of this specification.

18 Please unplug the battery when it is fully charged. The company is not responsible for any loss of life or property caused by violation of this specification.

CUSTOMER SERVICEE-MAIL:  
wamovalService@outlook.com

第二十一页

FCC-DISCLAIMER

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

第二十二页

FCC-DISCLAIMER

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
– Reorient or relocate the receiving antenna.  
– Increase the separation between the equipment and receiver.  
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
– Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.