

CHARGING INSTRUCTIONS

1. Connect the AC adapter to the Charger and plug it to the mains (green led is steady on).

TO MAINS



2. Connect the Charging Cord between the PAL and the charger (see illustration).
Red led charging indicator is steady on and the PAL will beep once.



3. Red charging indication will light steadily during fast charge mode. When the battery is fully charged, the charger will change to slow charge mode and the red charging indicator will blink.

Important:

For maximal durability - charge a new battery for 12 hours, prior to its use.

For longer battery life, use only the supplied charger.

Charge after every use of the PAL.

Do not attempt to replace battery packs yourself !

If this product fails to operate please call customer support.

Keep the PAL away from water!

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

We will be happy to assist you at customer support:

Tel: 516-931-1919 Fax: 516-931-5468

ITURAN U.S - 270 Duffy Ave, Hicksville NY 11801, U.S.A



PERSONAL ALARM & LOCATOR

USER'S GUIDE



PERSONAL ALARM & LOCATOR (PAL)

Congratulation! You have joined the exclusive client group of Ituran, U.S.!

The unique location technology of Ituran was originally developed for location of downed pilots and then modified for civilian use.

Our system allows for the location of human, goods and pets in open areas, woods, urban and metropolitan areas, outside or inside buildings.

For efficient and useful operation of the PAL, please follow the instructions.



OPERATING INSTRUCTIONS

1. TURNING YOUR PAL ON

Press and hold the green ON/OFF button until you hear a short beep. The red and green indicators will light for 5 seconds, followed by flashes of the green indicator once every 5 seconds.

2. EMERGENCY CALL

Press and hold the red ALRT button until you hear a short beep. An emergency signal is transmitted, followed by flashes of the red indicator twice every 5 seconds.

Ituran Control Center will confirm the emergency call by sending a signal to the PAL that will activate two short beeps and flashes of the green indicator twice every 5 seconds for 5 minutes.

ATTENTION: The emergency call will be transmitted even if the PAL is OFF.

WARNING : DO NOT PRESS THE RED BUTTON UNLESS IT IS AN EMERGENCY SITUATION.

3. TURNING YOUR PAL OFF

Press and hold the green ON/OFF button until you hear a long beep, and the red indicator will light for 2 seconds.

4. LOW BATTERY INDICATION

Low battery will be indicated by two short beeps every minute, and flashes of the red indicator once every 5 seconds.

In order to deactivate the beeps, press the green button shortly.