# USER MANUAL

What's in the box?
1. Speaker*1
2. Type-C cable*1

MADE IN CHINA
FCC ID: 2BCGV0020

Overview
1. Power ON/OFF/Light Button
2. Mode/Channel search/Play/Pause
3. Timer control button
4. Next track/Vol+
5. Previous track/Vol –
6. Alarm clock setting
7. Clock setting
8. Display panel
9. Lamp
10. Wireless charging surface
11. AUX line in
12. USB port
13. TF card
14. LED indicator
15. Type-C input

Specifications:
1. Model: CT02107
2. Item: 25250
3. Input: DC 5V/2A, 9V/2A
4. Speaker output power: 5W*2
5. Battery capacity: 3.7V/1200mAh, 4.44Wh
6. Wireless output: 10W

Operation Instructions
1. **Power On:** Long press the power button to turn on the speaker, you will hear a tone.
2. **Pairing:** Once speaker is turned on, open your mobile device, search the wireless device and select wireless ID '25250', It will pair automatically.
3. **Play/Pause:** Short press the button to play or pause the music.
4. **Next track/Vol+:** Short press to next track, long press to increase volume
5. **Previous track/Vol -:** Short press to last track, long press to decrease volume.
6. **Switch wireless, FM and white noise mode:** Long press the Mode button.
7. **White noise mode:** Long press the Mode button to enter white noise mode, tap the next/previous button to switch different sounds. Tap timer control button to set 15/30/60 mins timer, the product will automatically shut down when the time is reached.
8. **Lamp:** Tap the light button to turn on/off the lamp and change different color.
9. **Clock setting:** Tap the clock setting button to enter hour/minute setting, press the next/previous button to set the hour/minute, then tap the clock setting again to

complete the setting. Long press to switch 12 or 24 hours mode.
10. **Alarm clock setting:** Tap the alarm clock setting button to enter hour/minute/alarm setting, press the next/previous button to set the hour/minute/alarm sounds, then tap the alarm clock setting button again to complete the setting.
11. **FM mode:** Use the Type-C cable included to connect the speaker as antenna. Long press the mode button to enter FM mode, then tap the mode button to enter search channel mode, it will search and store the channel automatically, press the next/previous button to choose the channel you like after search is completed.
12. **Wireless charging your mobile device:** Use the Type-C cable included to connect the speaker to a qualified adaptor, place your wireless device on the wireless charging surface, the device will begin to charging immediately. Once fully charged, remove the device.
13. **TF card play:** Plug the TF card into TF slot, it will automatically play the music.
14. **USB play:** Plug the USB disk into USB port, it will automatically play the music.
15. **AUX line in**(not include)**:** Use the 3.5mm Audio cable to connect the speaker and you phone, then your can enjoy the music.
16. **Power Off:** Long press the power button to turn off the speaker.
17. **Charging speaker:** Use the Type-C cable included to connect the speaker to a qualified adaptor, the charging LED indicator will illuminate red and turn off after fully charged.

Caution:
1. Please enjoy music with an appropriate volume, which will avoid to damage your hearing and sound system.
2. Please avoid exposure, rain, water droplets, avoid prolonged exposure to high temperature, high humidity environment.
3. During use, please make it away from heat, high pressure, and prevent children from playing with this product.
4. Please use the power which meets the requirements.
5. Do not drop or bump and applied heavy pressure to avoid damage to the product.

FCC STATEMENT
This device complies with Part 15 of the FCC Rules. Operation is subject to thefollowing two conditions:
(1)This device may not cause harmful interference, and
(2)This device must accept any interference received, including interference that may cause undesired operation.

Warning: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful

interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

RF Statement
The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by (ShenZhen SHD Electronic Tech. Co., Ltd.) is under license. Other trademarks and trade names are those of their respective owners.

Bluetooth Listing Declaration ID: D063501