









BLUETOOTH SPEAKER MANUAL

10262PG



INSTRUCTIONS

1. Long press  for power on and power off, Short press  for Bluetooth, USB, TF card mode.
2. Short press  to Previous song, long press  to volume down
3. Short press  to Next song, long press  to volume up
4. Short press  to Play/Pause, long press  to LED light off switch, Double-Click to Last Number Redial
5. TF Card Slot, Insert TF card and the speaker will enter into TF card playing mode automatically
6. USB Jack, Insert USB disk and the speaker will enter into USB playing mode automatically
7. Type C Charging Port
8. Line-in with 3.5mm aux cable

BASIC FEATURES

- Bluetooth play
- Support handsfree call
- Support music from TF card
- Support music from USB

TROUBLE SHOOTING

- Cannot turn on the speaker: check if the speaker does not have power, if no power, charge it first.
- Cannot connect with Bluetooth devices: check if speaker connected with the third Bluetooth device, if yes, disconnect it first, if still cannot connect, reboot it and try again.

CHARGING VIA USB CABLE

- Via Type-C cable, connect the speaker with the Type-C charger(output voltage 5V/output current no less than 1A, this accessory is not included) for charging;
- Type-C cable is for charging use only, not for data transferring

SPECIFICATIONS

- Bluetooth Version: 5.0
- Speaker Output: 4Ω 5W*2
- Built-in Li-ion Battery: 1800mAh / 3.7V
- Input DC: 5V=500mAh
- Frequency Range: 100Hz-20KHz
- Product Size: 220*80*80MM
- Net Weight: 528.5g (Speaker Only)

INTERFACES

- Type-C Port: Power Charging
- USB Port: Plug USB for music playing
- TF card slot: Plug TF card into the card slot for music playing
- LED indicator:
 - Blue flash: Power on, Pairing.
 - Blue light: Paired
 - Red light: Charging status (red indicator off when Fully charged).

CAUTIONS

- Keep out of reach of children
- Never knock the speaker
- Keep it away from fire, high and low temperature
- Never block speakers nets
- Never open it by yourself
- Do not charge it for too long time in case of damage to the battery, 5 hours is the best charging time

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,

may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.