







GUARAN

产品基础 PRODUCT BASIC INFORMATION














旋钮功能 KNOB FUNCTION

长按旋钮三秒切换旋钮模式 Long press knob for 3 seconds to switch knob mode

音量模式(默认): 脈时針音量加、逆时针音量减、按压静音 Volume Mode (default): Clockwise Volume Up. Counterclockwise Volume Down

背光/Backlit 版本/Version 轴体/Key Switches 尺寸/Size Layout 327.5(L)×150.71(W)×30.03(H)±2 80 keys 有线/2.4G/BT USB-C wired/2.4G wireless/BT RGB 矮轴 low profile switch





BT连接







3.打开电脑/手机87、搜索升连接设备,搜索显示的名称: Kzzi-175.3.0 (连接PC路Windows7以下系统),Kzzi-175.5.0 (连接Windows8以上系统图本,移动设备等) Open PCMobile BT, secrit and connect the device, the search shows the name: Kzzi-76.3.0 (connect to PC with Windows 7 or below).

以此规格:重复以上参辑。Q/W/E/可存储设理时设备,在使用切除时 短控行。Q/W/E.即可在不同时设备之间切除(国都提示:使用切除的,请先配对好设施之利 And so or: Repeat the above sleps, Q/W/E/can store 3 groups of 57 devices, when using the switch Short press Fnr-QW/E, you can switch between different B* (Whrm tips: before using the switch Dases pare up the 3 groups of 87)

2.4G连接 2.4G RECEIVER CONNECTION





开关拨到2.4G状态,长按FN+P对码,P键快道闪烁插入接收器,P键停止闪烁即对码。 Switch to 2.4G、Long press FN+P to pair code.P key blinks to insert the receiver

(温馨提示:出厂时日配对好接收器,无需自行再次配对2.4G; 此方法只是2.4G无法连接的时候使用,首次设置即可,无需每次都设置 (Tips: The receiver is set to be paired at the factory You just need to set it only once, when pairing not working properly.)

指示灯 INDICATOR LIGHT

轻触开关:显示桌面功能 Tap this key: Quick desktop view switch



2.充电指示灯(红光),充电常亮、充满熄灭、低电量闪烁 Charging indicator (red light): Charging (solid), Fully charged (aff),Low battery (flas

电池电量提示 BATTERY LEVEL CHECK

键盘背光可显示当前电池电量状态 The keyboard's lighting can display the current hottom

(无线模式下查看) View in wireless mode

按FN+ENTER 查看电池电量情况 Pressing FN+ENTER allows you to view the battery level status.Each key from "1" to "0" represents a specific battery level range.

11 背光亮 表示此时键盘10%的电量 The backlight of the "1" key is illuminated, indicating that the keyboard's current battery level is at 10%.

11~ 🛍 背光同时亮,表示此时键盘20%的电量

The "1" and "2" keys are both illuminated, indicating that the keyboard's current battery level is at 20%.

以此类推 Similarly

11 - 19 背光同时亮,表示此时键盘电量 100% When the backlighting illuminates from 1 to 0 simultaneously, it indicates that the keyboard battery is at 100% charge.

背光控制 BACKLIGHT CONTROL



Fn + 支持多种背光效果切换
Multiple backlight effects switch


+ △ 背光亮度 +
Backlight brightness +

▽ 背光亮度 -Backlight brightness -

+ WIN 窗口锁定 Windows lock

Fn + space bar 长按3秒,恢复出厂设置 Long-press for three seconds to restore factory settings

FN组合键功能 FN KEY COMBINATION FUNCTION









ISED STATEMENT:

See a continue of the continu


hypothelium/rispanis cien continue avander per « 3 dil ren « 3 dil ren » 3 dil ren « 3 dil ren » 3 dil ren serie montali e mon


DAY LEMES.
Among the latent playing ask or lettere invalid judjeted appeal to exceed his section as excellent.
The description of account point in control point has an orbital subjects.
The description of a state of account point has an orbital subject of a state or account point of a state of account point of a state or account point of account point of a state or account point of account point point of account point point of account point point



GUARANTE Non-human dama 12-month warran

背光录制 BACKLIGHT RECORDING





Thank you for choosing KZZI products! If you have any questions or need assistance, please feel free to contact us. Our team is dedicated to providing support and addressing your inquiries.

We highly value your feedback and suggestions as they help us continuously improve and enhance product quality. Once again, we appreciate your support for KZZI!

Kzzi