FRONT

BACK





ijoĭ

model: IJ17-BEAD-B1C8

QUEST USA CORP. 495 Flatbush Ave Brooklyn, NY 11225

© GOIJOY & IJOY are registered trademarks of QUEST USA CORP.
All other trademarks and trade names are property of their respective owners.
Designed by GOIJOY & IJOY in New York. All rights reserved QUEST USA CORP.
Brooklyn, NY. Limited lifetime warranty. To activate your product warranty go to our website www.goijoy.com & register this product.

•YOUR IJOY PRODUCT

Thank you for puchasing and using the "IJOY BEAD" wireless bluetooth speaker. This product can provide high quality listening and enjoyment for your mobile phone, computer and multimedia. Before using this product, carefully read this manual to correctly manipulate and play its best performance. Please ask your local dealer or call us if you have any questions

PACKAGE CONTENTS

IJOY BEAD Bluetooth Speaker X 1 Charging Cable X 1 User Manual X 1 Carabiner Hook X 1

•PAIRING YOUR PRODUCT

Step 1: Open the Bluetooth setting on the phone or tablet and click "searching device", The device will search for Bluetooth devices automatically.

Step 2: The Bluetooth paring name is found out when the phone or tablet screen displays "IJOY BEAD". click to connect Step 3: When a cell phone or tablet /PC displays a successful connection, the blue light is on.

•BATTERY CAUTION

The battery used in this device may present a risk of fire, explosion or chemical burn if used incorrectly. Never use or charge the battery if it appears to be leaking, discolored, deformed, or in any way abnormal. Never dissasemble the unit or attempt to remove the battery as that could cause leakage of alkaline solution or other electrolytic substance. Always confirm that the temperature is 5 degrees Celsius before you change the battery. Never expose the battery to any liquid. Never expose the battery to excessive heat such as direct sunlight or fire. Never use the battery pack in an unventilated vehicle where excessive internal temperatures may be encountered. Always keep the battery out of reach of infants and small children.

•BATTERY DISPOSAL

Please do not attempt to change the battery yourself. If the battery has died and you do not want us to replace your battery, you should follow the disposal instructions listed here. Never dispose of used batteries/electronics with ordinary solid wastes. Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices. Many electronics retailers now recycle batteries and other electronic components at no charge.

•DEVICE FUNCTIONS

Play/Pause Vol+/Next Song



PRODUCT SPECIFICATIONS

SNR:≥65db

Battery: 300mAh

Playing time: 1-2H

Loudspeaker: 4Ω/3W

Independence: 1320HZ-20KHZ

Size: 90mm *90mm *47mm

•INSTRUCTIONS

- 1. OFF/BT/MP3 MODE: Slip the button to the middle to power off. Slip to the left for MP3 mode and click right for BT mode.
- 2. LED Indicator: When charging the speaker, the red light will be on until the speaker is fully charged.

TF CARD READER FUNCTION

In MP3 mode, the speaker can play music files automatically when the TF card reader is inserted.

HANDSFREE CALLING

The blue light will remain one when a phone call comes in. Tap the button to answer and hold the button to reject the call

FM MODE

Turn to the MP3 mode and connect the 2 in 1 USB cable to be an FM antenna. Click the button to search for FM channels and press the button for longer to turn the speaker into FM Mode.

•OTHER IMPORTANT SAFETY INFORMATION

To avoid danger of suffocation, keep plastic bag away from babies and children. Do not use this bag in cribs, beds, carriages or playpens. This bag is not a toy. Disposal of old electrical & electronic equipment (Applicable in the European Union and other European Countries with seperate collection systems.) The trash can symbol (seen on bottom right) on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over the the applicable collection point for recycling of electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the enviornment and human health, which could otherwise be caused by innapropiate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.







•LIMITED LIFETIME WARRANTY

Our product is warranted for a limited lifetime warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarentee of 24 months does not apply to decrease in the accumulators effective capacity caused by its use or age. Effective capacity gradually decreases depending on the method of use of the accumulator. **WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS.** For more information please visit, www.goijoy.com

Tip: Must choose the formal manufacturer certified charger, output voltage of 5v. If the product is not in use for a long time, please charge it.



FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.