




# Annex A


## Peak Excursion



### 10 Mhz High Channel




### 10 Mhz Low Channel






### 10 Mhz Mid Channel




### 20 Mhz High Channel






### 20 Mhz Low Channel




### 20 Mhz Mid Channel






### 5 Mhz High Channel



### 5 Mhz Low Channel





5 Mhz Mid Channel

