




ANT0

Mode	Band	Mobile Transmit	Mobile Receive
GSM	GSM850	824 – 849 MHz	869 – 894 MHz
	EGSM900	880 – 915 MHz	925 – 960 MHz
	DCS1800	1710 – 1785 MHz	1805 – 1885 MHz
	PCS1900	1850 – 1910 MHz	1930 – 1990 MHz
UMTS	B1	1920 – 1980 MHz	2110 – 2170 MHz
	B2	1850 – 1910 MHz	1930 – 1990 MHz
	B5	824 – 849 MHz	869 – 894 MHz
	B8	880 – 915 MHz	925 – 960 MHz
CDMA	BC0	824 – 849 MHz	869 – 894 MHz
	BC1	1850 – 1910 MHz	1930 – 1990 MHz

ANT1

Mode	Band	Mobile Receive
GSM	GSM850	869 – 894 MHz
	EGSM900	925 – 960 MHz
	DCS1800	1805 – 1885 MHz
	PCS1900	1930 – 1990 MHz
UMTS	B1	2110 – 2170 MHz
	B2	1930 – 1990 MHz
	B5	869 – 894 MHz
	B8	925 – 960 MHz
CDMA	BC0	869 – 894 MHz
	BC1	1930 – 1990 MHz