



Usage Guide

1. This product is very easy to use and the capacity of the essential oil bottle is 100ml.

2.a. When using for the first time, gently pull outward from the "Disassembly hole" and buckle out the back panel, as shown in "Figure

b. Unscrewing the nozzle of the empty bottle, then fill the empty bottle with essential oil, and screw the nozzle back into the essential oil bottle, as shown in "Figure b" c.Then install the bottle back to the diffuser, and pay attention to the

d. Installing the back panel as shown in "Figure d"; Note: When using for hours; short touch the power button (1) to switch gears. the first time or when the essential oil has been used up, refer to the Power off: long touch the switch for 2 seconds to shut down. figure below to fill the essential oil; if the essential oil is not used up and needs to be replaced with other essential oils, please keep the diffuser in

a vertical direction when replacing.




≥2A USB interface adapter (please use a regular brand charger certified by CCC to charge the product); When the product is charging, the charging indicator lights up red, and when the battery is fully charged, the charging indicator lights up green. When not charging, the charging indicator flashes, indicating that the battery power is less than 10%, please charge in time. position and direction of the nozzle when installing, as shown in "Figure 4. Product power on: long touch the power button @for 2 seconds, the LED

display will light up, the default working mode is 1st gear, and the timing is 4



Mist display gear 1: Spray 15S, Stop 165S Mist display gear 2: Spray 60S, Stop 120S Mist display gear 3: Spray 120S, Stop 60S





A1: 7~8H

Voltage: DC5V2A Battery: 10000mAh essential oils that are volatile, free of impurities and non-viscous.

Timer: 1~9H(Each switch changes the value by 1)

N.W. 1.05KG

Specification:

Size: 120*120*335mm

Coverage: 100~200m²

essential oils.

Q3: When the product is turned on, can't see the mist?

depending on the usage environment. **b.** The coverage and fragrance retention time of the fragrance are affected by


b. Different essential oil have different atomization effects.

Q1: How long does it take to fully charge the battery?

Q2: What kind of essential oil does the product use? A2: It is recommended to use pure plant essential oils, or

a.This is a normal phenomenon. The product itself has the a. The above data are laboratory test values. The data may vary slightly function of automatically adjusting the atomization particles to maximize the saving of essential oils.

> **b**.The atomization particles are only 1~3 nanometers, which are difficult to capture with the naked eye.




Precautions


stop when it tilts more than 45

6. There is an anti-dumping device inside the machine

When the machine and the nozzle are shaken, they will make noises, which is normal. To prevent oil leakage when the When the machine is put back 7. Essential oils are not edible. If ingested, please seek


machine accidentally tips over, the machine will automatically after 5S in place, it will resume working after 5S medical attention immediately. If it gets into your eyes, please rinse immediately with clean water. When spraying, please keep your mouth and nose away from the spray nozzle to avoid direct inhalation. People who are sensitive to fragrances, please use with caution. This product is only used to refresh the air and cannot be used for other





















FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.