

Sprint PCS CC-Phone Modem Components

All CC-Phone Modem packages include the following components:

- Quick Reference Guide
- CD ROM containing the CC-Wiz, Driver and User's Guide
- Warranty Card
- AC Adapter
- This User Guide

Sprint PCS Coverage

The Sprint PCS CC-Phone Modem operates on the Sprint PCS Nationwide Network which serves more than 330 major metropolitan areas. For coverage information, see the Sprint PCS web site, www.sprintpcs.com

Sprint PCS Customer Care

For questions about using your Sprint PCS CC-Phone Modem, call Sprint PCS Customer Care at 1-888-211-4PCS (4727) or see us at www.sprintpcs.com

CC-Phone Modem Basics

- **Software Included with CC-Phone Modem**
- **Account Activation**
- **Care and Maintenance**

This section provides a brief description of the software that comes with the Sprint PCS CC-Phone Modem and explains account activation. It also tells you how to care for your CC-Phone modem to ensure reliable operation.

Before you can use the CC-Phone modem, you must:

1. Install the software
2. Insert the CC-Phone modem
3. Activate the modem, if it has not been pre-activated

CAUTION: Do not insert the modem into a PC Card slot before installing the software.