

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.


BLUETOOTH SPEAKER

User Manual

T-8



Control Panel Function



- 1.LED Display
- 2.Power OFF&ON / VOLUME -&+
- 3.DC interface (5V)
- 4.MODE/LED(Long press to turn on/off light; Lightly press to enter into selection for Bluetooth,LINE Input,USB)
- 5.Line input
- 6.Previous track
- 7.USB input
- 8.Play/Pause&TWS (Wirless Bluetooth Connection: under bluetooth mode, press TWS button for around 3 seconds to pairing another TWS speaker.)
- 9.Next track
- 10.Charging Indicator
- RED=Charging Light off = Fully charged
- 11.MIC input

Specifications:

Power:	16W
Frequency Response	
for main speaker:	55Hz-20KHz
Power Supply:	DC 5V

POWER SOURCE

- 1.Please charge the unit at least 4 hours before first time using.
2. Twist the dial clockwise/anticlockwise to switch on/off the unit.

CHARGE THE BATTERY

When the battery is charging, the CHARGE STATUS lights shows on the LED display is red. After the battery has fully charged, the light turns off.

1. Connect the USB charge cable to the DC5V interface of the speaker firmly.
2. When the battery is fully charged, please disconnect the USB charge cable from the speaker.
- 3.The speaker works normally when charging.

POWER/VOLUME

Twist the dial clockwise/anticlockwise to increase/discrease the volume.

PREVIOUS/NEXT BUTTON

Under playing status, press PREVIOUS/NEXT button to get back to a previous or next song.

PAUSE/PLAY BUTTON

To stop playing the current track, please press PAUSE/PLAY button on the control panel. Press it once again to continue playing.

MODE/LED

Long press to turn on/off light.

Lightly press to enter into playing mode selection(Bluetooth,LINE Input,USB).

LINE IN JACK

- 1.Connect an audio cable to the LINE IN JACK of the speaker and to the audio output socket on the external audio devices such as MP3 player, discman,etc,then select LINE by pressing the MODE/LED button on the control panel .
- 2.Play from an external audio device.

MIC IN JACK

Plug in microphone directly for playing.

USB JACK

Insert USB card directly for playing.

Bluetooth:

Press MODE/LED button on control panel to select Bluetooth mode.

Simultaneously open the Bluetooth setting on your phone, tablet or any other bluetooth enabled audio device and select "ISB384B"(no need to match code),the unit and device will then connected via Bluetooth. Press the "NEXT SONG" and "PREVIOUS SONG" button on the control panel to select the song, press "PLAY/PAUSE" button to control the playing status.