


中文

AI 使用说明书

M122

OVS 蓝牙耳机

产品结构图



包装清单

耳机x2pcs
充电仓x1pcs
Type-C充电线 x1pcs
说明书x1pcs

将耳机取出悬挂在耳朵上，悬浮挂耳式佩戴，悬浮空气，轻盈贴合不入耳，全天候轻盈舒适久戴不累耳。

快速入门

连接手机APP

请扫码下载Wearfit Pro应用并安装，或前往各大应用商店，搜索“Wearfit Pro”找到应用并下载安装。

初次使用请注册好个人账号，并授予APP程序运行必要的权限，以确保设备正常使用
开启手机蓝牙，在手机蓝牙列表找到名为“M122”的耳机设备，点击连接，连接成功后，再打开“Wearfit Pro”APP，进入设备页，点击左上角“+”号，点击添加设备进入蓝牙搜索，找到名为“M122”的耳机设备，点击连接，连接成功后即可进入耳机界面。

注：如未连接成功，请检查手机蓝牙是否已正常开启，或耳机设备是否正常工作并处于待连接状态，或耳机设备是否未被任何其他手机连接。

Wearfit AI 对话

打开“Wearfit Pro”APP，点击右上角选择进入耳机设备页面，点击主页“Wearfit AI”卡片，进入功能页面，点击左下角可切换语音输入和文字输入模式，输入内容发送后，AI会给出内容，同时耳机同步播报内容。

一键翻译

打开“Wearfit Pro”APP，点击右上角选择进入耳机设备页面，点击“按住说话”按钮，录入语音后将自动输出翻译内容，同时耳机同步播报内容，点击下方语言可切换语言。

同声传译

打开“Wearfit Pro”APP，点击右上角选择进入耳机设备页面，点击主页“同声传译”卡片，进入功能页面，点击开始同传，进入录制界面，设备自动识别录入声音并同步翻译，同时耳机同步播报内容，点击上方语言可切换语言，点击右下角播放按钮可暂停/开始录音。

白噪音

打开“Wearfit Pro”APP，点击右上角选择进入耳机设备页面，点击主页“白噪音”卡片，进入功能页面，点击播放卡片进入播放页面，点击播放按钮可播放/暂停音频，点击“单次播放”按钮可切换播放模式。

产品操作介绍

功能	操作	指示灯	提示音
配对名称	M122		
开机	耳机在充电仓内静置下，取出耳机自动开机/耳机机关状态下，长按触摸键3秒后开机	白灯闪烁	Power on/开机
关机	耳机放入充电仓内部自动关机/耳机机关状态下，长按触摸键3秒关机	白灯长亮1秒后熄灭	Power off/关机
左右耳机配对	左右耳机开机后自动进入配对模式	左右耳配对成功后，主耳机白灯闪烁，副耳机为熄灭	Connected/连接成功 Not Pairing
切换中英文提示音	未连接智能设备情况下，连击任意左/右耳机触摸键4次，进行语音切换，说出“默认英文”	/	English/中文
智能设备连接	当双耳配对成功后，自动进入待连接状态，此时打开智能设备的蓝牙列表搜索点击“M122”进行连接，耳机与智能设备连接成功后，有提示音，且耳机指示灯熄灭	左右耳灯光熄灭	Connected /连接成功
切换音乐/游戏模式	连接设备状态下连击左右耳机触摸键4次，进行模式切换，说出“默认音乐模式”	/	音乐/游戏模式 MUSIC/GAME MODE
播放/暂停	音乐播放模式启动后，双击任意左/右耳机触摸键	/	/
上一曲	音乐播放模式启动后，连击左耳机触摸键三次	/	/
下一曲	音乐播放模式启动后，连击右耳机触摸键三次	/	/
增加音量	音乐播放模式启动后，单击左耳机触摸键	/	最大音量提示音
减小音量	音乐播放模式启动后，单击右耳机触摸键	/	/
语音助手	连接状态下，长按左耳机触摸键3秒松开，即可唤醒语音助手	/	叮咚
接听来电	来电状态下，连击任意左/右耳机触摸键	/	手机铃声提示音
挂断来电	来电状态下，长按任意左/右耳机触摸键2秒	/	/
挂断电话	通话状态下，双击任意左/右耳机触摸键	/	/

耳机参数

- | | |
|---------------------------------|----------------------------------|
| 1. 产品名称: M122 | 10.喇叭额定功率:5mW |
| 2. 蓝牙版本: Bluetooth 5.49 | 11. 耳机电池容量: 3.7V/40mAh (聚合物电池) |
| 3. 充电仓电池容量: 3.7V/500mAh (聚合物电池) | 12. 充电仓电池容量: 3.7V/500mAh (聚合物电池) |
| 4. 蓝牙传输距离: 10m | 13. 充电接口: USB Type-C |
| 5. 载波频率: 2.402GHz-2.480GHz | 14. 耳机使用时间: >6-8小时 |
| 6. 频率范围: 20Hz-20KHz | 15. 耳机单次充电时间: >1.5小时 |
| 7. 喇叭尺寸: 8-10mm | 16. 充电仓充电时间: >1.5小时 |
| 8. 喇叭灵敏度: 129dB ± 3dB | 17. 充电仓充电次数: 约5-6次 |
| 9. 喇叭阻抗: 16Ω±15% | 18. 关机待机电时间: >3000小时 |

简单故障排查

故障	原因	解决方法
不开机	耳机电量不足	对耳机进行充电
耳机内白灯	耳机电量不足	对耳机进行充电
充电无提示	耳机没有放好	调整耳机放置的位置
自动关机	自动电量不足	对耳机进行充电
耳机不回音	音量太大或者环境太嘈杂	调节音量或更换环境
耳机有杂音	外界干扰严重或距离手机太远	更换地点或靠近手机
对方声音小	耳机佩戴不正确或音量太小	调节耳机佩戴或音量大小
信号断续	外界干扰严重或距离手机太远	选择无干扰的环境或靠近手机


安全指引

- 初次使用本产品前，请先充满电再使用。
- 本产品不是玩具，12岁以下儿童须在成人监护下使用。
- 请勿使用通过正规厂家安全认证的5V/1A充电器，避免支持高电压的快速充电器对产品造成损坏。
- 请在安全的环境下充电，在给充电仓充电时，电量充满后请尽快将充电线拔出，避免长时间充电对电池造成损坏。充电仓的充电方式为Type-C接口。
- 本产品内置不可拆卸的可靠锂电池，重复对耳机进行充电和放电会随时间推移而导致电池性能下降，这对于所有可以重复充电电池来说均属于正常现象。
- 本产品带有锂电池，如长时间未使用，请至少一个月充电一次。
- 因个别差异原因，如佩戴时感到皮肤不适，请停止佩戴并咨询医生。
- 在蓝牙连接本产品使用时，请将耳机音量调至合适音量大小，以免长期在大音量状态下对听力造成损伤。
- 如果您在从事需要集中注意力的活动时使用本产品，应注意自身和其他人的安全，例如驾车或骑自行车时，在道路、施工现场、铁路上或徒步行走时，您应取下耳机或调整音量以确保可以听到周围的声响，包括警告和警告信号。
- 请遵守所在地区或国家的相关规定，驾车时按相关要求使用本产品。
- 本产品含有磁性材料，使用或安放产品时，请远离具有强磁场或强电流的电器，如微波炉、电冰箱等。

- 建议在温度-0°C-45°C的环境中使本产品。当环境温度低于-5°C时，电池性能会受到限制。
13. 有明文规定禁止使用无线设备的场所，请勿使用本产品，否则会干扰其它电子设备或导致其它危险。
14. 靠近医疗及工业设备或飞行器之前，请咨询当地工作人员能否使用。
15. 对本产品清洁和维护前，请停止使用本产品，关闭所有应用，并断开与其它设备的所有连接或传输。
16. 请根据本地法令，正确处理废弃电子产品，不可将电子电气设备、部件、电池与其它生活垃圾一起丢弃。

警告

- 请遵循本说明书的内容进行使用，避免产品因误操作损坏。
- 本产品请远离儿童、火源、热源、冷冻源、水源及化学品。
- 请勿长时间使用使大音量收听，以免对听力造成不良影响。
- 请勿将产品及附件浸入任何液体或用水冲洗产品，否则导致火灾或触电危险。
- 请勿将产品放置在太阳直射或者温度高、高温、高湿等环境中，避免产品损坏。
- 请勿将本产品放在尘土多、温度和湿度过高或过低的地方保存。
- 请勿将磁条卡(例如银行卡、公交卡等)长期接触本产品，否则可能导致磁条卡被磁场损坏。
- 请勿在本产品上施加较大的压力，或拆卸、摔打、震动本产品，以防产品损坏。
- 请勿在靠近热源处使用本产品，如散热器、热风调节器、炉灶或其他产生热量的仪器。
- 请勿将本产品产品的开口处，如充电口、指示孔、麦克风等。
- 请勿在雨天天气下使用本产品，设备可能导致设备出现故障，增大电击的风险。
12. 请勿避免本产品及其附件受潮或受冻，且剧烈运动或出汗较多时使用本产品，防止液体渗透到产品内部损坏本产品。
13. 本产品属于内置聚合物锂电池，不可更换，请勿丢弃或置于火中，以免爆炸、起火等危险发生。
14. 如因消费者违反上述警告而不恰当使用所造成的人身及财产损失将由自行承担一切后果本公司将不产生任何法律责任。



产地：中国·广东


英语

AI INSTRUCTION MANUAL

M122

OVS Bluetooth earphones

Product structure diagram



Packing list

Headphones x2pcs
Charging case x1pcs
Type-C charging cable x1pcs
Instruction manual x1pcs

Take out the headphones and hang them on your ears, wearing them in a suspended ear style. The suspended ear feels light and fits snugly without getting into your ears, making them lightweight and comfortable to wear all day long without tiring your ears.

Quick Start

Connect to the phone app

Please scan the QR code to download and install the Wearfit Pro app, or go to major app stores, search for "Wearfit Pro", and download and install the app.

For first-time use, please register a personal account and grant the necessary permissions for the app to function properly, ensuring the device works as expected.

Turn on the phone's Bluetooth, find the earphone device named "M122" in the Bluetooth list, and click to connect. After a successful connection, open the "Wearfit Pro" app, go to the device page, click the "+" icon in the top-right corner, and tap "Add Device" to start Bluetooth search. Find the Bluetooth device named "M122", click to connect, and once connected successfully, you can enter the earphone interface.

Note: If the connection is not successful, please check whether the phone's Bluetooth is enabled, whether the earphone device is powered on and in pairing mode, or if the earphone device is already connected to another phone.

Wearfit AI Conversation

Open the "Wearfit Pro" app, click the top-right corner to enter the headphone device page, tap the "Wearfit AI" card on the homepage to access the feature page. Tap the bottom-left corner to switch between voice input and text input modes. After sending the input, the AI will provide a response, and the headphones will broadcast the content simultaneously.

One-click Translation

Open the "Wearfit Pro" app, click the top-right corner to enter the headphone device page, tap the "Press to Speak" button. After recording your voice, the translation will be automatically provided, and the headphones will broadcast the translated content. Tap the language box at the bottom to switch languages.

Simultaneous Interpretation

Open the "Wearfit Pro" app, click the top-right corner to enter the headphone device page, tap the "Simultaneous Interpretation" card on the homepage to access the feature page, then click "Start Interpretation" to enter the recording interface. The device will automatically detect and input sound, providing simultaneous translation, while the headphones will broadcast the translated content. Tap the language box at the top to switch languages, and click the play button at the bottom-right corner to pause/start audio recording.

White Noise

Open the "Wearfit Pro" app, click the top-right corner to enter the headphone device page, tap the "White Noise" card on the homepage to access the feature page, tap the audio card to enter the playback page, click the play button to play/pause the audio, and tap the "Single Play" button to switch the playback mode.

Introduction to product operation

function	operate	Light	Tone
Pair name	M122		
Boot	Headphones in the case of charging bin, take out the headphones automatically, boot/Headphones off state, Long Touch Key 3 seconds to boot	White light flashing	Power on/开机
Shutdown	Put the earphone into the charging bin and shut down automatically. Press the touch button for 5 seconds to shut down the earphone	The white light stays on for 1 second before turning off	Power off/关机
Pair the left and right earphones	The left and right earphones will automatically enter pairing mode after powering on	After successful pairing of the left and right ears, the white light of the main earphone flashes and the light of the auxiliary ear goes out	Connected/Pairing successfully
Toggle the Chinese and English prompt tones	Without connecting the smart device, double-click any left/right ear touch key 4 times, language switch. Factory default English	/	English/中文
Smart device connectivity	When the ears are successfully paired, it will automatically enter the state to be connected at this time, open the Bluetooth list of the smart device, search for "M122", and click to connect. Once connected successfully, the earphone will go off	The lights in the left and right ears are turned off	Connected /连接成功
Play/Pause	Connect the device to the state of the left and right ear touch keys 4 times, mode switching, the factory default music mode	/	音乐/游戏模式 MUSIC/GAME MODE
Previous song	After the music player starts, double-click any left/right earphone touch button	/	/
Next song	After the music player starts, double-click the right earphone touch button three times	/	/
Increase the volume	After the music player starts, click the touch button on the right headset	/	Maximum volume indicator (knock)
Reduce the volume	After the music player starts, click the touch button on the left headset	/	/
Voice assistant	Connect the device to the state of the left and right ear touch keys 4 times, mode switching, the factory default music mode	/	Ding Dong
Answer an incoming call	When the call is incoming, double-click any left or right earphone function key	/	Ringtone of your phone

Reject an incoming call	When the call is incoming, press and hold the function button of any left or right earphone for 2 seconds	/	/
Hang up	While on the phone, double-click the touch button on any headset	/	/
Low battery alarm	When the voltage of the earbuds is lower than 3.3V, there will be a prompt up to the ear Powered off	The white light flashes every 5 seconds	Ding Dong
Disconnect	Outside the effective connection range, or manually disconnect the Bluetooth connection of the smart device	The main headphone's white light is flashing, and the auxiliary earphone's light is off	Disconnected /断开连接
Automatic reconnection	After powering on or disconnecting the earbuds will automatically reconnect to the last connected smart device within the effective distance	The lights go out	connected /连接成功
Charge the headphones	The earphones will automatically shut down and start charging when placed back in the charging compartment. The white light of the earphones will remain on, and the light will turn off when fully charged		
The charging indicator of the headphones	Put the earphones into the charging compartment, and the charging compartment will charge the earphones instantly with a continuous light prompt. After the earphones are fully charged, the charging indicator light will turn off and the earphones will be charged. The electric compartment blue light will turn off after 15 seconds.		
Charging bin charging	When the battery level in the charging compartment is too low, connect a standard output 5V power adapter to the charging compartment for charging, and the red light of the charging compartment will flash	The red light stays on continuously after the charging compartment is fully charged	
The charging bin fully charged			

Headset parameters

- | | |
|---|--|
| 1. Product name: M122 | 10. Nom rated power: 5mW |
| 2. Bluetooth version: Bluetooth 5.49 | 11. Headphone battery capacity: 3.7V/40mAh (polymer battery) |
| 3. Support mode: AAC/SBC | 12. Charging bin battery capacity: 3.7V/500mAh (polymer battery) |
| 4. Bluetooth transmission distance: 10m | 13. Charging interface: USB Type-C |
| 5. Carrier frequency: 2.402GHz-2.480GHz | 14. Headset use time: >6-8 hours |
| 6. Frequency response range: 20Hz-20KHz | 15. Earphone single charging time: >1.5 hours |
| 7. Nom size: 8-10mm | 16. Charging time: >1.5 hours |
| 8. Nom sensitivity: 129dB ± 3dB | 17. Charge the headset: About 5-6 times |
| 9. Nom impedance: 16Ω±15% | 18. Shutdown standby time: >3000 hours |

Simple troubleshooting

fault	cause	Resolution
Doesn't turn on	The headphones are low on battery	Charge the headphones
Headphones flash white light	The headphones are low on battery	Charge the headphones
Charging is slow	The headphones were not put away	Adjust the position where the headphones are placed
Automatic power off	Automatic low battery	Charge the headphones
The headphones have an echo	The volume is too loud or the environment is too noisy	Adjust the volume or change the environment
There is a murmur from the headphones	Serious external interference or too far away from the phone	Change the location or be close to your phone
The other party's voice is quiet	The headphones are worn incorrectly or the volume is too low	Adjust the headset wear or volume
The signal is intermittent	Serious external interference or too far away from the phone	Choose a distraction-free environment or be close to your phone


Safety guidelines

- Before using this product for the first time, please fully charge it before using it.
- The product is not a toy, and children under the age of 12 must be used under the supervision of an adult.
- Please use a 5V/1A charger that has passed the safety certification of a regular manufacturer to avoid damage to the product caused by a fast charging charger that supports high voltage.
- Please charge in a safe environment, when charging the charging case, please pull out the charging cable as soon as possible after the power is fully charged to avoid damage to the battery caused by long-term charging. The charging method of the charging case is the Type-C interface.
- This product has a built-in non-removable rechargeable battery, and repeated charging and discharging of the earbuds will lead to a decrease in battery performance over time, which is normal for all rechargeable batteries.
- This product comes with a healthy battery, if it has not been used for a long time, please charge it at least once a month.
- If you feel skin discomfort when wearing it due to individual differences, please stop wearing it and consult a doctor.
- When using this product with Bluetooth connection, please adjust the sound of the earphones to an appropriate volume to avoid hearing damage caused by long-term loud volume.
- When using this product while engaging in activities that require concentration, you should pay attention to your own safety and the safety of others, such as when driving or cycling, on roads, construction sites, railways, or walking. You should remove your headphones or adjust the volume to ensure that you can hear the sounds around you, including alarms and warning signals.

- Please follow the relevant regulations of your region or country and use this product as required when driving.
- This product contains magnetic materials, please keep away from electrical appliances with strong magnetic or electric fields, such as microwave ovens, refrigerators, etc., when using or placing the product.
- It is recommended to use this product in an environment with a temperature of -0°C-45°C. When the ambient temperature is below -5°C, battery performance is limited.
- Do not use this product in places where it is expressly prohibited to use wireless equipment, otherwise it will interfere with other electronic equipment or cause other dangers.
- Before approaching medical or industrial equipment or boarding a plane, please ask the local staff if they can use it.
- Before cleaning and maintaining this product, stop using this product, turn off all applications, and disconnect all connections or cables to other equipment.
- Before disposal of waste electronic products properly in accordance with local laws and regulations, and do not dispose of electrical and electronic equipment, parts, batteries and other household waste.

warn

- Please follow the content of this manual to avoid damage to the product due to incorrect operation.
- Keep this product away from children, fire, heat, refrigeration, water and chemicals.
- Do not listen at a loud volume for a long time to avoid adverse effects on hearing.
- Do not immerse the product and accessories in any liquid or rinse the product with water, otherwise it will cause fire or electric shock hazard.
- Do not place the product in the sun or in a place with high temperature. High temperature can shorten the life of electronic components, damage batteries, and deform certain plastic parts.
- Do not store this product in a place with a lot of dust, too high or too low temperature and humidity.
- Do not contact the magnetic stripe card (such as bank card, bus card, etc.) with this product for a long time, otherwise it may cause the magnetic stripe card to be damaged by the magnetic field.
- Do not apply greater pressure to this product, or disassemble, beat, or shake this product to prevent damage to the product.
- Do not use this product near heat sources, such as radiators, hot air regulators, stoves, or other instruments that generate heat.
- Do not block the openings of this product, such as charging ports, indicator lights, microphones, etc.
- Do not use the device in rainstormy weather, thunderstorms may cause the device to malfunction and increase the risk of electric shock.
- Please avoid using this product when this product and its accessories are exposed to rain or moisture, and when you exercise vigorously or sweat a lot, to prevent liquid from penetrating into the product and causing damage.
- The product belongs to the built-in polymer battery, which cannot be replaced, please do not discard or put it in the fire to avoid explosion, fire and other dangers.
- If the consumer violates the above warning and inappropriate use, the personal and property damage will be borne by the company, and the company will not incur any legal responsibility.



产地：中国·广东

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.