



Quick Start Guide





- | | | |
|----------------------|-------------------------|---------------------|
| 1 Scan/Action Button | 5 Keypad | 9 Scan/Decode LED |
| 2 Up/Down Button | 6 Scan/Action Button | 10 Charging LED |
| 3 Microphone | 7 Touch Screen | 11 Radio Status LED |
| 4 I/O Connector | (with screen protector) | 12 Phone Speaker |
| | 8 Power Button | |

Note 1: To reset the MC70, press and hold the power button for five (5) seconds.

- | | | |
|-------------------|----------------------------|-------------------------|
| 13 Battery Door | 18 Speaker | 22 Scan/Action Button |
| 14 Door Latch | 19 Scan Window | 23 Action Button |
| 15 Handstrap | (see Data Capture Options) | 24 Back Housing Bracket |
| 16 Handstrap Slot | 20 Stylus | 25 Memory Card Slot |
| 17 Headset Jack | 21 Tether Point | |




- 1 Call
- 2 Soft Key
- 3 Navigation
- 4 Scan/Action Button
- 5 End Call
- 6 Orange Key
- 7 Backlight
- 8 Blue Key
- 9 OK
- 10 Phonepad
- 11 Menu
- 12 Start Menu

**Blue Key**



Use this key to launch applications and select items (shown on the keypad in blue).
> Press the  key once to activate this mode followed by another key.

Orange Key

Use this key to access the secondary layer of characters and actions.
> Press the  key once to lock the keypad in the Alpha state.
> Press the  key a second time to return to the normal state.

1 Insert the Battery

Note 2: Standard Capacity Battery and Door shown.


2 Charge the MC70**1-Slot Cradle****4-Slot Cradle****Charging LED**

Blinking Amber = Charging
Solid Amber = Fully Charged
Fast Blinking Amber = Charging Error

* It is recommended that this product be charged for 24 hours before the first use to ensure that the internal battery is fully charged.

3 Install ActiveSync[®]

Download ActiveSync[®] 4.0 or higher from <http://www.microsoft.com> and follow the instructions to install ActiveSync onto the host computer.

4 Communicate with Host**5** Create a Partnership

Follow the on-screen ActiveSync instructions to establish a connection between the MC70 and the host computer.

SUPPORT INFORMATION

More information on the MC70
Visit the Symbol Web site at <http://www.symbol.com/mc70>

Setting up and using the MC70
MC70 User Guide
MC70 Integrator Guide
Available at: <http://www.symbol.com/mc70>

Troubleshooting
MC70 – MC70 User Guide
Accessories – MC70 Integrator Guide
Available at: <http://www.symbol.com/mc70>

Connecting and synchronizing with the host computer
ActiveSync® Help on the host computer. To view help, start ActiveSync®, click Help - Microsoft ActiveSync Help.

Information on using programs on the MC70
Tap Start – Help within the specific program.

Service and Warranty
MC70 Regulatory Guide




© 2005 Symbol Technologies, Inc.

72-71770-01
Rev A - November 2005


MC70 Quick Start Guide

ACCESSORIES

Memory Card Installation




SIM Card Installation (Located Under Battery)



<http://www.symbol.com/mc70>

SYMBOL TECHNOLOGIES, INC. One Symbol Plaza Holtsville, New York 11742-1300

Screen Protector




Symbol recommends the use of a screen protector to minimize wear and tear. Screen protectors enhance the usability and durability of touch screen displays. Benefits include:

- Protection from scratches and gouges
- Durable writing and touch surface with tactile feel
- Abrasion and chemical resistance
- Glare reduction
- Keeping the device's screen looking like new
- Quick and easy installation.


Not using a screen protector can affect your warranty coverage.

An initial screen protector is already applied to your MC70. Contact your local account manager or Symbol Technologies, Inc. for more information and purchasing details. Part number: KT-67525-01 Screen Protector 3/pk.

Vehicle Cradle




Trigger Handle



Standard Capacity Battery: ~ 4 hours Extended Capacity Battery: ~ 8 hours


Charge in Cradle

Flashing Amber: Battery charging
Solid Amber: Battery fully charged




Spare Battery Charger

Flashing Amber: Battery charging
Solid Amber: Battery fully charged




Snap-On Accessories

Magnetic Stripe Reader




Cables




DATA CAPTURE OPTIONS

Scanner




Imager




OPTIMUM SCANNING AND IMAGING


Scanning/Imaging




Scanning



Imaging



AVOID EXTREME WRIST ANGLES



AVOID EXTREME WRIST ANGLES

