

FIGURE 3
LED STRIP (M/N: CSTN10CDID)
COVER REMOVED




FIGURE 4
LED STRIP (M/N: CSTN10CDID)
MAINBOARD FRONT




FIGURE 5
LED STRIP (M/N: CSTN10CDID)
MAINBOARD BACK




FIGURE 6
LED STRIP (M/N: CSTN10CDID)
CHIP&CRYSTAL ON BOARD#1




FIGURE 7
LED STRIP (M/N: CSTN10CDID)
CHIP&CRYSTAL ON BOARD#2




FIGURE 8
LED STRIP (M/N: CSTN10CDID)
ANTENNA

