


<p style="text-align: center;">BLUETOOTH SPEAKER USER MANUAL</p> <p>Packing List</p> <ol style="list-style-type: none"> 1.) Bluetooth Speaker 2.) USB cable 3.) Speaker Strap 4.) User Manual  <p style="text-align: center;">1</p>	<p>How to recharge the Bluetooth Speaker Connect the micro USB cable onto the device with 5V DC power source. The red charging indicator light will indicate when charging is in progress; and the red light will switch off automatically after charging is completed. Please remove the micro USB cable immediately after the Bluetooth Speaker is fully charged.</p> <p>How to use the Bluetooth Speaker <u>Power on/off:</u> Press and hold the Press Button for 3-5 seconds to turn the device on or off; after the speaker is turned on it will start with the Bluetooth mode (by default). A Blue indicator light will flash frequently to indicate that the speaker is not in pair with any device.</p> <p><u>Switch mode:</u> Double click the Press button to switch the Bluetooth mode and the Camera mode.</p> <p style="text-align: center;">2</p>	<p>How to connect the speaker with your electronic device via Bluetooth Press and hold the Press Button to turn the speaker on; or double click the Press Button to switch to Bluetooth mode. A voice signal "Bluetooth mode" will emit to indicate the speaker is in Bluetooth mode. Enable Bluetooth function on your personal electronic device and scan for speaker "MO8644". Pair your device with the "MO8644" speaker for connection. A Blue indicator light will stay on to indicate that the speaker is successfully paired. Now you are ready to control your electronic device with the speaker.</p> <p>How to control music In Bluetooth mode, click the Press Button to Play or Pause music.</p> <p>How to answer a call when device is in use In Bluetooth mode, an incoming call will automatically go to the speaker. Click the Press Button to answer the call.</p> <p style="text-align: center;">3</p>	<p>Please be reminded to place the MIC toward you for better sound quality.</p> <p>How to use remote shutter function In camera mode, click the Press Button once to take a photo.</p> <p>NOTE: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a</p> <p style="text-align: center;">4</p>	<p>particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/ TV technician for help. This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.</p> <p style="text-align: center;">5</p>
--	---	--	--	--

LIL JAMMERZ™ PRODUCT INFORMATION AND BLUETOOTH® SPEAKER OPERATING INSTRUCTIONS



Once your Lil' Jammerz™ speaker is fully charged and the FREE app has been downloaded, you're ready to use it. Just power on the speaker, pair it with your Bluetooth device, slip it inside the hook-and-loop zipper pouch, attach the toys to your car seat or stroller and enjoy the music!

Prior to regular operation, the Lil' Jammerz™ Bluetooth speaker must be charged approximately 3 hours, and paired with your smartphone or tablet. Remember that most of the Lil' Jammerz™ Bluetooth speaker functionality is controlled by your phone or Bluetooth-enabled device, so you'll want to familiarize yourself with its settings. Most Bluetooth devices will "remember" your Lil' Jammerz™ speaker, so you'll only have to pair it once.

INFORMATION

- Your Lil' Jammerz™ interactive toy's Bluetooth speaker connects easily to most popular Bluetooth-enabled devices (smartphones, tablets, and portable handheld devices) within 25 feet.
 - Use beyond the specified 25-foot range can affect sound quality and the ability to control the Lil' Jammerz™.
 - The speaker will operate for approximately 2 hours when fully charged.
 - Power-off the speaker when not in use to prolong battery life.
 - The speaker will give an audible warning when charging is required.
 - When using a Smartphone, incoming phone calls will not ring on the speaker.
- If you choose to accept the incoming call on your smartphone, the Lil' Jammerz Bluetooth speaker will stop playing music. Reconnect the Bluetooth function after call is completed.
- Plush toys are hand washable, line-dry. Remove speaker before hand washing.

PAIRING

- To start pairing, make sure your Bluetooth device is ON, and the Lil' Jammerz™ Bluetooth speaker is OFF.
- The speaker and Bluetooth-enabled device should be no more than 3 feet apart when pairing.
- Press and hold the center button to turn ON the Bluetooth speaker.
- Find the Bluetooth device settings screen on your phone or device.
- Your device will search for available Bluetooth pairings. (For details for your device – Smartphone, tablet, etc., refer to the device user guide.)
- Select "Lil' Jammerz" from the list.
- If it does not appear on the list, turn the Bluetooth speaker OFF. Restart your phone or other Bluetooth device. Once your phone is ON, turn the Bluetooth speaker ON again and attempt pairing.
- When pairing is successful, a voice alert will notify the user, "Bluetooth Connected."
- Immediately secure the speaker into the purple microphone plush toy hook and loop zipper pouch. Zip the zipper completely and seal the hook and loop material.
- Bluetooth speaker can only be paired with one device at a time.

POWER ON: To turn the power ON, press and hold the center button for three to four seconds. The voice alert will notify you when the power is ON, and then again when the speaker is connected to your Bluetooth device. Once the speaker is connected, insert it into the purple microphone plush toy hook-and-loop zipper pouch. Zip the zipper completely and seal the hook-and-loop closure.

SELECTING AND PLAYING MUSIC

Once powered ON and paired, the Bluetooth speaker should now be in standby mode, ready to use*. Use your Bluetooth device to select the music you want to play from any source such as your music library, internet radio, or the Lil' Jammerz™ app. Use your phone or other device to select tracks, adjust the volume, play and pause music, etc. While the speaker volume level is >80dB, Lil' Jammerz encourages childcare giver to keep volume adjusted low. Battery power is being used whenever the speaker is ON, whether in standby mode (ON but not playing) or playing music.

POWER OFF: To turn the power OFF, open the hook-and-loop seal, unzip the zipper, and remove the speaker. Press and hold the center button for three to four seconds. The voice alert will notify you that the speaker is no longer connected to the Bluetooth® device, and then again when powering down. Return the speaker to its secure, hook-and-loop zipper pouch or place it out of the reach of children.

CAUTION

- The Lil' Jammerz™ Bluetooth speaker unit is not a toy, and should always be secured inside its hook and loop zipper pouch or removed and out of child's reach when you are not playing music.
- Prior to using the speaker, charge the battery with the USB cable included with the speaker. Charging time is approximately three hours.

• The speaker battery is not replaceable, only rechargeable.

• To avoid damage to the speaker, please use only the USB cable shipped with the product.

• Visit liljammerz.com/bluetooth-safety for information on SAR and Bluetooth devices.

Questions? Contact Customer Care info@liljammerz.com or 888.811.9110

FCC ID: 2AMAT1022SRB
MADE IN CHINA

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Lil' Jammerz™ is under license. Other trademarks and trade names are those of their respective owners.