




# Read the manual before use


If you have any questions, please contact the customer service to deal with them immediately Please do not make negative comments at will. Our service is up to your satisfaction

**Important:** Plug in the charging wire for charging at the first time after receiving the goods, and use it after fully charging, which can make the headset last longer

**Important:** Do not use super fast charging with current above 2A to avoid damaging the circuit chip due to excessive current



the earphone touch control is marked in red circle



If you find that you do not like or will not use the goods, remember to contact the store customer service to teach you how to use them. If you do not like to return the goods and remember to choose another reason for returning, this is very important to us. Thank you very much !

If only one side has sound, please first delete the BD2 that has been connected, turn off the wireless of your phone, the earphones need to be paired once, enter the tws mode, and return to the first step

**Important:** Plug in the charging wire for charging at the first time after receiving the goods, and use it after fully charging, which can make the Bluetooth headset last longer

**Important:** Do not use super fast charging with current above 2A to avoid damaging the circuit chip due to excessive current


## The connection steps are as follows:

Open the cover of the phone, first make sure the wireless of the phone is off, Take out the two headphones from the charging case, wait for 10 seconds, the headphone indicator light changes from fast flash to one headphone light off, it means the headphones have been paired. Open the Bluetooth of your cell phone, search for "BD2", click to connect

## Touch function

- 1: Click the headset touch area Play/Pause/Answer/Hang up
- 2: Double click on the left ear to open the ANC function
- 3: Double click on the right ear to open the pass-through function
- 4: Triple-click the headset touch control area Volume down/volume up
- 5: Four click on the headset touch control area previous song/next song
- 6: Long press the left earphone for 2 seconds to start Siri function
- 7: Long press 2 seconds on the right headset Game mode / music mode switching

## the earphone touch control is marked in red circle



## Charging method:

Plug in our matching charging cable, charging the display shows the power, when charging to 100%, which is fully charged!

If you find that you do not like or will not use the goods, remember to contact the store customer service to teach you how to use them. If you do not like to return the goods and remember to choose another reason for returning, this is very important to us. Thank you very much !

## FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.