


ATTACHMENT A
USER'S MANUAL (DRAFT)

A complete user's manual has not been prepared by OMRON Corporation. It will be prepared by the auto manufacturer installing the equipment in its vehicles. The enclosure is part of an instruction manual which has been prepared by OMRON Corporation.

REMOTE TRANSMITTER



You can lock and unlock your vehicle with the remote transmitter.

LOCK

When you push the LOCK button, all the doors will lock.

You cannot lock any of the doors with the remote transmitter if any door is open or the key is in the ignition switch.

UNLOCK

When you push the UNLOCK button, all the doors will unlock. If you unlock the doors with the remote transmitter, but do not open any of the doors within 30 seconds, the doors will automatically relock.

You cannot unlock any of the doors with the remote transmitter if any door is open or the key is in the ignition switch.

 CAUTION

The remote control switch is a precision electronic device. Therefore, pay attention to the following:

- Do not impose shock on the remote control switch.
- Keep the remote control switch dry.
- Do not disassemble the remote control switch.

 CAUTION

Changes or modifications not expressly approved by the manufacturer for compliance could void the user's authority operate the equipment.

 CAUTION

When the remote control switch is opened, keep water, dust, etc. off its inside. In addition, do not touch the precision electronic device.

Your keyless entry system operates on a radio frequency subject to Federal Communications Commission (FCC) rules and Industry Canada rules. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

"Complies with RSS-210 of Industry Canada."