


产品配色与工艺说明图


Product Colour, Material & Finishing Specfications


Product Model 产品型号	TB30	Brand 品牌	中性	Job No. 图档编码	
Product Type 产品类	无线充电器说明书	Description 描述	/	Revision 版本号	
Dimension 尺寸	85*65mm	Original Designer 原设计师		Date 日期	2020/3/5
Scale 比例	1:1	Technology 工艺	128g哑粉纸 双面四色印刷	Verifing 审核	/






User Manual





"Under bluetooth connection,long perss" ▷■",the bluetooth speaker makes a "drip" sound,represent the bluetooth is disconnected and the green light flashes,waiting for the next pairing.
"Click"—"button for the previous song,long press is reduce the volume "Click"—button for the next song,long press is increase volume.





Radio / TF card



Working Instructions of Bluetooth speaker indicator light

Connected dev	ice Light keeps green	
Working Ins	structions of Battery Charging Indicator Light	
Charging	light keeps red	
Fully charged	light keeps green	

Power on	The wireless charging indicator light flashes green and blue alternately, 2seconds later both blue and green lights on at the same time, then the green light on for standby.
Standby	Light keeps green
Charging	Light keeps blue
Fully charged	The light will turn to green when fully charged, except when charge iPhones. (The light will not turn to green when the iPhones fully charged.)
Error report	Blue light flashes.